



**士林電機**  
Shihlin Electric

# Shihlin Electric General Inverters


## SL3 Series

### User Manual

#### *Compact*

SL3-021-0.4K ~ 2.2K

SL3-043-0.4K ~ 2.2K



MANUAL GUIDE	1
DELIVERY CHECK	2
INVERTER INTRODUCTION	3
BASIC OPERATION	4
PARAMETER DESCRIPTION	5
INSPECTION AND MAINTENANCE	6
APPENDIX	7



# 1. MANUAL GUIDE

## 1.1 Safety instructions

Thank you for choosing Shihlin inverters SL3 series. This user manual introduces how to use the product correctly. Please read the user manual carefully before using the product. In addition, please use the product after understanding the safety instructions.

### Safety Instructions

- ✓ Installation, operation, maintenance and inspection must be performed by qualified personnel.
- ✓ In this instruction, the safety instruction levels are classified into "Warning" and "Caution".
- ⚠ **Warning:** Incorrect handling may cause hazardous conditions, resulting in death or severe injury.
- ⚠ **Caution:** Incorrect handling may cause hazardous conditions, resulting in medium or slight injury, or may cause only material damage.

#### Warning

- ✓ While the inverter power is ON, do not open the front cover or the wiring cover. Do not run the inverter with the front cover or the wiring cover removed. Otherwise you may access the exposed high voltage terminals or the charging part of the circuitry and get an electric shock.
- ✓ It is crucial to turn off the inverter power before any wiring installation or inspection is made. Before the inverter screen is OFF, which indicates that there is still high voltage in it, please do not touch the internal circuit and components.
- ✓ The inverter must be connected to the ground properly.
- ✓ Do not operate or touch the heat sink or handle the cables with wet hands. Otherwise you may get an electric shock.
- ✓ Do not change the cooling fan while power is ON. It is dangerous to change the cooling fan while power is ON.

#### Caution

- ✓ Voltage applied to each terminal must be the one specified in the user manual; otherwise, failure or damage may be caused.
- ✓ Do not operate a voltage-resistant test for the parts inside the inverter because semiconductors in inverter may be easily damaged due to high-voltage breakdown.
- ✓ Do not touch the inverter because the temperature of the inverter is very high when it is powered on or right after disconnecting the power supply; otherwise, burn may occur.
- ✓ Failure or damage may be caused due to wrong wiring.
- ✓ Do not reverse the polarities (+, -) by mistake, failure or damage may be caused.
- ✓ Please install the inverter on nonflammable walls without holes (to avoid contacts with the cooling fin of the inverter from the back). If the inverter is installed on or close to flammable objects it may cause a fire.
- ✓ Please disconnect the inverter from power supply in case of failure. Overload current passes through the inverter continuously may cause a fire.

#### Other Precautions:

\*1 If the product is ultimately used as a military unit, or when the product is used for weapons manufacturing, etc., this product will be included in the export product control object specified in the "Foreign Trade Law of PRC". When exporting, strict inspection and export procedures are required.

\*2 In this manual, the case or the safety cover will be remove, and the description will be made in graphics and text in order to explain the product in detail. When operating, to ensure safety be sure to install the case and wire correctly according to the regulations referred in manual.

\*3 Graphics in the manual are slightly different from the actual product for the convenience of illustrating, this will not affect customer rights.

\*4 To improve our products, parameters and contents may be modified in the future, and the contents of this manual are subject to change without notice. Please download the latest version from Shihlin website ([www.sseec.com.cn](http://www.sseec.com.cn) or [www.seec.com.tw](http://www.seec.com.tw)).

## 1.2 Table of contents

User Manual .....	1
1. MANUAL GUIDE .....	1
1.1 Safety instructions.....	1
1.2 Table of contents.....	2
1.3 Definitions of terminologies.....	10
2. DELIVERY CHECK.....	11
2.1 Nameplate instruction.....	11
2.2 Type instruction .....	11
2.3 Order code description .....	11
3. INVERTER INTRODUCTION.....	12
3.1 Electric specification .....	12
3.1.1 440V series three-phase.....	12
3.1.2 220V series single phase.....	13
3.2 General specification .....	14
3.3 Appearance and dimensions.....	15
3.3.1 Frame A .....	15
3.3.2 Frame B .....	16
3.4 Name of each component.....	17
3.4.1 Frame A/B.....	17
3.5 Installation and wiring.....	18
3.5.1 Transportation.....	18
3.5.2 Stockpile.....	18

---

3.5.3 Installation notice .....	18
3.5.4 EMC installation instructions.....	21
3.6 Peripheral devices.....	22
3.6.1 System Wire Arrangement.....	22
3.6.2 No-fuse breaker and magnetic contactor .....	23
3.7 Terminal wire arrangement.....	24
3.7.1 Main circuit Terminals .....	25
3.7.2 Main circuit wiring and terminal specification .....	26
3.7.3 Ground .....	26
3.7.4 RFI filter.....	26
3.7.5 Control circuit .....	27
3.8 Replacement procedure of fan .....	29
4. BASIC OPERATION .....	30
4.1 Component name of keypad .....	30
4.2 Operation modes of inverter .....	31
4.2.1 Flow chart for switching operation mode .....	32
4.2.2 Flow chart for switching built-in keypad working mode .....	32
4.2.3 Operation flow chart for monitoring mode .....	33
4.2.4 Operation flow chart for frequency setting.....	34
4.2.5 Operation flow chart for parameter setting .....	34
4.2.6 Operation flow chart for HELP mode .....	35
4.2.7 Operation flow chart for changing motor rotation direction.....	36
4.3 Basic operation steps for different modes .....	37

## Table of contents

---

4.3.1 Basic operation steps for PU mode (00-16(P.79) = 0 or 1) .....	37
4.3.2 Basic operation steps for external mode (00-16(P.79) = 0 or 2) .....	37
4.3.3 Basic operation steps for JOG mode (00-16(P.79) = 0 or 1).....	38
4.3.4 Basic operation steps for communication mode (00-16(P.79) = 3) .....	38
4.3.5 Basic operation steps for combined mode 1 (00-16(P.79) = 4).....	38
4.3.6 Basic operation steps for combined mode 2 (00-16(P.79) = 5).....	38
4.3.7 Basic operation steps for combined mode 3(00-16(P.79) = 6).....	39
4.3.8 Basic operation steps for combined mode 4(00-16(P.79) = 7).....	39
4.3.9 Basic operation steps for combined mode 5(00-16(P.79) = 8).....	39
4.4 Operation.....	40
4.4.1 Check and preparation before running.....	40
4.4.2 Running methods.....	40
4.4.3 Test run.....	41
5. PARAMETER DESCRIPTION .....	42
5.1 System parameter group 00.....	42
5.1.1 Inverter information.....	45
5.1.2 Parameter restoration.....	46
5.1.3 Parameter protection .....	48
5.1.4 Monitoring function.....	50
5.1.5 Speed display .....	52
5.1.6 Built-in keypad set target frequency selection.....	53
5.1.7 PWM carrier frequency .....	54
5.1.8 Stop operation selection .....	55
5.1.9 Forward/reverse rotate prevent function .....	57

---

5.1.10 Operation mode selection.....	57
5.1.11 Motor control mode selection .....	58
5.1.12 50/60Hz switch selection .....	59
5.1.13 Parameter mode setting .....	59
5.2 Basic Parameter Group 01 .....	60
5.2.1 Limiting the output frequency .....	62
5.2.2 Base frequency, base voltage .....	63
5.2.3 Acceleration/deceleration time setting.....	64
5.2.4 Torque boost V/F .....	67
5.2.5 Starting frequency.....	67
5.2.6 Load pattern selection V/F .....	68
5.2.7 JOG run.....	70
5.2.8 Output frequency filter time.....	70
5.2.10 Second function .....	72
5.2.11 Middle frequency, output voltage of middle frequency V/F .....	73
5.2.12 S pattern time.....	74
5.2.13 Remote function acc/dec time selection .....	76
5.3 Analog input and output parameter group 02 .....	77
5.3.1 Proportional linkage gain .....	78
5.3.2 Auxiliary frequency.....	79
5.3.3 Terminal 3-5 signal selection and processing .....	80
5.3.4 Inverter rated current display level .....	85
5.3.5 PWM signal duty cycle.....	85

5.4 Digital input/ output parameter group 03 .....	86
5.4.1 Digital input terminals function selection .....	89
5.4.2 Digital output terminals function selection .....	93
5.4.3 Terminal logic selection .....	94
5.4.4 Digital output signal delay .....	95
5.4.5 Digital input signal filter .....	95
5.4.6 Digital input terminal enable when power on.....	95
5.4.7 Output frequency detection.....	96
5.4.8 Zero current detection.....	97
5.5 Multi-speed parameter group 04.....	98
5.5.1 16 steps speed.....	100
5.5.2 Programmed operation mode.....	102
5.6 Motor parameter group 05 .....	104
5.6.1 Motor parameter .....	105
5.7 Protection parameter group 06 .....	106
5.7.1 Electronic thermal relay capacity .....	107
5.7.2 Current stalling protection.....	108
5.7.3 Over torque detection .....	109
5.7.4 Maintenance alarm function.....	110
5.7.5 Short circuit protection .....	110
5.7.6 Input phase loss protection.....	111
5.7.7 Time record function .....	111
5.7.8 Alarm query function .....	112
5.8 Communication parameter group 07.....	113



---

5.8.1 Shihlin protocol and Modbus protocol .....	114
5.8.2 Communication EEPROM write selection .....	129
5.9 PID parameter group 08.....	130
5.9.1 PID function selection .....	131
5.9.2 PID parameter group .....	131
5.9.3 PID pressure range setting .....	135
5.9.4 PID analog signal feedback loss .....	135
5.10 Application parameter group 10.....	136
5.10.1 DC injection brake .....	138
5.10.2 Zero-speed control.....	139
5.10.3 DC injection brake before start .....	139
5.10.4 Restart mode selection .....	140
5.10.5 Remote setting function selection.....	141
5.10.6 Auto reset function .....	144
5.10.7 Forward and reverse rotation dead time .....	145
5.10.8 Energy-saving function V/F .....	145
5.10.9 Dwell function V/F .....	146
5.10.10 Triangular wave function V/F .....	147
5.10.11 Voltage stall action level .....	148
5.10.12 Reciprocating machine function .....	148
5.11 Special Adjustment Parameter Group 13.....	150
5.11.1 Slip Compensation V/F .....	150
5.11.2 Modulation coefficient .....	150

## Table of contents

---

5.11.3 Vibration inhibition .....	151
5.11.4 Current detection option .....	151
5.12 User registered parameter 15 .....	152
5.12.1 User registered parameter.....	153
6. INSPECTION AND MAINTENANCE.....	155
6.1 Inspection item.....	155
6.1.1 Daily inspection item .....	155
6.1.2 Replacement parts.....	155
6.2 Ways to measure voltage, current, power on main circuit.....	156
6.2.1 Selecting measurement instruments .....	156
6.2.2 Measurement of voltage .....	156
6.2.3 Measurement of current.....	156
6.2.4 Measurement of power .....	156
6.2.5 Measurement of insulation resistance.....	158
6.2.6 Hi-pot test.....	158
7. Appendix.....	159
7.1 Appendix 1 Parameter table.....	159
7.1.1 Parameter in p sequence.....	159
7.1.2 Parameter in group .....	175
7.2 Appendix 2 Alarm code list .....	190
7.3 Appendix 3 : Warning code list.....	192
7.4 Appendix 4:Troubles and solutions .....	193
7.5 Appendix 5 Optional equipment.....	194
7.5.1 PU301 Keypad .....	194

---

7.5.2	DU06 Keypad .....	197
7.5.3	DU08 Keypad .....	198
7.5.4	DU10 Keypad .....	200
7.5.5	PU302 Keypad .....	201
7.5.6	CBL : Data transmission line (for use with the above keypads) .....	203
7.6	Appendix 6 European Specification Compatibility Description.....	204
8.	REVISION RECORD .....	207

## 1.3 Definitions of terminologies


- ✓ Output frequency, target frequency, steady output frequency
  - The actual output current frequency of inverter is called “output frequency.”
  - The frequency set by user (via built-in keypad, multi-speed terminals, voltage signal, and current signal or communication settings) is called “target frequency.”
  - When motor starts running, inverter output frequency will gradually accelerate to target frequency before it finally runs steadily at the target frequency. This output frequency is called “steady output frequency.”
  
- ✓ Parameter settings
  - Detail explanation on parameter settings are provided in Chapter 5. For users who are not familiar with these settings, arbitrary adjustment of the parameter may result in abnormal operations. All parameters can be reset to their default values by the parameter 00-02(P.996~P.999). For setting procedures of this parameter, please refer to 00-02(P.996~P.999) in Section 5.1.2.
  
- ✓ The “operation mode” and “working mode” of the built-in keypad
  - Target frequency command source and start signal source depend on inverter operation mode. There are nine operating modes in Shihlin inverter. Please refer to Section 4.3 for details.
  - Built-in keypad is used mainly for monitoring the numeric values, setting parameters and target frequency. There are a total of four working modes on the Shihlin keypad. Please refer to Section 4.2 for details.
  
- ✓ The difference between “terminal name” and “function name”:
  - Printed letters can be found near the terminals on control board and main board. They are used to distinguish each terminal and are called “terminal name.”
  - For “multi-function control terminal” and “multi-function output terminal,” besides the terminal name, it is also necessary to define the “function name.” The function name indicates the actual functions of the terminal.
  - When explaining the function for a terminal, the name used is its “function name”.
  
- ✓ The difference between “on” and “turn on”:
  - When explaining the function for the “multi-function digital input terminal”, two words “on” and “turn on” are often used:
  - The word “on” is used to indicate that the external switch of the terminal is in close state, and thus it belongs to the description of the state.
  - The word “turn on” is used to describe the action that the external switch of the terminal is shut from the open state to the close state, and thus belongs to the description of action. Similarly, the words “off” and “turn off” belong to the above-mentioned states and actions.
  
- ✓ P.XXX
  - P.XXX refers to parameter number, not page number.

## 2. DELIVERY CHECK


Each SL3 inverter has been checked thoroughly before delivery, and is carefully packed to prevent any mechanical damage. Please check for the following when opening the package.

- Check whether the product was damaged during transportation.
- Whether the model of inverter is the same with what is shown on the package.

### 2.1 Nameplate instruction



### 2.2 Type instruction



### 2.3 Order code description

Example:

Inverter specification	Specification description	Order code
SL3-021-1.5K	SL3 series 220V 1.5kW inverter	SNKSL30211R5K
SL3-043-1.5K	SL3 series 440V 1.5kW inverter	SNKSL30431R5K

### 3. INVERTER INTRODUCTION

#### 3.1 Electric specification

##### 3.1.1 440V series three-phase

Frame		B			
Model SL3-043-□□□K-□□		0.4	0.75	1.5	2.2
Inverter Output	Rated output capacity (kVA)	1	2	3	4.6
	Rated output current (A)	1.5	2.6	4.2	6
	Applicable motor capacity (HP)	0.5	1	2	3
	Applicable motor capacity (kW)	0.4	0.75	1.5	2.2
	Overload current rating	150% 60 seconds, 200% 1 seconds (inverse-time characteristics)			
	Carrier frequency (kHz)	1 ~ 15kHz			
	Maximum output voltage	3 phase 380-480V			
Power Supply	Rated input current (A) *Note 1	1.8	3.2	4.3	7.1
	Rated input AC voltage/ frequency	3 phase 380-480V 50Hz/60Hz			
	Permissible AC voltage fluctuation	3 phase 323-528V 50Hz/60Hz			
	Permissible frequency fluctuation	±5%			
	Power supply capacity (kVA)	1.5	2.5	4.5	6.9
Cooling method		Fan cooling			
Weight (kg)		0.8	0.8	0.85	0.85

Note 1: The value indicates the current at rated output. The rated input current value is not only affected by power transformer, input side reactor, wiring condition, but also fluctuates with the impedance of the power supply side.

## 3.1.2 220V series single phase

Frame		A			B
Model SL3-021-□□□K-□□		0.4	0.75	1.5	2.2
Inverter Output	Rated output capacity (kVA)	1	1.5	2.5	4.2
	Rated output current (A)	2.7	4.5	8	11
	Applicable motor capacity (HP)	0.5	1	2	3
	Applicable motor capacity (kW)	0.4	0.75	1.5	2.2
	Overload current rating	150% 60 seconds, 200% 1 seconds (inverse-time characteristics)			
	Carrier frequency (kHz)	1 ~ 15kHz			
	Maximum output voltage	3 phase 200-240V			
Power Supply	Rated input current (A) *Note 1	6.5	9.3	15.7	24
	Rated input AC voltage/ frequency	single phase 200-240V 50Hz/60Hz			
	Permissible AC voltage fluctuation	single phase 170-264V 50Hz/60Hz			
	Permissible frequency fluctuation	±5%			
	Power supply capacity (kVA)	1.5	2.5	3.5	6.4
Cooling method		Fan cooling			
Weight (kg)		0.6	0.6	0.6	0.8

Note 1: The value indicates the current at rated output. The rated input current value is not only affected by power transformer, input side reactor, wiring condition, but also fluctuates with the impedance of the power supply side.


### 3.2 General specification

Control method		V/F control
Output frequency range		0.00~599.00Hz
Frequency setting resolution	Digital setting	0.01Hz
	Analog setting	Maximum output frequency $\pm$ 0.1%.
Output frequency accuracy	Digital setting	Maximum target frequency $\pm$ 0.01%.
	Analog setting	Maximum target frequency $\pm$ 0.1%.
Starting torque		150% / 5Hz automatic torque boost
V/F characteristics		Constant torque curve, variable torque curve, five-point VF curve
Acceleration / deceleration curve characteristics		Linear acceleration / deceleration curve, S shape acceleration / deceleration curve 1 & 2 & 3
Drive motor		Induction motor (IM)
Stalling protection		The stalling protection level can be set to 0~200%
Target frequency setting		Up down button, VR knob setting, DC 0~5V/10V signal, DC 4~20 mA signal, multi-speed stage level setting, communication setting, PWM pulse setting.
Built-in keypad	Operation monitoring	Output frequency, output current, output voltage, electronic thermal accumulation rate, temperature rising accumulation rate, output power, analog input signal value, digital input and output terminal status...; alarm history 12 sets with operation details of the latest two set
	LED indicator ( 6 )	Frequency monitoring indicator, voltage monitoring indicator, current monitoring indicator, motor running indicator, mode switch indicator, PU mode indicator
Communication function		RS-485 communication, choose between Shihlin/Modbus communication protocol
Protection mechanism / alarm function		Output short circuit protection, over-current protection, over-voltage protection, under-voltage protection, motor over-heat protection, IGBT module over-heat protection, communication error protection, PID error protection, memory error protection, CPU error protection, stall prevention, module over-heat protection, input power fail protection, terminal 3-5 disconnect protection, over torque protection, Current leakage to ground protection, hardware detect circuit error protection
Environment	Ambient temperature	-10 ~ +40°C (non-freezing),
	Ambient humidity	Below 90%Rh (non-condensing).
	Storage temperature	-20 ~ +65°C
	Surrounding environment	Indoor, no corrosive gas, no flammable gas, no flammable powder.
	Altitude	Altitude below 2000 meters, when altitude is above 1,000 m, derate the rated current 2% per 100m
	Vibration	Vibration below 5.9m/s <sup>2</sup> ( 0.6G )
	Grade of protection	IP20
	Over voltage level	II
	Degree of environmental pollution	2
Class of protection	Class I	
International certification		CE



### 3.3 Appearance and dimensions


#### 3.3.1 Frame A



unit : mm

Model	W	W1	H	H1	H2	D	S1
SL3-021-0.4K	68	56	132	120	42.5	104	5 (tighten torque 20~25kgf.cm)
SL3-021-0.75K							
SL3-021-1.5K							

3.3.2 Frame B



unit : mm


Model	W	W1	H	H1	H2	D	S1
SL3-021-2.2K	72	59.5	142	129.5	42.5	110	5 (tighten torque 20~25kgf.cm)
SL3-043-0.4K							
SL3-043-0.75K							
SL3-043-1.5K							
SL3-043-2.2K							

## 3.4 Name of each component

### 3.4.1 Frame A/B

\*1.A Frame : SL3-021-0.4K , SL3-021-0.75K , SL3-021-1.5K

\*2.B Frame : SL3-021-2.2K , SL3-043-0.4K , SL3-043-0.75K , SL3-043-1.5K , SL3-043-2.2K



## 3.5 Installation and wiring

### 3.5.1 Transportation

Hold the body when carrying and don't only hold the cover or any part of the inverter, otherwise it may drop down.

### 3.5.2 Stockpile

The product must be placed in the packaging box before installation. In order to make the product conform to the scope of warranty of the company and facilitate maintenance in the future, please pay attention to the following matters when storing if the inverter will not be used temporarily:

1. Must be placed in dry places without dirt and dust.
2. The environment temperature for storage place must range from -20°C to +65°C.
3. The relative humidity for storage place must range from 0% to 95%, and no condensation.
4. Avoid storing in the environment containing corrosive gas or liquid.
5. It's better to be packed properly and kept on shelf or table.

Note:1. Even if the storing place humidity meets the standard requirements, icing and condensation can also occur if the temperature changes rapidly, thus should be avoided.


2. Don't place it on the ground, it should be placed on a shelf. If the environment is bad, put desiccant in the packaging bag.
3. If the storage period is more than 3 months, the storing temperature should not be higher than 30°C. Considering that capacitors will easily degrade in high temperature without being powered on.
4. If the inverter is installed in a machine or control panel when not in use (especially in construction site or humid and dusty places), the inverter should be removed and put in suitable environment according to the above storage conditions.
5. If the inverter isn't power on for a long time, the capacitors will degrade. Do not place it for more than one year without being powered on.

### 3.5.3 Installation notice


✓ Before installing, please confirm whether meet the conditions listed in the table below:

Ambient temperature	-10 ~ +40°C (non-freezing)
Ambient humidity	Below 90%Rh (non-condensing).
Storage temperature	-20 ~ +65°C
Surrounding environment	Indoor, no corrosive gas, no flammable gas, no flammable powder.
Altitude	Altitude below 2000 meters, when altitude is above 1,000 m, derate the rated current 2% per 100 m
Vibration	Vibration below 5.9m/s <sup>2</sup> (0.6G).
Grade of protection	IP20
The degree of environmental pollution	2


✓ Please install the inverter vertically in order not to reduce the heat dissipation effect:



(a) Vertical installation






(b) Horizontal installation



(c) Transverse installation

✓ Please follow the installation restrictions shown below to ensure enough ventilation space for inverter cooling and wiring space:


- Arrangement of single or paralleling inverter :



unit : mm

Size	Frame A	Frame B
A	50	50
B	50	50
C	100	100
D	50	50
E	50	50
F	Ventilation direction	


- Arrangement of multiple inverters:



(a) Horizontal arrangement (b) Vertical arrangement

Note: 1. When it is inevitable to arrange inverters vertically to minimize space, install guides since heat from the bottom inverters can increase the temperature on the top inverters, causing inverter failures.

- Din rail installation :



(a) DIN rail mounting (b) DIN rail remove

### 3.5.4 EMC installation instructions

Just as other electrical and electronic equipment, an inverter is the source of electromagnetic interference and an electromagnetic receiver when working with a power system. The amount of electromagnetic interference and noise is determined by the working principles of an inverter. In order to guarantee the inverter working reliably in the electromagnetic environment, it must have a certain ability of anti-electromagnetic interference in design. In order to make the drive system work normally, please meet the following several aspects requirements in installation:

✓ Field wiring

Power line supply electric independently from power transformer, five or four core line are generally used, null line and ground sharing a single line is forbidden.

Commonly signal wire (weak) and power wire (heavy) are in control cabinet, for the inverter, power wire is divided into input line and output line. Signal wire is easily interfered by power wire, so that causing the misoperation of the device. When wiring, signal wire and power wire should be distributed in different areas, parallel lines and interlaced lines are forbidden at close range(within 20cm), and especially don't bundle up the two lines. If the signal cables must pass via the power lines, the two should keep 90 degree angle. Interlace lines and banding together is also forbidden for the input and output line of power wire, especially on the occasions which noise filter is installed. It will cause the coupling of electromagnetic noise via the distributed capacitance of the input and output lines, thus the noise filter will out of action.

Generally a control cabinet has different electric equipment such as inverter, filter, PLC, measurement instrument, their ability of emitting and bearing electromagnetic noise are diverse from each other, and this requires classifying these equipment. The classification can be divided into strong noise equipment and noise sensitive equipment, Install the similar equipment in the same area and, and keep a distance more than 20cm among inhomogeneous equipments.

✓ Input noise filter, input and output magnet ring (Zero phase reactor)

Adding noise filter to the input terminal, the inverter will be isolated from the other equipment, and its ability of conduction and radiation will be reduced effectively. By adding winding ferrite bead to the input and output terminal and coordinating with internal filter, the inverters will have a better effect.

✓ Shielding

Good shielding and grounding can greatly reduce the interference of inverter, and can improve the anti-interference ability of the inverter. Sealing off the inverter with the good conductive sheet metal and connecting the sheet metal to ground, the radiation interference will be reduced effectively. To reduce the interference of inverter and improve the anti-interference ability, cable with shielding layer should be used in input and output and the both ends of it should be connected to ground. Shielding cable is suggested to be used in control connecting and communication connecting of the inverter external terminals under bad electromagnetic environment. Generally, the both ends of shielding layer should be connected to the control /communication ground, and they can also be connected to ground.

✓ Grounding


The inverter must be connected to the ground safely and reliably. Grounding is not only for equipment and personal safety, but also the simplest, the most efficient and the lowest cost method to solving the EMC problem, so it should be prioritized. Please refer to the section of "3.7 Terminal wiring".

✓ Carrier wave

The leakage current contains the leakage current from line to line or over the ground. It depends on the size of the distributed capacitance when wiring and the carrier frequency of the frequency. The higher the carrier frequency, the longer the motor cable, and the larger the cable cross-sectional area is, the larger the leakage current is. Reducing the carrier frequency can effectively reduce the leakage current. When the motor line is long (50m above), the output side should be installed with ac reactor or sine wave filter, when the motor line is longer, a reactor should be installed every other distance. At the same time, reducing carrier frequency can effectively reduce the conduction and radiation interference.

### 3.6 Peripheral devices

#### 3.6.1 System Wire Arrangement




Power	Please provide power specified in manual.
Molded case circuit breaker (MCCB) or earth leakage current breaker (ELB)	When power ON there might be huge inrush current flows to inverter. Refer to chapter 3.6.2 for model selection.
Magnetic contactor (MC)	Do not use contactor to power on/off inverter. Doing so will shorten the life span of the inverter.
AC reactor(input side)	It is recommend to install AC reactor to improve the power factor. The wire distance should be within 10 meters
Zero-phase reactor	Zero-phase reactors are used to reduce radio noise especially when audio equipment is installed near the inverter. Effective for noise reduction on both the input and output sides. The frequency band effective range is from AM to 10 MHz
EMI filter	Used to reduce electromagnetic interference
Output AC Line Reactor	Motor surge voltage amplitude depends on motor cable length. Recommend to install.



## 3.6.2 No-fuse breaker and magnetic contactor

Inverter model	Motor capacity	Power source capacity	Applicable no-fuse switch (NFB/MCCB) type (Shihlin Electric)	Applicable electromagnetic contactor (MC) type (Shihlin Electric)
SL3-043-0.4K	440V 0.5HP	1.5kVA	BM30SN3P3A	S-P11
SL3-043-0.75K	440V 1HP	2.5kVA	BM30SN3P5A	S-P11
SL3-043-1.5K	440V 2HP	4.5kVA	BM30SN3P10A	S-P11
SL3-043-2.2K	440V 3HP	6.9kVA	BM30SN3P15A	S-P21
SL3-021-0.4K	220V 0.5HP	1.5kVA	BM30SN3P5A	S-P11
SL3-021-0.75K	220V 1HP	2.5kVA	BM30SN3P10A	S-P11
SL3-021-1.5K	220V 2HP	3.5kVA	BM30SN3P15A	S-P11
SL3-021-2.2K	220V 3HP	6.4kVA	BM30SN3P20A	S-P11/ S-P12

### 3.7 Terminal wire arrangement




Note :

- 1.All series includes built-in RFI filters, in order to comply with CE regulations, please refer to section 3.5.4.
- 2.When exterior keypad is connect to RJ45 port, RS485 by DA+/DB- will not work;
- 3.When switching terminal 3-5 voltage/ current input, please check the ACI/AVI switch position, and check parameter 02-20 ( P.17 ) setting.



### 3.7.1 Main circuit Terminals

#### ✓ Description



Main circuit terminals description	
R/L1-S/L2-T/L3	Connect to commercial power supply
U/T1-V/T2-W/T3	Connect to three-phase induction motor.
	Connect to ground

#### ✓ Terminal layout of the main circuit terminals

- 1. SL3-021-0.4K , SL3-021-0.75K , SL3-021-1.5K , SL3-021-2.2K




- 2. SL3-043-0.4K , SL3-043-0.75K , SL3-043-1.5K , SL3-043-2.2K



### 3.7.2 Main circuit wiring and terminal specification

Inverter model	Terminal screw specifications	Tightening torque (Kgf.cm)	Recommended wiring specification (mm <sup>2</sup> )			Recommended wiring specification (AWG)		
			R, S, T	U, V, W	Grounding Cable	R, S, T	U, V, W	Grounding Cable
SL3-021-0.4K	M2.5	2.5-3.5	2.5	2.5	2.5	14	14	14
SL3-021-0.75K			2.5	2.5	2.5	14	14	14
SL3-021-1.5K			2.5	2.5	2.5	14	14	14
SL3-021-2.2K	M3	4-6	4	4	4	12	12	12
SL3-043-0.4K			1.5	1.5	1.5	16	16	16
SL3-043-0.75K			2.5	2.5	2.5	14	14	14
SL3-043-1.5K			2.5	2.5	2.5	14	14	14
SL3-043-2.2K			2.5	2.5	2.5	14	14	14


- Note: 1. Do not connect power wire to motor terminals (U/T1)(V/T2)(W/T3) on inverter, otherwise it will cause damage.  
 2. Do not add phase capacitor, surge absorber or magnetic contactor on the output side of the inverter.



- Do not use "magnetic contactor" or "no fuse switch" to start and stop the motor.
- Please do grounding for the inverter and motor to avoid electric shock.
- For specifications of no-fuse breaker and magnetic contactor, please refer to section 3.6.2.
- If the distance between the inverter and motor is long, please use thick wires, make sure wire voltage drop is under 2V (wire length below 500 meters).
- Use "insulation crimp sleeve " for power supply side and load side connection.

### 3.7.3 Ground

For safety and to reduce noise, the grounding  $\oplus$  of the inverter must be well grounded. To avoid electric shocks and fire accident, the external metal ground wire of the equipment should be short and thick, and should be connected to specific grounding terminals on the inverter. If several inverters are placed together, all inverters must be connected to the common ground. Please refer to the following diagrams and ensure that no loop is formed between grounding terminals.



### 3.7.4 RFI filter


SL3 series inverters are equipped with built-in RFI filters. These filters are effective in reducing electromagnetic interference, but to meet CE standard, please refer to section 3.5.4 for installation and wiring.

## 3.7.5 Control circuit

## ✓ Control terminal name

Terminal type	Terminal name	Function instructions	Terminal specifications
Digital signal input	STF	These are multi-function control terminals, a total of 4.	Input impedance: 2.4 kΩ Action current : 3 mA (when 24 VDC) Maximum frequency: 1kHz
	STR		
	M0		
	M1		
Analog signal input	10	+10.5±0.5V	Maximum current:10mA
	3	0~10V/4~20mA	Input impedance:10kΩ ( 0-10V ) or 235Ω ( 4-20mA )
Relay output	A	Multi-function relay output terminals. A-C is normal open contact, C is common terminal.	Maximum voltage : 30 VDC or 250 VAC Maximum current: Resistor load 5A NO Inductance load 2A NO ( cosΦ=0.4 )
	C		
Communication terminal	RJ45	RS-485、 optical coupling isolation.	Highest rate:38400bps Longest distance:500m
	DA+		
	DB-		
Common terminal	SD/5	COM terminal for STF、 STR、 M0、 M1、 10、 3.	---

## ✓ Arrangement of control terminal




## ● Wires connection

For the control circuit wiring, strip off the sheath of a cable, and use it with a blade terminal. For a single wire, strip off the sheath of the wire and apply directly.

Please insert a blade terminal or a single wire into the terminal for wiring.

(1) Strip off the sheath for the below length. If the length of the sheath peeled is too long, a short circuit may occur with neighboring wires. If the length is too short, wires might come off.

Wires should be well connected to avoid messiness. In addition, don't need to solder it.




## Terminal wire arrangement

(2) Insert the wire to blade terminal and crimping.


Insert wires to a blade terminal, and check that the wires come out for about 0 to 0.5 mm from a sleeve.

Check the condition of the blade terminal after crimping. Do not use a blade terminal of which the crimping is inappropriate, or the face is damaged.



● Please do use blade terminals with insulation sleeve. Blade terminals commercially available:


Cable gauge (mm <sup>2</sup> )	Blade terminals model	L (mm)	d1 (mm)	d2 (mm)	Manufacturer	Crimping tool product number
0.3	AI 0,25-6 WH	10.5	0.8	2	Phoenix Contact Co., Ltd.	CRIMPFOX 6
0.5	AI 0,5-6 WH	12	1.1	2.5		
0.75	AI 0,75-6 GY	12	1.3	2.8		
0.75 (for two wires)	AI-TWIN 2×0,75-6 GY	12	1.3	2.8		



Note:1. Please Use a small flathead screwdriver (tip thickness: 0.6mm, width: 3.0mm). If a flathead screwdriver with a narrow tip is used, terminal block maybe damaged.

2. Tightening torque is 20~25kgf.cm too large tightening torque can cause screw slippage, too little tightening torque can cause a short circuit or malfunction.

✓ Toggle switch



Switch number	Switch state	Explanation	Remarks
AVI/ACI	*	Input 4~20mA current signal into terminal 3	Also requires setting 02-20 ( P.17 ), refer to chapter 5.3.3
		Input 0~10V voltage signal into terminal 3	


Note: 1. The state with “ \* ” mark is the default state.

### 3.8 Replacement procedure of fan

If the fan is broken, please send the unit back to our factory to repair.

## 4. BASIC OPERATION

### 4.1 Component name of keypad






NO.	Operation parts	Name	Content
(a)	PU —	Operation mode indicator	PU: On when in PU/JOG operation mode, flickers in H1~H5 operation mode.
(b)	MON —	Keypad status indicator	MON : On to indicate keypad is in monitoring mode
(c)	RUN —	RUN indicator	Flickers when running.
(d)	Hz A V — — —	Unit for the monitoring value	Hz: On when monitoring frequency. A: On when monitoring output current. V: On when monitoring optional values (output voltage by default). Can be set by 00-07 ( P.161 ) to monitor different values.
(e)		MODE/RESET button	Switch the display screen ( Switches to different operation modes ) Long press to reset the inverter when alarm.
(f)		RUN/STOP button	When inverter is in stop state this button gives run command. When inverter is in run state this button gives stop command.
(g)		UP/DOWN button	Increase/Decrease frequency, parameter number, parameter value, etc.
(h)		SET button	Long press this key to write parameter values, frequency, etc.
			Short press this key to read the parameter value. Enter the next menu.
(i)		VR knob	Set target frequency
(j)		Monitor (5-digit LED)	Shows the frequency, parameter number, and parameter value, etc.




## 4.2 Operation modes of inverter

- Operation modes are related to signal source for the target frequency and signal source for motor starting. In Shihlin SL3 inverter there are nine kinds of operation modes: "PU mode(*PU*)", "JOG mode(*JOG*)", "External mode(*Ext*)", "Communication mode (*CU*)", " Combined mode 1 (*H1*)", " Combined mode 2(*H2*)", " Combined mode 3(*H3*)", " Combined mode 4(*H4*)", " Combined mode 5(*H5*)".
- You can use the built-in keypad to monitor output frequency, monitor output voltage, monitor output current, browse alarm messages, parameter settings, and frequency settings. There are 6 working modes in the built-in keypad: "Operation Mode", "Monitoring Mode", "Running Direction Setting Mode", "Frequency Setting Mode", "Parameter Setting Mode", and "HELP Mode".

Related parameters	Value	Operation mode	Signal source for target frequency	Signal source for motor starting	Remarks	
Operation mode selection 00-16(P.79)	0	PU mode ( <i>PU</i> )	Built-in keypad	 button on built-in keypad	"PU mode", "JOG mode" and "external mode" are interchangeable.	
		JOG mode ( <i>JOG</i> )	Value set in parameter 01-13(P.15)	 button on built-in keypad		
		External mode ( <i>Ext</i> )	"External voltage/current signal", "multi-speed terminal" and external JOG signal (01-13(P.15)) Frequency of each section in the programmed operation mode 04-19~04-26 /P.131~P.138	External STF/STR terminals External STF terminal		
	1	PU mode ( <i>PU</i> )	Equals to "PU mode" when 00-16(P.79) = 0			"PU mode" and "JOG mode" are interchangeable.
		JOG mode ( <i>JOG</i> )	Equals to "JOG mode" when 00-16(P.79) = 0			
	2	External mode ( <i>Ext</i> )	Equals to "External mode" when 00-16(P.79) = 0			
	3	Communication mode ( <i>CU</i> )	Communication	Communication		
	4	Combined mode 1 ( <i>H1</i> )	Built-in keypad	External STF/STR terminals		
	5	Combined mode 2 ( <i>H2</i> )	External voltage / current signal, multi-speed terminal	 button on built-in keypad		
	6	Combined mode 3 ( <i>H3</i> )	Communication, multi-speed terminal and external JOG (01-13(P.15))	External STF/STR terminals		
7	Combined mode 4 ( <i>H4</i> )	External voltage / current signal, multi-speed terminal	Communication			
8	Combined mode 5 ( <i>H5</i> )	Built-in keypad, multi-speed terminal and external JOG (01-13(P.15))	External STF/STR terminals			


- When 00-16(P.79) = 0, the external mode (*Ext*) is the default mode after inverter is turned on. Use 00-16(P.79) to switch the operation mode.

4.2.1 Flow chart for switching operation mode



- Note: 1. In "PU mode", keypad screen displays *PU* and the indicator in *PU* will light up.  
 2. In "External mode", keypad screen displays *OPnd*.  
 3. In "Combined mode 1, 2, 3, 4, or 5", the indicator in *PU* will flicker.  
 4. In "JOG mode", the indicator in *PU* will light up, and show *u00* when motor is not running.  
 5. No flow chart when 00-16(P.79) is set to =2, 3, 4, 5, 6, 7 or 8 since the operation mode will not switch


4.2.2 Flow chart for switching built-in keypad working mode



- Note: 1. Please refer to section 4.2.3 for detailed operation steps under monitoring mode.  
 2. Please refer to section 4.2.4 for detailed operation steps under frequency setting mode.  
 3. Please refer to section 4.2.5 for detailed operation steps under parameter setting mode.  
 4. Please refer to Section 4.2.1 for detailed operation steps under switching operation mode.  
 5. Please refer to Section 4.2.6 for detailed operation steps under HELP mode.  
 6. Please refer to Section 4.2.7 for detailed operation steps for changing motor rotation direction.


### 4.2.3 Operation flow chart for monitoring mode

- Take External mode as an example :




- Note: 1. In “monitoring output frequency” mode, indicator in **MON** and **Hz** will light up, and the screen will display current output frequency.
2. In “monitoring optional value” mode, indicator in **MON** and **V** will light up, and the screen will display current optional value. The optional value is chosen by parameter 00-07(P.161), the default setting is monitor output voltage.
3. In “monitoring output current” mode, indicator in **MON** and **A** will light up, and the screen will display current output current.
4. When in “browsing alarm record” mode, indicator in **MON** will light up, and the screen will display current alarm code.
5. For alarm codes, please refer to Appendix 2.

### 4.2.4 Operation flow chart for frequency setting




- Note: 1. When inverter is running, use ▲/▼ key on built-in keypad to change the target frequency setting.  
 2. Under frequency setting mode, indicator in **Hz** and **MON** will not light up.  
 3. When setting frequency with keypad, the set value cannot exceed the upper frequency. When high frequency is needed, the upper frequency should be changed first.

### 4.2.5 Operation flow chart for parameter setting




- Note: Indicator in **Hz** and **MON** will NOT light up under parameter setting mode. Be sure to hold SET key and keep it above 0.5s.

4.2.6 Operation flow chart for HELP mode



Note: 1. When browsing alarm record, the screen will display 4 most recent alarm code.  
 2. For alarm codes, please refer to Appendix 2.



4.2.7 Operation flow chart for changing motor rotation direction





Note: 1. The operation mode is valid when signal source for motor starting comes from keypad.

## 4.3 Basic operation steps for different modes



### 4.3.1 Basic operation steps for PU mode (00-16(P.79) = 0 or 1)

Step	Description
1	<ul style="list-style-type: none"> <li>Switch operation mode to PU mode, and indicator in <b>PU</b> will light up.</li> </ul> <p>Note: 1. When 00-16(P.79) =0, the inverter will first be in external mode after power on or reset. 2. For selecting and switching operation mode, please refer to section 4.2.</p>
2	<ul style="list-style-type: none"> <li>Enter frequency setting mode and write target frequency into memory.</li> </ul> <p>Note: For detailed setting procedures, please refer to section 4.2.4.</p>
3	<ul style="list-style-type: none"> <li>Press  to run the motor. At this point, indicator <b>RUN</b> will flicker to indicate that the motor is running. The keypad will automatically switch to monitor mode and display the current output frequency.</li> </ul> <p>Note: 1. For detailed operation steps for monitoring mode, please refer to section 4.2.3. 2. While the motor is running, the user can enter frequency setting mode to change target frequency for regulating the motor speed.</p>
4	<ul style="list-style-type: none"> <li>Press  and the motor will begin to decelerate until it comes to a full stop.</li> <li>Indicator in <b>RUN</b> will not turn off until the inverter stops outputting voltage</li> </ul>

### 4.3.2 Basic operation steps for external mode (00-16(P.79) = 0 or 2)

Step	Description
1	<ul style="list-style-type: none"> <li>Switch operation mode to External mode, screen will display <i>OPnd</i></li> </ul> <p>Note: 1. When 00-16(P.79) =0, after power on or reset, press  to switch to operation mode, inverter will first switch to external mode, then use  to switch to PU mode; 2. When 00-16(P.79) =2, inverter will always be in external mode ; 3. For selecting and switching operation mode, please refer to section 4.2.</p>
2	<ul style="list-style-type: none"> <li>Target frequency is set by external terminals (default priority from high to low):</li> <li>If program operating mode is chosen, please refer to section 5.4.1 function selection of digital input and 5.5.2 programmed operation mode.</li> <li>If target frequency is set by multi-speed stage levels, please refer to section 5.5.1 16 step speed.</li> <li>If target frequency is set by input signal across terminal 3-5, please refer to section 5.3.3 terminal 3-5 signal selection and processing .</li> </ul>
3	<ul style="list-style-type: none"> <li>Turn on STF or STR to run the motor.</li> <li>At this point, indicator in <b>RUN</b> will flicker, indicating that the motor is running.</li> </ul> <p>Note: 1. For setting up the starting terminals STF and STR, please refer to 00-15(P.78) in section 5.1.8 and 5.4.1 function selection of digital input. 2. For detailed operation steps for the monitor mode, please refer to section 4.2.3. 3. If programmed operation mode is chosen, then STF and STR will become the starting signal and the pause signal, instead of being forward or reverse terminals.</p>
4	<ul style="list-style-type: none"> <li>Turn off STF or STR to decelerate the motor until it comes to a full stop.</li> <li>Indicator in <b>RUN</b> will not turn off until the inverter stops outputting voltage.</li> </ul>

### 4.3.3 Basic operation steps for JOG mode (00-16(P.79) = 0 or 1)

Step	Description
1	<ul style="list-style-type: none"> <li>Switch operation mode to JOG mode and indicator in <b>PU</b> will light up, the display shows <b>u f</b>.</li> </ul> <p>Note: 1. For detailed operating procedures for the monitor mode, please refer to section 4.2.</p>
2	<ul style="list-style-type: none"> <li>Press  to run the motor. At this point, indicator in <b>RUN</b> will flicker, indicating that the motor is running.</li> <li>Release  to decelerate the motor until it comes to a full stop. Indicator in <b>RUN</b> will not turn off until the inverter stops the output.</li> </ul> <p>Note: 1. For detailed operating procedures for monitor mode, please refer to section 4.2.3. 2. In JOG mode, target frequency is the value of 01-13(P.15), and the acceleration / deceleration time is the value of 01-14(P.16). Please refer to section 5.2.7 JOG operation.</p>



### 4.3.4 Basic operation steps for communication mode (00-16(P.79) = 3)

- ◆ In communication mode, user can set parameters and run/stop or reset inverters by communication. Please refer to Communication function related parameters for details.

### 4.3.5 Basic operation steps for combined mode 1 (00-16(P.79) = 4)

Step	Description
1	<ul style="list-style-type: none"> <li>In Combined Mode 1, indicator <b>PU</b> will light up.</li> </ul> <p>Note: 1. For detailed operation procedures for monitor mode, please refer to section 4.2.</p>
2	<ul style="list-style-type: none"> <li>Enter frequency setting mode and write target frequency into memory.</li> </ul> <p>Note: For setting details, please refer to section 4.2.4.</p>
3	<ul style="list-style-type: none"> <li>Set target frequency by built-in keypad and start the inverter by terminal STF/STR .</li> <li>At this point, indicator in <b>RUN</b> will flicker, indicating that the motor is running.</li> </ul> <p>Note: For detailed operation procedures for monitor mode, please refer to section 4.2.3.</p>
4	<ul style="list-style-type: none"> <li>When terminal STF/STR signals turn off, motor will decelerate until it comes to a full stop.</li> <li>Indicator in <b>RUN</b> will not turn off until the inverter stops outputting.</li> </ul>

### 4.3.6 Basic operation steps for combined mode 2 (00-16(P.79) = 5)

Step	Description
1	<ul style="list-style-type: none"> <li>In Combined Mode 2, indicating lamp <b>PU</b> will light up.</li> </ul> <p>Note: For selecting and switching the operation mode, please refer to Section 4.2.</p>
2	<ul style="list-style-type: none"> <li>Target frequency is set by external terminals (default priority from high to low):</li> <li>If the programmable operating mode is chosen, please refer to section 5.4.1 function selection of digital input and 5.5.2 programmed operation mode.</li> <li>If target frequency is set by multi-speed stage levels, please refer to section 5.5.1 16 step speed.</li> <li>If target frequency is set by input signal across terminal 3-5, please refer to section 5.3.3 terminal 3-5 signal selection and processing .</li> </ul>
3	<ul style="list-style-type: none"> <li>Press  to run the motor. At this point, indicator <b>RUN</b> will flicker to indicate that the motor is running.</li> </ul> <p>Note: 1. For detailed operation steps for monitoring mode, please refer to section 4.2.3. 2. While the motor is running, the user can enter frequency setting mode to change target frequency for regulating the motor speed.</p>
4	<ul style="list-style-type: none"> <li>Press  and the motor will begin to decelerate until it comes to a full stop.</li> <li>Indicator in <b>RUN</b> will not turn off until the inverter stops outputting voltage.</li> </ul>



## 4.3.7 Basic operation steps for combined mode 3(00-16(P.79) = 6)

Step	Description
1	<ul style="list-style-type: none"> <li>In Combined Mode 3, indicator in <b>PU</b> will flicker.</li> </ul> <p>Note: 1. For detailed operation procedures for monitor mode, please refer to section 4.2.</p>
2	<p>Default priority from high to low :</p> <ul style="list-style-type: none"> <li>When external JOG is "on", target frequency is determined by 01-13(P.15). Acceleration / deceleration time is set by the value of 01-14(P.16).</li> <li>When RL, RM, RH and REX of multi-speed stage levels are "on", target frequency is determined by combination of multi-speed stage levels, please refer to section 5.5.1 16 step speed.</li> <li>Target frequency is set by communication.</li> </ul>
3	<ul style="list-style-type: none"> <li>Give STF/STR signal to run the motor. At this point, indicator <b>RUN</b> will flicker to indicate that the motor is running.</li> <li>Functions of 00-02(P.996~P.999) can be accomplished by communication.</li> </ul> <p>Note: For detailed operation procedures for the monitor mode, please refer to Section 4.2.3.</p>
4	<ul style="list-style-type: none"> <li>When terminal STF/STR signals turn off, motor will decelerate until it comes to a full stop.</li> <li>Indicator in <b>RUN</b> will not turn off until the inverter stops outputting.</li> </ul>

## 4.3.8 Basic operation steps for combined mode 4(00-16(P.79) = 7)

Step	Description
1	<ul style="list-style-type: none"> <li>In Combined Mode 4, indicator in <b>PU</b> will flicker.</li> </ul> <p>Note: 1. For detailed operation procedures for monitor mode, please refer to Section 4.2.</p>
2	<p>Default priority from high to low :</p> <ul style="list-style-type: none"> <li>If target frequency is set by multi-speed stage levels, please refer to section 5.5.1 16 step speed.</li> <li>If target frequency is set by input signal across terminal 3-5, please refer to section 5.3.3 terminal 3-5 signal selection and processing .</li> </ul>
3	<ul style="list-style-type: none"> <li>The inverter starting is activated by communication (including "Reset"). At this point, indicator <b>RUN</b> will flicker indicating that the motor is running.</li> </ul> <p>Note: 1. For detailed operation procedures for the monitoring mode, please refer to Section 4.2.3.</p> <p>2. While the motor is running, the user can enter into the frequency setting mode to change the target frequency for regulating the motor speed.</p>
4	<ul style="list-style-type: none"> <li>When communication sends the stop instruction, the motor will decelerate until it comes to a full stop.</li> <li>Indicator <b>RUN</b> will not turn off until the inverter stops the output.</li> </ul>

## 4.3.9 Basic operation steps for combined mode 5(00-16(P.79) = 8)

Step	Description
1	<ul style="list-style-type: none"> <li>In Combined Mode 5, indicator <b>PU</b> will light up.</li> </ul> <p>Note: For detailed operating procedures for monitor mode, please refer to Section 4.2.</p>
2	<ul style="list-style-type: none"> <li>Target frequency of the inverter is set by keypad:</li> <li>When RL, RM, RH and REX for multi-speed stage levels are "on", target frequency is determined by the combination of multi-speed stage levels , please refer to section 5.5.1 16 step speed.</li> <li>When external JOG is "on", target frequency is determined by 01-13(P.15). Acceleration / deceleration time is set by the value in 01-14(P.16).</li> </ul>
3	<ul style="list-style-type: none"> <li>Inverter starting is triggered by external STF or STR terminals.</li> </ul> <p>Note: 1. For detailed operation procedures for the monitoring mode, please refer to section 4.2.3.</p> <p>2. While the motor is running, the user can enter frequency setting mode to change the target frequency for regulating motor speed.</p>
4	<ul style="list-style-type: none"> <li>When terminal STF/STR signals turn off, motor will decelerate until it comes to a full stop.</li> <li>Indicator in <b>RUN</b> will not turn off until the inverter stops outputting.</li> </ul>

## 4.4 Operation





### 4.4.1 Check and preparation before running

Before running, the following shall be checked:

1. Check if the wiring is correct. Inverter output terminals (U/T1, V/T2, W/T3) cannot be connected to the power.  
Confirm that grounding terminal (⊕) is well grounded.
2. Confirm that there is no short circuit or short circuit to ground between the terminals or each exposed live part.
3. Confirm all terminal connections, and check if plug connectors (optional) and screws are all fastened.
4. Confirm that the motor is not connected to any load or mechanism.
5. All external switches are in off state before the power is turned on. When the power is turned on, the inverter will not start and no abnormal action will occur.
6. Turn on the power only after the cover is well placed.
7. Do not touch the switch with wet hands.
8. Make sure the following after power on:  
No alarm on built-in keypad, both indicator in **Hz** and **MON** will light up.

### 4.4.2 Running methods

For every running method, please refer to basic operation procedures in chapter 4 and parameter description in chapter 5. Select the most appropriate operation methods according to the application requirements and regulations. The most commonly used operation methods are shown below:

Operation method	Source of the target frequency	Source of the operating signal
Built-in keypad operation		
External terminal signal operation	 <p style="margin-left: 100px;">Parameter setting: 04-01(P.5)=30 04-02(P.6)=10</p>	Input by digital input terminal: STF-SD STR-SD
	 <p style="margin-left: 100px;">terminal 3-5 input</p>	

### 4.4.3 Test run

- Check cables and abnormalities before the test run. After power on, the inverter is in external mode.
1. After power on, make sure no alarm on built-in keypad, make sure indicator **Hz** and **MON** is on.
  2. Connect a switch between STF/SD and STR/SD.
  3. Connect a potentiometer between 3-5-10 or provide 0~5V dc between 3 and 5.
  4. Adjust potentiometer or 0~5V dc to a minimum value (under 1V).
  5. If STF is on, forward rotation is activated. If STR is on, reverse rotation is activated. Turn off STF or STR to decelerate the motor until it stops completely.
  6. Check the following:
    - 1). Whether the direction of motor rotation is correct.
    - 2). Whether the rotation is smooth (check for noise and vibration).
    - 3). Whether the acceleration / deceleration is smooth.
- If there is an optional keypad, do the following:
1. Make sure the keypad is connected to the inverter properly.
  2. Change the operation mode to PU mode after power on, check the target frequency is 50/60Hz.
  3. Use the optional keypad to set the target frequency at about 5Hz.
  4. Press **FWD** for forward rotation and **REV** for reverse rotation. Press **STOP RESET** to decelerate the motor until it stops completely.
  5. Check the following:
    - 1) Whether the direction of motor rotation is correct.
    - 2) Whether the rotation is smooth (check for noise and vibration).
    - 3) Whether the acceleration / deceleration is smooth.
- If it runs successfully, continue the test run by increasing the frequency and go through the above procedure. After confirming that there are no abnormalities, it can be put into operation.

Note: If the operation of the inverter and motor is abnormal, stop the operation immediately and check the cause of the abnormality according to "Troubleshooting". After the inverter stops outputting, if the main circuit power terminals R/L1, S/L2, T/L3 are not disconnected, if the inverter's output terminals U/T1, V/T2, W/T3 are touched, it may cause an electric shock. In addition, even if the main circuit power supply is turned off, due to the charging voltage on the filter capacitor, it will take a certain time for the discharge to end. After the main circuit power supply is cut off, wait for 10 minutes and test the intermediate DC circuit voltage with a voltmeter to confirm that it is below the safe voltage value before you can touch the internal circuit of the inverter.

## 5. PARAMETER DESCRIPTION

### 5.1 System parameter group 00

Group	Parameter Number	Name	Setting Range	Default	Page
00-00	P.90	Inverter model	Read only	---	45
00-01	P.188	Firmware version	Read only	---	45
00-02	P.996 ~ P.999	Parameter restoration	0: Off	0	46
			1: Clear alarm history (P.996=1)		
			2: Reset inverter (P.997=1)		
			3: Restore all parameters to default (P.998=1)		
			4: Restore some parameters to default 1 (P.999=1)		
			5: Restore some parameters to default 2 (P.999=2)		
00-03	P.77	Selection of parameters write protection	0: Parameters can be written only when the motor stops.	0	48
			1: Parameters cannot be written.		
			2: Parameters can also be written when the motor is running.		
			3: Parameters cannot be read when in password protection.		
00-04	P.294	Password parameter	0~65535	0	48
00-05	P.295	Password setup	2~65535	0	48
00-06	P.110	Built-in keypad monitor selection	0 : When inverter starts, built-in keypad enters monitor mode automatically, screen displays output frequency (with slip compensation ).	2	50
			1 : When inverter starts, built-in keypad displays target frequency.		
			2 : When inverter starts, built-in keypad enters monitor mode automatically, screen displays steady state output frequency		
			3 : When inverter starts, built-in keypad enters monitor mode automatically, screen displays current pressure and feedback pressure of the constant pressure system in percentage		
			4 : When inverter starts, built-in keypad doesn't enter monitor mode but enter the previous mode before power off		
			5 : When inverter starts, built-in keypad enters monitor mode automatically, screen displays current pressure and feedback pressure of the constant pressure system		
00-07	P.161	Multi-function display	0: Output AC voltage (V)	0	50
			1: DC bus voltage. (V)		
			2: Inverter temperature rising accumulation rate (%)		
			3: Target pressure of the constant pressure system (%)		
			4: Feedback pressure of the constant pressure system (%)		
			5: Running frequency (Hz)		
			6: Electronic thermal accumulation rate (%)		
7 : Reserved					

Group	Parameter Number	Name	Setting Range	Default	Page
00-07	P.161	Multi-function display	8: Signal value (mA) of 3-5 input terminals (mA/V).	0	50
			9: Output power (kW).		
			10 : Reserved		
			11: Forward reverse rotation signal. 1: forward rotation 2: reverse rotation 0: stop.		
			12: NTC temperature (°C)		
			13 : Motor electronic thermal accumulation rate (%)		
			14~18 : Reserved		
			19: Digital terminal input state		
			20: Digital terminal output state		
			21: Actual working carrier frequency		
00-08	P.37	Speed display	0 : Display output frequency(not mechanical speed)	0.0	52
			0.1~5000.0		
			1~50000		
00-09	P.259	Speed display unit selection	0: Speed display unit is 1	1	52
			1: Speed display unit is 0.1		
00-10	P.59	Built-in keypad set target frequency selection	XXX0: Use up down button on built-in or external keypad to set frequency	0	53
			XXX1: Use keypad knob on external keypad to set frequency		
			XXX2 : Use keypad knob on built-in keypad to set frequency		
			X0XX: Every frequency change will save after 30s		
			X1XX: Every frequency change will save after 10s		
			X2XX: Every frequency change will not save		
			0XXX: Set frequency will work immediately when use up down button on built-in keypad		
			1XXX: Set frequency will work after pressing SET when use up down button on built-in keypad		
00-11	P.72	Carrier frequency	1~15 kHz	5 kHz	54
00-12	P.31	Soft-PWM carrier function selection	0: Off	0	54
			1: When 00-11(P.72)<5,Soft-PWM is on(only apply to V/F control)		
			2 : When 00-11(P.72) > 9, if the IGBT temperature is high, carrier frequency will decrease automatically, when temperature go back to normal, carrier frequency go back to 00-11(P.72) value		
00-13	P.71	Idling brake / DC brake	0: Idling brake	1	55
			1: DC brake		
00-14	P.75	Stop function selection	0: Press STOP button and inverter stop running in PU and H2 mode	1	55
			1: Press STOP button and inverter stop running in all mode.		

System parameter group 00


Group	Parameter Number	Name	Setting Range	Default	Page
00-15	P.78	Prevent forward/reverse rotation selection	0: Forward/reverse rotation are both permitted.	0	56
			1: Prevent reverse rotation (Giving reverse signal decelerates and stops the motor).		
			2: Prevent forward rotation (Giving forward signal decelerates and stops the motor).		
00-16	P.79	Operation mode selection	0: "PU mode", "external mode" and "Jog mode" are interchangeable.	0	56
			1: "PU mode" and "JOG mode" are interchangeable.		
			2: "External mode" only		
			3: "Communication mode" only		
			4: "Combined mode 1"		
			5: "Combined mode 2"		
			6: "Combined mode 3"		
			7: "Combined mode 4"		
8: "Combined mode 5"					
00-17	P.97	Second target frequency selection	0: Frequency set by built-in keypad	0	56
			1: Frequency set by RS485 communication		
			2: Frequency set by analog input		
00-19	P.35	Communication mode selection	0: In communication mode, run signal and frequency is given by communication.	0	56
			1: In communication mode, run signal and frequency is given by external signal.		
00-21	P.300	Motor control mode selection	0: Induction motor V/F control	0	57
			1: Reserved		
			2: Reserved		
00-24	P.189	50Hz/60Hz switch selection	0: Frequency related parameter default value is 60Hz.	0	58
			1: Frequency related parameter default value is 50Hz.	1	
00-25	P.990	Parameter display mode setting	0: Parameter is displayed in "group mode"	0	58
			1: Parameter is displayed in "sequence P mode"		

## 5.1.1 Inverter information

➤ For checking inverter model, control board firmware version, etc.

Parameter	Name	Default	Setting Range	Content
00-00 P.90	Inverter model	Read only	Read only	---
00-01 P.188	Firmware version	Read only	Read only	Inverter control board firmware version

## ◆ Inverter model



**Read** Applicable motor capacity:

Value(value of the two low-order bits of 00-00(P.90))	Capacity (kw)
2	0.4
3	0.75
4	1.5
5	2.2

Note: The parameters above are read only, not for write.

## 5.1.2 Parameter restoration

➤ Set parameters back to default.

Parameter	Name	Default	Setting Range	Content
00-02	Parameter restoration	0	0	Off
			1	Clear alarm history (P.996=1)
			2	Reset inverter (P.997=1)
			3	Restore all parameters to default (P.998=1)
			4	Restore some parameters to default 1 (P.999=1)
			5	Restore some parameters to default 2 (P.999=2)
			6	Restore some parameters to default 3 (P.999=3)

### Setting Parameter restoration

- ◆ 1: When 00-02(P.996~P.999) is set to 1, screen will flash *Er.C.L*, the alarm record will be erased after writing, and 00-02(P.996~P.999) is reset to 0.
- ◆ 2: When 00-02(P.996~P.999) is set to 1, screen will flash *r.E.S.T*, and inverter will be reset, then 00-02(P.996~P.999) is reset to 0. After resetting the inverter, the accumulated values in “electronic thermal relay” and “IGBT module thermal relay” will be set to zero.
- ◆ 3: When 00-02(P.996~P.999) is set to 3, screen will flash *ALL*, all the parameters will be restored to the default values except the parameters in table 1 below. After parameters are restored, 00-02(P.996~P.999) is reset to 0.

**Exception** The parameters in table 1 below will not be restored to the default values:

Group	No.	Name
00-00	P.90	Inverter model
00-01	P.188	Firmware version
00-24	P.189	50Hz/60Hz switch selection
00-25	P.990	Parameter display mode setting
01-08	P.21	Acceleration/deceleration time increments
06-27	P.292	Total inverter operation time (minutes)
06-28	P.293	Total inverter operation time (days)
06-29	P.296	Total inverter power on time (minutes)
06-30	P.297	Total inverter power on time (days)

- ◆ 4 : When 00-02(P.996~P.999) is set to 4, screen will flash *P.r.C.r*, all the parameters will be restored to the default values except the parameters in table 1 and table 2 below after writing. After parameters are restored, 00-02(P.996~P.999) is reset to 0.

**Exception** The parameters in table 2 below and table 1 will not be restored to default values:



Group	No.	Name
00-21	P.300	Motor control mode selection
02-25	P.198	Terminal 3-5 minimum input current/ voltage
02-26	P.199	Terminal 3-5 maximum input current/ voltage
02-27	P.196	Percentage corresponds to terminal 3-5 minimum input current/ voltage
02-28	P.197	Percentage corresponds to terminal 3-5 maximum input current/ voltage
02-61	P.141	Polarity of percentage corresponds to terminal 3-5 current/ voltage signal
05-01	P.302	Motor rated power
05-02	P.303	Motor poles
05-03	P.304	Motor rated voltage
05-04	P.305	Motor rated frequency
05-05	P.306	Motor rated current
05-06	P.307	Motor rated rotation speed
05-07	P.308	Motor excitation current
05-08	P.309	IM motor stator resistance

- ◆ 5: User registered parameter 15-00~15-19(P.900~P.919) and the parameters set in 15-00~15-19(P.900~P.919) and the parameters in table 1 above will not be restored to default values. After parameters are restored, 00-02(P.996~P.999) is reset to 0.
- ◆ 6: User registered parameter 15-00~15-19(P.900~P.919) and the parameters set in 15-00~15-19(P.900~P.919) and the parameters in table 1 and table 2 above will not be restored to default values. After parameters are restored, 00-02(P.996~P.999) is reset to 0.

Note: When the parameter is restored to default value or some of the parameters are restored to default value, be sure to wait for the screen to display *End*, which means that it's complete, and then perform other operations.

## 5.1.3 Parameter protection

➤ It is used to select whether parameters can be written to prevent changing parameter values due to misoperation.

Parameter	Name	Default	Setting Range	Content
00-03 P.77	Selection of parameters write protection	0	0	Parameters can be written only when the motor stops.
			1	Parameters cannot be written.
			2	Parameters can also be written when the motor is running.
			3	Parameters cannot be read when in password protection.
00-04 P.294	Password parameter	0	0~65535	Write the registered password to decrypt parameter protection.
00-05 P.295	Password setup	0	2~65535	Register password for parameter protection setting.



Selection of parameters write protection

◆ Write parameters only during stop (00-03(P.77)="0"initial value)

**Exception** When running, the parameters below can still be written:

Group	No.	Name
00-03	P.77	Selection of parameters write protection
00-07	P.161	Multi-function display
02-25	P.198	Terminal 3-5 minimum input current/ voltage
02-26	P.199	Terminal 3-5 maximum input current/ voltage
02-27	P.196	Percentage corresponds to terminal 3-5 minimum input current/ voltage
02-28	P.197	Percentage corresponds to terminal 3-5 maximum input current/ voltage
02-52	P.56	Inverter rated current display level
04-00	P.4	Speed 1 (high speed)
04-01	P.5	Speed 2 (medium speed)
04-02	P.6	Speed 3 (low speed)
04-03	P.24	Speed 4
04-04	P.25	Speed 5
04-21	P.133	Programmed operation mode speed 3
04-22	P.134	Programmed operation mode speed 4
04-23	P.135	Programmed operation mode speed 5
04-24	P.136	Programmed operation mode speed 6
04-25	P.137	Programmed operation mode speed 7
04-26	P.138	Programmed operation mode speed 8
06-17	P.261	Maintenance alarm function

Group	No.	Name
04-05	P.26	Speed 6
04-06	P.27	Speed 7
04-07	P.142	Speed 8
04-08	P.143	Speed 9
04-09	P.144	Speed 10
04-10	P.145	Speed 11
04-11	P.146	Speed 12
04-12	P.147	Speed 13
04-13	P.148	Speed 14
04-14	P.149	Speed 15
04-19	P.131	Programmed operation mode speed 1
04-20	P.132	Programmed operation mode speed 2
06-40	P.288	Alarm record code query
06-42	P.290	Alarm record message query
08-03	P.225	PID target value
08-18	P.223	Analog feedback signal bias
08-19	P.224	Analog feedback signal gain
10-19	P.230	Dwell frequency at acceleration
10-21	P.232	Dwell frequency at deceleration
10-46	P.268	Voltage stall level

◆ Most parameters cannot be written. (00-03="1")

**Exception** Parameters below can be written.

Group	No.	Name
00-03	P.77	Selection of parameters write protection

00-16	P.79	Operation mode selection
-------	------	--------------------------

- ◆ When running, the parameters below can be written. ( 00-03(P.77)="2")

**Exception** When running, the parameters below cannot be written:

Group	No.	Name	Group	No.	Name
00-00	P.90	Inverter model	06-27	P.292	Total inverter operation time (minutes)
00-01	P.188	Firmware version	06-28	P.293	Total inverter operation time (days)
00-11	P.72	Carrier frequency	06-41	P.289	Alarm record code display
00-15	P.78	Prevent forward/reverse rotation selection	06-43	P.291	Alarm record message display
00-16	P.79	Operation mode selection	06-29	P.296	Total inverter power on time (minutes)
00-19	P.35	Communication mode selection	06-01	P.22	Stall prevention operation level
06-30	P.297	Total inverter power on time (days)	06-08	P.155	Over torque detection level

- ◆ When in password protection, parameters cannot be read. ( 00-03(P.77)="3")

**Exception** Parameters below can still be read:

Group	No.	Name
00-00	P.90	Inverter model
00-01	P.188	Firmware version
00-04	P.294	Password parameter
00-05	P.295	Password setup
00-08	P.37	Speed display
00-10	P.59	Keypad knob value lock selection
00-16	P.79	Operation mode selection
00-25	P.990	Parameter display mode setting
01-00	P.1	Maximum frequency
01-01	P.2	Minimum frequency
02-21	P.39	Terminal 3-5/ keypad knob maximum operation frequency
06-41	P.289	Alarm record code display
06-43	P.291	Alarm record message display

### Setting Password protection

- ◆ Register a password
  1. Write a number (2 ~ 65535) in 00-05(P.295) as a password, password protection takes effect immediately;
  2. After registering a password, 00-05(P.295)=1;
- ◆ Unlock password protection
  1. Write the correct password in 00-04(P.294), and then password protection will be unlocked;
  2. After unlocking the password, 00-04(P.294)=0, 00-05(P.295)=1;
  3. If turn the power off and then turn on, inverter will still restore to the password protection status.
- ◆ Password all clear
  1. Write the correct password in 00-04(P.294) to unlock the password protection;
  2. Write 0 in 00-05(P.295), password will be all cleared.

Note: If password is forgotten, enter the same incorrect password three times in 00-04(P.294), and the interval between two consecutive times is not more than 10s. The password can be cleared and the user parameters will be automatically restored to default.

## 5.1.4 Monitoring function

➤ Item to monitor on built-in keypad can be selected.

Parameter	Name	Default	Setting Range	Content
00-06 P.110	Built-in keypad monitor selection	2	0	When inverter starts, built-in keypad enters monitor mode automatically, screen displays output frequency (Note 1).
			1	When inverter starts, built-in keypad displays target frequency.
			2	When inverter starts, built-in keypad enters monitor mode automatically, screen displays steady state output frequency
			3	When inverter starts, built-in keypad enters monitor mode automatically, screen displays current pressure and feedback pressure of the constant pressure system in percentage
			4	When inverter starts, built-in keypad doesn't enter monitor mode but enter the previous mode before power off
			5	When inverter starts, built-in keypad enters monitor mode automatically, screen displays current pressure and feedback pressure of the constant pressure system
00-07 P.161	Multi-function display	0	0	Output AC voltage (V)
			1	DC bus voltage. (V)
			2	Inverter temperature rising accumulation rate (%)
			3	Target pressure of the constant pressure system (%)
			4	Feedback pressure of the constant pressure system (%)
			5	Running frequency (Hz)
			6	Electronic thermal accumulation rate (%)
			8	Signal value (mA) of 3-5 input terminals (mA/V).
			9	Output power (kW).
			11	Forward reverse rotation signal. 1: forward rotation 2: reverse rotation 0: stop.
			12	NTC temperature (°C)
			13	Motor electronic thermal accumulation rate (%)
			14~18	14~18 : Reserved
			19	Digital terminal input state
20	Digital terminal output state			
21	Actual working carrier frequency			

Note: 1. The "output frequency" here is the value after slip compensation.

2. The multi-function display function is implemented in the monitor voltage mode. For switching to monitor voltage mode, refer to section 4.2.3.

3. Digital terminal input state detail



b3	b2	b1	b0
M1	M0	STR	STF

4. Digital terminal output state detail

b1	b0
A-C	0

Display

## Keypad monitoring selection

- ◆ Display current pressure and feedback pressure of the constant pressure system in percentage( 00-06(P.110)="3")  
The screen shows two sections. A decimal point is used to separate the boundaries, on the left is the target pressure and on the right is the feedback pressure of the constant pressure system in percentage.  
As shown in this figure : , "20" means the target pressure of the constant pressure system is 20%, the target value will be  $20\% \times 08-43(P.251)$  ; "30" means the feedback pressure of the constant pressure system is 30%, the feedback value will be  $30\% \times 08-43(P.251)$ .
- ◆ Displays current pressure and feedback pressure of the constant pressure system ( 00-06(P.110)="5")  
The screen shows two sections. A space is used to separate the boundaries, on the left is the target pressure and on the right is the feedback pressure of the constant pressure system  
As shown in this figure : : , "2.0" means the target pressure of the constant pressure system is 2.0 , "3.0" means the feedback pressure of the constant pressure system is 3.0.

Display

## Multi-function display

- ◆ The display value will show in the monitor voltage mode. Please refer to 4.2.3 for flow chart of monitoring mode.

## 5.1.5 Speed display

➤ In “monitoring output frequency” mode, the screen displays corresponding machine speed.

Parameter	Name	Default	Setting Range	Content
00-08 P.37	Speed display	0.0	0	Display output frequency(not mechanical speed)
			0.1~5000.0	When 00-09(P.259)=1
			1~50000	When 00-09(P.259)=0
00-09 P.259	Speed display unit selection	1	0	Speed display unit is 1
			1	Speed display unit is 0.1

### Setting Speed display

◆ The setting value of 00-08(P.37) is the speed of motor when output frequency is 60Hz.

For example:

1. If the transmitting belt speed is 950 m/minute when the inverter output frequency is 60Hz, set 00-08(P.37) = 950.
2. After setting, in the keypad “output frequency monitor mode” , the screen will display the speed of the transmitting belt.

Note: The machine speed on the screen is the theoretical value calculated proportionately by the inverter output frequency and the setting value of 00-08(P.37). So there's minute discrepancy between the displayed machine speed and the actual one.


## 5.1.6 Built-in keypad set target frequency selection

Parameter	Name	Default	Setting Range	Content
00-10 P.59	Built-in keypad set target frequency selection	0	XXX0	Use up down button on built-in or external keypad to set frequency
			XXX1	Use keypad knob on external keypad to set frequency
			XXX2	Use keypad knob on built-in keypad to set frequency
			X0XX	Every frequency change will save after 30s
			X1XX	Every frequency change will save after 10s
			X2XX	Every frequency change will not save
			0XXX	Set frequency will work immediately when use up down button on built-in keypad
			1XXX	Set frequency will work after pressing SET when use up down button on built-in keypad

## Setting

## Built-in keypad set target frequency selection

00-10 ( P.59 ) is set by unit, 4 in total.



- Note: 1. The set value on the hundreds digit of 00-10 (P.59) is only for the frequency set by up down keys on keypad.
2. When 00-10 (P.59) ones digit is 1, if the external keypad has a VR knob, the VR knob setting frequency is valid. If the external keypad does not have a VR knob, then up down keys of the external keypad is valid.


### 5.1.7 PWM carrier frequency

➤ The motor sound can be changed by adjusting PWM carrier frequency properly.

Parameter	Name	Default	Setting Range	Content
00-11 P.72	Carrier frequency	5 kHz	1~15 kHz	--
00-12 P.31	Soft-PWM carrier function selection	0	0	Off
			1	When 00-11(P.72)<5, Soft-PWM is on(only apply to V/F control)
			2	When 00-11(P.72) > 9, if the IGBT temperature is high, carrier frequency will decrease automatically, when temperature go back to normal, carrier frequency go back to 00-11(P.72) value

#### Setting Carrier frequency

- ◆ The higher the carrier frequency, the lower the motor acoustic noise, but will result in greater leakage current and larger noise generated by the inverter.
- ◆ The higher the carrier frequency, the more energy inverter will consume, and temperature will also be higher.
- ◆ If mechanical resonance occurred in a system, 00-11(P.72) can also be adjusted to lower the vibration.
- ◆ The higher the carrier frequency, the lower the rated current of the inverter. This is to prevent the inverter from overheating and prolong the service life of the IGBT, so such protective measures are necessary. When the carrier frequency is 9kHz and below, the rated current of the inverter is 100%. As the carrier frequency increases, the rated current will decrease, which will accelerate heat accumulation to protect the inverter. The relationship curve between rated current and carrier frequency is shown in the figure below:



Note: The setting value of carrier frequency is best to be 8 times larger than the target frequency.




#### Setting Carrier operation selection V/F

- ◆ Soft-PWM control is a control method that changes the motor noise from a metallic sound into an inoffensive, complex tone.
- ◆ Motor noise modulation control is when the inverter changes its carrier frequency from time to time during operation, metal noises generated by the motor will not be in a single frequency, so sharp single frequency noises will be reduced.



## 5.1.8 Stop operation selection


- Select the inverter stop method

Parameter	Name	Default	Setting Range	Content
00-13 P.71	Idling brake / DC brake	1	0	Idling brake
			1	DC brake
00-14 P.75	 function selection	1	0	Press  button and inverter stop running in PU and H2(combine mode 2) mode
			1	Press  button and inverter stop running in all mode.

### Setting Idling brake / DC brake


- ◆ Idling brake ( 00-13(P.71)="0")

After receiving stop signal, inverter stops output immediately, and the motor idle freely.





- ◆ DC braking(00-13(P.71)="1")


After receiving stop signal, inverter decelerates according to the acceleration/deceleration curve until it stops completely.



### Setting button function selection

- ◆ Press  button to stop during operation (00-14(P.75)="1")

**Note:** When running in non-PU and H2 modes, pressing the  button will display E0 and lock all functions on the keypad. Please follow the steps below to cancel this state:

1. If the start signal is given from digital input terminal, switch off the signal (Note1);
2. Press  button for over 1.0 second to remove E0 state.

Note: In programmed operation mode, it is not necessary to switch off the start signal. Inverter will run at the section

System parameter group 00

where it stopped after reset.

### 5.1.9 Forward/reverse rotate prevent function

- Set this parameter to limit the motor rotation to only one direction, and prevent reverse rotation fault resulting from the incorrect input of the start signal.

Parameter	Name	Default	Setting Range	Content
00-15 P.78	Prevent forward/ reverse rotation selection	0	0	Forward/reverse rotation are both permitted.
			1	Prevent reverse rotation (Giving reverse signal decelerates and stops the motor).
			2	Prevent forward rotation (Giving forward signal decelerates and stops the motor).

Note: It is valid to all start signals.

### 5.1.10 Operation mode selection

- Select the operation mode of the inverter, and determine the source of start signal and target frequency.

Parameter	Name	Default	Setting Range	Content
00-16 P.79	Operation mode selection	0	0	"PU mode", "external mode" and "Jog mode" are interchangeable.
			1	"PU mode" and "JOG mode" are interchangeable.
			2	"External mode" only
			3	"Communication mode" only
			4	"Combined mode 1"
			5	"Combined mode 2"
			6	"Combined mode 3"
			7	"Combined mode 4"
			8	"Combined mode 5"
00-17 P.97	Second target frequency selection	0	0	Frequency set by built-in keypad
			1	Frequency set by RS485 communication
			2	Frequency set by analog input
00-19 P.35	Communication mode selection	0	0	In communication mode, run signal and frequency is given by communication.
			1	In communication mode, run signal and frequency is given by external signal.

**Setting** Operation mode selection

- ◆ Please refer to Section 4.3 for detailed setting and usage

**Setting** Communication mode instruction selection

- ◆ When 00-16(P.79)=3, select communication mode:
  1. If 00-19(P.35)=0, Start and frequency command is given by communication;
  2. If 00-19(P.35)=1, Start and frequency command is given by external terminals.

### 5.1.11 Motor control mode selection

➤ Choose control mode for the AC motor

Parameter	Name	Default	Setting Range	Content
00-21 P.300	Motor control mode selection	0	0	Induction motor V/F control
			2	Reserved

 Setting Motor control mode

- ◆ Induction motor V/F control: user can design proportion of V/F as required and can control multiple motors simultaneously.

Note : 1. The motor capacity must be the same level or one level lower than the inverter capacity.

### 5.1.12 50/60Hz switch selection

- Select between 50Hz or 60Hz according to different power source frequency or default motor frequency, this effects all frequency-related parameters.

Parameter	Name	Default	Setting Range	Content
00-24 P.189	50Hz/60Hz switch selection	0	0	Frequency related parameter default value is 60Hz.
		1	1	Frequency related parameter default value is 50Hz.

#### Setting 50/60Hz switch selection

- ◆ The following two steps shows how to set frequency related parameter to 60Hz system (00-24(P.189)="0").
  1. Set 00-24(P.189)=0;
  2. Set 00-02=3(P.998=1) to set all parameters to default, at this point frequency-related parameters of the inverter will be reset to 60Hz.
- ◆ The following parameters are affected:

Group	No.	Name
01-03	P.3	Base frequency
01-09	P.20	Acceleration/deceleration reference frequency
02-21	P.39	Maximum operation frequency ( Terminal 3-5input signal/ built-in keypad knob set frequency )

Group	No.	Name
05-04	P.305	Motor rated frequency
05-06	P.307	Motor rated rotation speed
06-03	P.66	Stall prevention operation reduction starting frequency
08-14	P.182	Upper integral limit

### 5.1.13 Parameter mode setting

- Select "Sequence P mode" or "group mode" to display parameters.

Parameter	Name	Default	Setting Range	Content
00-25 P.990	Parameter display mode setting	0	0	Parameter is displayed in "group mode"
			1	Parameter is displayed in "sequence P mode"

#### Display Parameter mode setting

- ◆ "Group mode" displaying

00-25

- ◆ "Sequence P mode" displaying

P. 0

## 5.2 Basic Parameter Group 01

Group	Parameter Number	Name	Setting Range	Default	Page
01-00	P.1	Maximum frequency	0.00 ~ 01-02 ( P.18 ) Hz	120.00Hz	61
01-01	P.2	Minimum frequency	0 ~ 120.00Hz	0.00Hz	61
01-02	P.18	High-speed maximum frequency	01-00 ( P.1 ) ~ 599.00Hz	120.00Hz	61
01-03	P.3	Base frequency	50Hz system setting: 0 ~ 599.00Hz	50.00Hz	62
			60Hz system setting: 0 ~ 599.00Hz	60.00Hz	
01-04	P.19	Base voltage	0 ~ 1000.0V	99999	62
			99999: Change according to the input voltage		
01-05	P.29	Acceleration/deceleration curve selection	0: Linear acceleration /deceleration curve	0	63
			1: S shape acceleration /deceleration curve 1		
			2: S shape acceleration /deceleration curve 2		
			3: S shape acceleration /deceleration curve 3		
01-06	P.7	Acceleration time	0 ~ 360.00s/0 ~ 3600.0s	5.00s	63
01-07	P.8	Deceleration time	0 ~ 360.00s/0 ~ 3600.0s	5.00s	63
01-08	P.21	Acceleration/deceleration time increments	0: Time increment is 0.01s	0	63
			1: Time increment is 0.1s		
01-09	P.20	Acceleration/deceleration reference frequency	50Hz system setting: 1.00 ~ 599.00Hz	50.00Hz	63
			60Hz system setting: 1.00 ~ 599.00Hz	60.00Hz	
01-10	P.0	Torque boost	0 ~ 30.0% : 0.75K and under	6.0%	66
			0 ~ 30.0% : 1.5K ~ 2.2K	4.0%	
01-11	P.13	Starting frequency	0 ~ 60.00Hz	0.50Hz	66
01-12	P.14	Load pattern selection	0: For constant torque loads (conveyor belt, etc.)	0	67
			1: For variable torque loads (fans and pumps, etc.)		
			2、3: For Lifting loads		
			4: Multipoint V/F curve		
			5~13: Special two-point V/F curve		
01-13	P.15	JOG frequency	0 ~ 599.00Hz	5.00Hz	69
01-14	P.16	JOG Acc/ Dec time	0 ~ 360.00s/0 ~ 3600.0s	0.50s	69
01-15	P.28	Output frequency filter time	0 ~ 31	0	69
01-16	P.91	Frequency jump 1A	0 ~ 599.00Hz	99999	70
			99999: Off		
01-17	P.92	Frequency jump 1B	0 ~ 599.00Hz	99999	70
			99999: Off		
01-18	P.93	Frequency jump 2A	0 ~ 599.00Hz	99999	70
			99999: Off		
01-19	P.94	Frequency jump 2B	0 ~ 599.00Hz	99999	70
			99999: Off		
01-20	P.95	Frequency jump 3A	0 ~ 599.00Hz	99999	70
			99999: Off		

Group	Parameter Number	Name	Setting Range	Default	Page
01-21	P.96	Frequency jump 3B	0 ~ 599.00Hz	99999	70
			99999: Off		
01-22	P.44	Second acceleration time	0 ~ 360.00s/0 ~ 3600.0s	99999	71
			99999: Off		
01-23	P.45	Second deceleration time	0 ~ 360.00s/0 ~ 3600.0s	99999	71
			99999: Off		
01-24	P.46	Second torque boost	0 ~ 30.0%	99999	71
			99999: Off		
01-25	P.47	Second base frequency	0 ~ 599.00Hz	99999	71
			99999: Off		
01-26	P.98	Middle frequency 1	0 ~ 599.00Hz	3.00Hz	72
01-27	P.99	Output voltage 1 of middle frequency	0 ~ 100.0%	10.0%	72
01-28	P.162	Middle frequency 2	0 ~ 599.00Hz	99999	72
			99999: Off		
01-29	P.163	Output voltage 2 of middle frequency	0 ~ 100.0%	0.0%	72
01-30	P.164	Middle frequency 3	0 ~ 599.00Hz	99999	72
			99999: Off		
01-31	P.165	Output voltage 3 of middle frequency	0 ~ 100.0%	0.0%	72
01-32	P.166	Middle frequency 4	0 ~ 599.00Hz	99999	72
			99999: Off		
01-33	P.167	Output voltage 4 of middle frequency	0 ~ 100.0%	0.0%	72
01-34	P.168	Middle frequency 5	0 ~ 599.00Hz	99999	72
			99999: Off		
01-35	P.169	Output voltage 5 of middle frequency	0 ~ 100.0%	0.0%	72
01-36	P.255	S curve time at the beginning of acceleration	0 ~ 25.00s/0 ~ 250.0s	0.20s	73
01-37	P.256	S curve time at the end of acceleration	0 ~ 25.00s/0 ~ 250.0s	99999	73
			99999: Off		
01-38	P.257	S curve time at the beginning of deceleration	0 ~ 25.00s/0 ~ 250.0s	99999	73
			99999: Off		
01-39	P.258	S curve time at the end of deceleration	0 ~ 25.00s/0 ~ 250.0s	99999	73
			99999: Off		
01-40	P.219	Remote function acc/dec time selection	0 : Use default acc/dec time ( same as regular mode )	0	75
			1 : Use second acc/dec time		

## 5.2.1 Limiting the output frequency

➤ Output frequency can be limited. Fix the output frequency at the upper and lower limits.


Parameter	Name	Default	Setting Range	Content
01-00 P.1	Maximum frequency	120.00Hz	0.00 ~ 01-02 ( P.18 ) Hz	--
01-01 P.2	Minimum frequency	0.00Hz	0 ~ 120.00Hz	Output minimum frequency
01-02 P.18	High-speed maximum frequency	120.00Hz	01-00 ( P.1 ) ~ 599.00Hz	Set when need inverter to run over 120Hz

**Setting** Maximum frequency, high-speed maximum frequency

- ◆ The “maximum frequency” and the “high-speed maximum frequency” are interrelated:
  1. If the target frequency upper limit is set below 01-00(P.1), use 01-00(P.1) as the maximum frequency;
  2. If the target frequency upper limit is above 01-00(P.1), use 01-02(P.18) as the maximum frequency.
- ◆ If  $01-00(P.1) < 01-01(P.2)$ , the steady output frequency will be fix at 01-00(P.1) value.
- ◆ When setting the target frequency in PU mode, the frequency set value cannot exceed the value of 01-00(P.1).

**Setting** Minimum frequency

- ◆ If the target frequency  $\leq 01-01(P.2)$ , the steady output frequency equals to = 01-01(P.2).
- ◆ If  $01-01(P.2) < \text{target frequency} \leq 01-00(P.1) / (01-02(P.18))$ , the steady output frequency equals to target frequency.






## 5.2.2 Base frequency, base voltage

- Use this function to adjust the inverter outputs (voltage, frequency) to match with the motor rating.

Parameter	Name	Default	Setting Range	Content
01-03 P.3	Base frequency	50.00Hz	0.00 ~ 599.00Hz	50Hz system (00-24(P.189)=1)
		60.00Hz		60Hz system (00-24(P.189)=0)
01-04 P.19	Base voltage	99999	0 ~ 1000.0V	Set base voltage according to motor rating.
			99999	Base voltage is equal to power source voltage.

### Setting Base frequency

- ◆ Generally, 01-03(P.3) is set as the rated frequency of motor.  
When the rated frequency on the motor nameplate is "50 Hz", make sure to set it to "50 Hz". If set it to "60 Hz" the voltage will drop too much, causing torque to drop. As a result, the inverter may trip due to overload.
- ◆ When running the motor requires switching to the commercial power supply, set the commercial power supply voltage value in 01-03(P.3).



Note: For second base frequency please refer to 5.2.10 the second function.

### Setting Base voltage

- ◆ When the output frequency is lower than the base frequency, the output voltage of the inverter will increase as the output frequency increases; when the output frequency reaches the base frequency (01-03(P.3)), the output voltage will reach the base voltage. If the output frequency exceeds the base frequency and still rising, the output voltage will be fixed at the base voltage.

### 5.2.3 Acceleration/deceleration time setting

➤ Use this function to set motor acceleration/deceleration time.


Parameter	Name	Default	Setting Range	Content
01-05 P.29	Acceleration/ deceleration curve selection	0	0	Linear acceleration /deceleration curve
			1	S shape acceleration /deceleration curve 1 (Note 1)
			2	S shape acceleration /deceleration curve 2 (Note 2)
			3	S shape acceleration /deceleration curve 3 (Note 3)
01-06 P.7	Acceleration time	5.00s	0 ~ 360.00s/ 0 ~ 3600.0s	2.2K and types below
01-07 P.8	Deceleration time	5.00s	0 ~ 360.00s/ 0 ~ 3600.0s	2.2K and types below
01-08 P.21	Acceleration/ deceleration time increments	0	0	Time increment is 0.01s
			1	Time increment is 0.1s
01-09 P.20	Acceleration/ deceleration reference frequency	50.00Hz	1.00 ~ 599.00Hz	50Hz system setting (00-24(P.189)=1)
		60.00Hz		60Hz system setting(00-24(P.189)=0)

#### Setting Acceleration/deceleration curve selection

- ◆ Linear acceleration /deceleration curve(01-05(P.29)="0")

An acceleration slope is formed by the combination of 01-06(P.7) and 01-09(P.20). A deceleration slope is formed by the combination of 01-07(P.8) and 01-09(P.20).

When the target frequency varies, it increases according to the "acceleration slope" or decreases according to the "deceleration slope" linearly. See the figure below:



- ◆ S shape acceleration /deceleration curve 1(01-05(P.29)="1")

An acceleration slope is formed by the combination of 01-06(P.7) and 01-03(P.3). A deceleration slope is formed by the combination of 01-07(P.8) and 01-03(P.3).

The acceleration / deceleration curve has an S-shape change according to the "acceleration / deceleration slope".


The S-shape equation between 0 and 01-03 (P.3) is:

$$f = [1 - \cos(\frac{90^\circ \times t}{01-06(P.7)})] \times 01-03(P.3)$$

The S-shape equation above 01-03 (P.3) is:

$$t = \frac{4}{9} \times \frac{01-06(P.7)}{01-03(P.3)^2} \times f^2 + \frac{5}{9} \times 01-06(P.7)$$


t = time; f = output frequency



◆ S shape acceleration /deceleration curve 2(01-05(P.29)="2")

An acceleration slope is formed by the combination of 01-06(P.7) and 01-09(P.20). A deceleration slope is formed by the combination of 01-07(P.8) and 01-09(P.20).

When the target frequency varies, the acceleration increases S-shape according to the "acceleration slope". The deceleration decreases S-shape according to the "deceleration slope". As shown in the figure below, when frequency is adjusted from  $f_0$  to  $f_2$ , it accelerates S-shape once, and the time is  $01-06(P.7) \times (f_2 - f_0) / 01-09(P.20)$ . Then if the frequency is adjusted from  $f_2$  to  $f_3$ , it accelerates S-shape the second time, and the time is  $01-06(P.7) \times (f_3 - f_2) / 01-09(P.20)$ .



◆ S shape acceleration /deceleration curve 3(01-05(P.29)="3")

Please refer to 5.2.12 S pattern time setting.

**Setting**

Acceleration/deceleration time increments

- ◆ When 01-08(P.21)=0, minimum acceleration / deceleration time 01-06(P.7),01-07(P.8), 01-14(P.16),01-22(P.44), 01-23(P.45),01-36~01-39(P.255~P.258),04-35~04-42(P.111~P.1180,10-27~10-28(P.238~P.239) increment is 0.01s.
- ◆ When 01-08(P.21)=1, minimum acceleration / deceleration time 01-06(P.7),01-07(P.8), 01-14(P.16),01-22(P.44), 01-23(P.45),01-36~01-39(P.255~P.258),04-35~04-42(P.111~P.1180,10-27~10-28(P.238~P.239) increment is 0.1s.

Setting Acceleration / deceleration reference frequency

- When the output frequency of the inverter is accelerated from 0Hz to 01-09(P.20), the required time is defined as "acceleration time".
- ◆ When the output frequency of the inverter is decelerated from 0Hz to 01-09(P.20), the required time is defined as "deceleration time".

Note: 1. S shape acceleration /deceleration curve 1 is used when acceleration/deceleration is required in a short time in high-speed area equal to or higher than the base frequency, such as spindle motor.

2. S shape acceleration /deceleration curve 2 can effectively reduce motor vibration during the acceleration / deceleration, and thus prevent the belts and gears from failing.

3. S shape acceleration /deceleration curve 3 is used to start the inverter gradually without impact.

4. Please refer to Section 5.2.10 second function for the second acceleration/deceleration time.

5. When RT is "on", the second function is on. For the operation characteristics of the motor, please refer to Section 5.2.10. RT mentioned in this section is the function name of the "multi-function digital input terminal". Please refer to 03-00(P.83)、03-01(P.84)、03-03(P.80)、03-04(P.81) for function selection and purposes of the multi-function digital input terminal. For related wiring, please refer to Section 3.7.

### 5.2.4 Torque boost V/F

- For an inverter controlled by V/F mode, when the motor starts up, the starting torque is usually insufficient since the output voltage of the inverter is low. In this case, the output voltage can be elevated by setting the torque boost (01-10) properly, and thus getting a better starting torque.

Parameter	Name	Default	Setting Range	Content
01-10 P.0	Torque boost	6.0%	0 ~ 30.0%	0.75K and under
		4.0%		1.5K ~ 2.2K models

**Setting** Torque boost

- ◆ If 01-10(P.0)=6% and 01-04(P.19)=220V, and when output frequency of the inverter is 0.2Hz, the output voltage is:

$$01-04(P.19) \times \left( \frac{100\% - 01-10(P.0)}{01-03(P.3)} \times f + 01-10(P.0) \right) = 220V \times \left( \frac{100\% - 6\%}{50Hz} \times 0.2Hz + 6\% \right) = 14.03V$$

- ◆ If RT is "on," "the second torque boost" on 01-24(P.46) is valid (Note 2).

Note: 1. If the set value of 01-10(P.0) is too high, it will activate over current protection or fail to start.  
 2. Please refer to Section 5.2.10 for the second torque boost.  
 3. RT mentioned in this section is the function name of the "multi-function digital input terminal". Please refer to 03-00(P.83), 03-01(P.84), 03-03(P.80), 03-04(P.81) ; for function selection of the multi-function digital input terminal. For related wiring, please refer to Section 3.7.


### 5.2.5 Starting frequency

- When the motor starts up, the instantaneous output frequency of the inverter is called "starting frequency".

Parameter	Name	Default	Setting Range	Content
01-11 P.13	Starting frequency	0.50Hz	0 ~ 60.00Hz	---

**Setting** Starting frequency

- ◆ If target frequency of inverter is lower than 01-11(P.13) value, the motor will not run. When given the start signal to motor, the output frequency will go up from the value of 01-11(P.13).



### 5.2.6 Load pattern selection V/F

➤ In V/F control, you can choose the best output characteristics for different applications and load.

Parameter	Name	Default	Setting Range	Content
01-12 P.14	Load pattern selection	0	0	For constant torque loads (conveyor belt, etc.)
			1	For variable torque loads (fans and pumps, etc.)
			2、3	For Lifting loads
			4	Multipoint V/F curve
			5 ~ 13	Special two-point V/F curve




Load pattern selection

◆ When 01-12(P.14) = 4, suppose that 01-04(P.19)=220V, 01-26(P.98)=5Hz, 01-27(P.99)=10%, when the inverter is running at 5Hz, the output voltage equals to 01-04(P.19)×01-27(P.99) = 220V×10% = 22V.

◆ If RT is “on”, 01-24(P.46) “the second torque boost” is valid.


<p style="text-align: center;">01-12(P.14) = 0</p> <p style="text-align: center;">Applicable to constant torque loads (convey belt, etc.)</p>	<p style="text-align: center;">01-12(P.14) = 1</p> <p style="text-align: center;">Curve equation of output voltage and output frequency is</p> $V = \frac{(\text{Base voltage} - \text{Base voltage} * P.0) * \text{Output frequency}^2}{\text{Base frequency}^2} + \text{Base voltage} * P.0$
<p style="text-align: center;">01-12(P.14) = 2</p> <p style="text-align: center;">Ascending / descending loads</p>	<p style="text-align: center;">01-12(P.14) = 3</p> <p style="text-align: center;">Ascending / descending loads</p>

01-12(P.14) = 4




Determine whether the curve is high starting torque or decreasing torque according to the value of the parameter set in the figure (Note 1).

01-12(P.14)=5




When 01-12(P.14)=5, the value of A is 7.1% (Note 2)

01-12(P.14) = 6 , 7 , 8




When 01-12(P.14)=6, the value of A is 8.7%. When 01-12(P.14)=7, the value of A is 10.4%. When 01-12(P.14)=8, the value of A is 12.0%.(Note 2)

01-12(P.14) = 9 , 10



When 01-12(P.14)=9, the value of A is 20.0%. When 01-12(P.14)=10, the value of A is 25.0%.(Note 2)

01-12(P.14) = 11 , 12 , 13



When 01-12(P.14)= 11, the value of A is 9.3%. When 01-12(P.14) = 12, the value of A is 12.7%. When 01-12(P.14) = 13, the value of A is 16.1%. (Note 2)

Note: 1. Referring to the diagrams above, set 01-26(P.98) and 01-27(P.99) if one point is needed. Set 01-26(P.98), 01-27(P.99), 01-28(P.162) and 01-29(P.163) if two points are needed. 01-26(P.98), 01-27(P.99), 01-28(P.162), 01-29(P.163), 01-30(P.164) and 01-31(P.165) if three points are needed.

2. When set 01-12(P.14) between 5 and 13, if 01-10(P.0) is larger than the point A, point A equals to 01-10(P.0).


### 5.2.7 JOG run

- The frequency and acceleration/deceleration time for JOG running can be set. JOG can be used for conveyor positioning, test run, etc.

Parameter	Name	Default	Setting Range	Content
01-13 P.15	JOG frequency	5.00Hz	0 ~ 599.00Hz	---
01-14 P.16	JOG Acc/ Dec time	0.50s	0 ~ 360.00s/ 0 ~ 3600.0s	01-08(P.21)=0/ 01-08(P.21)=1

**Setting** JOG operation

- ◆ In JOG mode, the output frequency is the set value of 01-13(P.15), and the acceleration / deceleration time is the set value of 01-14(P.16).



Note:1. Please refer to Section 4.3.3 for how to enter the JOG mode.  
 2. For the operation steps of switching between forward and reverse rotation, please refer to 4.2.7 Operation flow chart for changing motor rotation direction.

### 5.2.8 Output frequency filter time

- This filter can reduce the impact when switching the frequency between high and low, and thus reduce the vibration of machine

Parameter	Name	Default	Setting Range	Content
01-15 P.28	Output frequency filter time	0	0 ~ 31	---

**Setting** Output frequency filter time

- ◆ The filtering effect is better when output frequency filter time is larger, but will also increase the response delay.
- ◆ If 01-15(P.28) is set to 0, the filtering function is off.




## 5.2.9 Frequency jump

- To avoid resonance from a mechanical system, these parameters allow jumping through resonant frequencies.

Parameter	Name	Default	Setting Range	Content
01-16 P.91	Frequency jump 1A	99999	0 ~ 599.00Hz	---
			99999	Invalid.
01-17 P.92	Frequency jump 1B	99999	0 ~ 599.00Hz	---
			99999	Invalid.
01-18 P.93	Frequency jump 2A	99999	0 ~ 599.00Hz	---
			99999	Invalid.
01-19 P.94	Frequency jump 2B	99999	0 ~ 599.00Hz	---
			99999	Invalid.
01-20 P.95	Frequency jump 3A	99999	0 ~ 599.00Hz	---
			99999	Invalid.
01-21 P.96	Frequency jump 3B	99999	0 ~ 599.00Hz	---
			99999	Invalid.

### Setting Frequency jump

- ◆ To avoid system's mechanical resonance frequency when running the motor, the inverter provides three sets of jump frequencies: 01-16(P.91) and 01-17(P.92) (the first set), 01-18(P.93) and 01-19(P.94) (the second set), 01-20(P.95) and 01-21(P.96) (the third set)



- ◆ For example: assuming 01-16(P.91)=45 and 01-17(P.92)=50;  
 If the target frequency  $\leq$  45Hz, then the steady output frequency = the target frequency.  
 If 45Hz  $\leq$  target frequency < 50Hz, then the steady output frequency = 45Hz.  
 If the target frequency  $\geq$  50Hz, then the steady output frequency = the target frequency.

Note: 1. During acceleration / deceleration, output frequency of inverter will pass through the jump frequency.  
 2. When 01-16(P.91)=99999 or 01-17(P.92)=99999, the first set of frequency jump is invalid.  
 When 01-18(P.93)=99999 or 01-19(P.94)=99999, the second set of frequency jump is invalid.  
 When 01-20(P.95)=99999 or 01-21(P.96)=99999, the third set of frequency jump is invalid.

## 5.2.10 Second function

➤ When given RT signal, these parameters will work.

Parameter	Name	Default	Setting Range	Content
01-22 P.44	Second acceleration time	99999	0 ~ 360.00s/0 ~ 3600.0s	01-08(P.21)=0/ 01-08(P.21)=1
			99999	Off
01-23 P.45	Second deceleration time	99999	0 ~ 360.00s/0 ~ 3600.0s	01-08(P.21)=0/ 01-08(P.21)=1
			99999	Off
01-24 P.46	Second torque boost	99999	0 ~ 30.0%	---
			99999	Off
01-25 P.47	Second base frequency	99999	0 ~ 599.00Hz	---
			99999	Off

### Setting Second function

- ◆ When 01-08(P.21)=0, minimum acceleration / deceleration time 01-22(P.44), 01-23(P.45) increment is 0.01s.
- ◆ When 01-08(P.21)=1, minimum acceleration / deceleration time (01-22(P.44), 01-23(P.45)) increment is 0.1s.  
When RT is “on”, second function is valid. For the motor operation characteristics, please refer to the following second function setting.

If 01-22(P.44)≠99999 and 01-23(P.45)=99999, when RT is “on”, acceleration /deceleration time is the “set value of 01-22(P.44)”.

If 01-22(P.44)≠99999 and 01-24(P.46)=99999, when RT is “on”, torque boost is the “set value of 01-10(P.0)”.

If 01-22(P.44)≠99999 and 01-24(P.46)≠99999, when RT is “on”, torque boost is the “set value of 01-24(P.46)”.

If 01-22(P.44)≠99999 and 01-25(P.47)=99999, when RT is “on”, base frequency is the “set value of 01-03(P.3)”.

If 01-22(P.44)≠99999 and 01-25(P.47)≠99999, when RT is “on”, base frequency is the “set value of 01-25(P.47)”.

Note: RT mentioned here is the function name of “multi-function digital input terminal”. Please refer to 03-00(P.83), 03-01(P.84), 03-03(P.80), 03-04(P.81) for function selection of multi-function digital input terminal; please refer to Section 3.7.

## 5.2.11 Middle frequency, output voltage of middle frequency V/F

➤ Parameters can be set when using special motors, especially to adjust motor torque.

Parameter	Name	Default	Setting Range	Content
01-26 P.98	Middle frequency 1	3.00Hz	0 ~ 599.00Hz	---
01-27 P.99	Output voltage 1 of middle frequency	10.0%	0 ~ 100.0%	---
01-28 P.162	Middle frequency 2	99999	0 ~ 599.00Hz	---
			99999	Off
01-29 P.163	Output voltage 2 of middle frequency	0.0%	0 ~ 100.0%	---
01-30 P.164	Middle frequency 3	99999	0 ~ 599.00Hz	---
			99999	Off
01-31 P.165	Output voltage 3 of middle frequency	0.0%	0 ~ 100.0%	---
01-32 P.166	Middle frequency 4	99999	0 ~ 599.00Hz	---
			99999	Off
01-33 P.167	Output voltage 4 of middle frequency	0.0%	0 ~ 100.0%	---
01-34 P.168	Middle frequency 5	99999	0 ~ 599.00Hz	---
			99999	Off
01-35 P.169	Output voltage 5 of middle frequency	0.0%	0 ~ 100.0%	---

Setting
---------

Middle frequency, output voltage of middle frequency

◆ Please refer to the description for 01-12(P.14)=4 in Section 5.2.6 Load pattern selection.


### 5.2.12 S pattern time

➤ It is used to set the acceleration time of S pattern acceleration/deceleration.

Parameter	Name	Default	Setting Range	Content
01-36 P.255	S curve time at the beginning of acceleration	0.20s	0 ~ 25.00s/ 0 ~ 250.0s	01-08(P.21)=0/ 01-08(P.21)=1
01-37 P.256	S curve time at the end of acceleration	99999	0 ~ 25.00s/ 0 ~ 250.0s	01-08(P.21)=0/ 01-08(P.21)=1
			99999	Not selected.
01-38 P.257	S curve time at the beginning of deceleration	99999	0 ~ 25.00s/ 0 ~ 250.0s	01-08(P.21)=0/ 01-08(P.21)=1
			99999	Not selected.
01-39 P.258	S curve time at the end of deceleration	99999	0 ~ 25.00s/ 0 ~ 250.0s	01-08(P.21)=0/ 01-08(P.21)=1
			99999	Not selected.


#### Setting S pattern time

◆ When 01-05(P.29) = 3, "S pattern acceleration /deceleration curve 3".



- Parameters 01-36(P.255), 01-37(P.256), 01-38(P.257) and 01-39(P.258) are used to start inverter gradually without impact. And adjust the value to vary degrees of S shape acceleration / deceleration curve. When the S shape acceleration / deceleration curve is started, the inverter will accelerate/decelerate with different speed according to the primary acceleration/deceleration time.
- When S shape acceleration/deceleration curve 3 is selected, the acceleration/ deceleration time will be longer, as follows
- When the selected acceleration time (01-06(P.7) or 01-22(P.44)) $\geq$ 01-36(P.255) and 01-37(P.256), the actual acceleration time is as follows:  
Actual acceleration time = the selected acceleration time +(01-36(P.255) + 01-37(P.256))/ 2
- When the selected deceleration time (01-07(P.8) or 01-23(P.45)) $\geq$ 01-38(P.257) and 01-39(P.258), the actual deceleration time is as follows:  
Actual deceleration time = the selected deceleration time +(01-38(P.257) + 01-39(P.258))/ 2

Example: when the parameters are in default value (60 Hz system), the actual acceleration time from stop state to 60Hz in accordance with S shape acceleration/deceleration curve 3 is as follows:



Set acceleration time  $T1 = (01-09(P.20) - 01-11(P.13)) * 01-06(P.7) / 01-09(P.20)$

Actual acceleration time  $T2 = T1 + (01-36(P.255) + 01-37(P.256)) * (01-09(P.20) - 01-11(P.13)) / 2 / 01-09(P.20)$

So  $T1 = (60 - 0.5) * 5 / 60 = 4.96s$  (the actual acceleration time of linear acceleration)

Actual acceleration time  $T2 = 4.96 + (0.2 + 0.2) * (60 - 0.5) / 2 / 60 = 5.16s$

Note: All calculations of acceleration/deceleration time are based on 01-09 (P.20).

## 5.2.13 Remote function acc/dec time selection

- Used to select the remote control function RM, RH to modify the acceleration and deceleration time of the remote control frequency.

Parameter	Name	Default	Setting Range	Content
01-40	Remote function	0	0	Use default acc/dec time ( same as regular mode )
P.219	acc/dec time selection		1	Use second acc/dec time



Remote control frequency acceleration and deceleration time selection

01-40 (P.219) = 0, the acceleration and deceleration time of the remote control frequency is the current acceleration and deceleration time (the same as the acceleration and deceleration time of the output frequency);

- ◆ When 01-40 ( P.219 ) = 1,

If 01-22 ( P.44 ) ≠ 99999 , 01-23 ( P.45 ) = 99999 , The acceleration time and deceleration of the remote control frequency are both "01-22 (P.44) set value" ;

If 01-22 ( P.44 ) ≠ 99999 , 01-23 ( P.45 ) ≠ 99999 , The acceleration time of the remote control frequency is "01-22 (P.44) setting value", and the deceleration time is "01-23 (P.45) setting value" ;

If 01-22 ( P.44 ) = 99999 , the acceleration and deceleration time of the remote control frequency is the current acceleration and deceleration time (the same as the acceleration and deceleration time of the output frequency)

## 5.3 Analog input and output parameter group 02

Group	Parameter Number	Name	Setting Range	Default	Page
02-06	P.185	Proportional linkage gain	0 ~ 100%	0%	77
02-07	P.240	Auxiliary frequency	0: Off	0	78
			2: Output frequency = basic frequency + auxiliary frequency (given by terminal 3-5)		
			4: Output frequency = basic frequency - auxiliary frequency (given by terminal 3-5)		
			6: Output frequency = proportional linkage signal (given by terminal 3-5)		
02-10	P.60	Terminal 3-5 filter time	0 ~ 2000ms	31ms	79
02-20	P.17	Terminal 3-5 signal range selection	0: Signal sampling range from 4~20mA.	1	79
			1: Signal sampling range from 0 ~ 10V.		
			2: Signal sampling range from 0 ~ 5V.		
02-21	P.39	Maximum operation frequency ( Terminal 3-5 input / built-in keypad knob )	50 Hz system:1.00 ~ 599.00Hz	50.00Hz	79
			60 Hz system:1.00 ~ 599.00Hz	60.00Hz	
02-24	P.184	Terminal 3-5 disconnect selection	0: Off	0	79
			1: Inverter decelerates to 0Hz, multi-function digital output terminal set off alarm		
			2: Inverter stops immediately, and keypad displays "AErr" alarm		
			3: Inverter runs continuously according to the frequency command before disconnection. Digital output terminal will set off alarm.		
02-25	P.198	Terminal 3-5 minimum input current/ voltage	0 ~ 20.00 mA /V	0.00V	79
02-26	P.199	Terminal 3-5 maximum input current/ voltage	0 ~ 20.00 mA/V	10.00V	79
02-27	P.196	Percentage corresponds to terminal 3-5 minimum input current/ voltage	0% ~ 100.0%	0.0%	79
02-28	P.197	Percentage corresponds to terminal 3-5 maximum input current/ voltage	0% ~ 100.0%	100.0%	79
02-52	P.56	Inverter rated current display level	0~500.00A	According to model	84
02-61	P.141	Polarity of percentage corresponds to terminal 3-5 current/ voltage signal	0~11	0	79
02-62	P.76	Keypad knob on inverter minimum value	0.00~599.00 Hz	0.00Hz	79
02-63	P.204	PWM signal duty cycle	0: automatically detects the period of input PWM pulse	0	84
			1~1000ms: set the PWM duty cycle value input into terminal STF		


### 5.3.1 Proportional linkage gain

- This function is used to multiply frequency command from external analog input terminal. When multiple inverters are running in proportion, it is effective to use this function to fine-tune the frequency command from master inverter to slave inverter.

Parameter	Name	Default	Setting Range	Content
02-06 P.185	Proportional linkage gain	0%	0 ~ 100%	---

**Setting** Proportional linkage gain

- ◆ When output frequency is lower than 01-01(P.2), it is equal to lower limit frequency 01-01(P.2). When output frequency is higher than 01-00(P.1), it is equal to upper limit frequency 01-00(P.1).
- ◆ After multiplying the setting frequency by 02-06(P.185) value, add and subtract can be performed as follows:  
For example: When the setting frequency is 50Hz, 02-06(P.185)=50% and the external analog input signal is 0~10V.



In the above figure, when 0V is given, the target frequency is  $50\text{Hz} - (50\text{Hz} \times 50\%) = 25\text{Hz}$ ;

when 5V is given, the target frequency is  $50\text{Hz} - (50\text{Hz} \times 0\%) = 50\text{Hz}$ ;

when 10V is given, the target frequency is  $50\text{Hz} + (50\text{Hz} \times 50\%) = 75\text{Hz}$ .

Note: 1. For proportional linkage signal input, please refer to the description of parameter 02-07 (P.240).  
2. When use terminal 3-5 analog (voltage/current) signal as proportional linkage signal input terminal, please refer to parameter 02-20(P.17) ; for the setting of external analog signal frequency range, please refer to parameter 02-21(P.39).



### 5.3.2 Auxiliary frequency

- Frequency can be adjusted and synthesized flexibly to meet the different control requirements in different scenarios.

Parameter	Name	Default	Setting Range	Content
02-07 P.240	Auxiliary frequency	0	0	Off
			2	Output frequency = basic frequency + auxiliary frequency (given by terminal 3-5)
			4	Output frequency = basic frequency - auxiliary frequency (given by terminal 3-5)
			6	Output frequency = proportional linkage signal (given by terminal 3-5)

**Setting** Auxiliary frequency

- ◆ When output frequency is lower than 01-01(P.2), it equals to lower limit frequency 01-01(P.2). When output frequency is higher than 01-00(P.1), it equals to upper limit frequency 01-00(P.1).

Note: 1. Basic frequency command is given by keypad, communication or multi-speed terminal.  
 2. For proportional linkage signals, please refer to the description of parameter 02-06(P.185).  
 3. When use terminal 3-5 analog (voltage/current) signal as proportional linkage signal input terminal, please refer to parameter 02-20(P.17). For the setting of external analog signal frequency range, please refer to parameter 02-21(P.39).

### 5.3.3 Terminal 3-5 signal selection and processing


➤ Select terminal 3-5 signal specification and frequency compensation function.

Parameter	Name	Default	Setting Range	Content
02-10 P.60	Terminal 3-5 filter time	31ms	0 ~ 2000ms	---
02-20 P.17	Terminal 3-5 signal range selection	1	0	Signal sampling range from 4~20mA.
			1	Signal sampling range from 0 ~ 10V.
			2	Signal sampling range from 0 ~ 5V.
02-21 P.39	Maximum operation frequency (Terminal 3-5 input / built-in keypad knob)	50.00Hz	1.00 ~ 599.00Hz	50Hz system (00-24(P.189)=1)
		60.00Hz		60Hz system (00-24(P.189)=0)
02-24 P.184	Terminal 3-5 disconnect selection	0	0	Off
			1	Inverter decelerates to 0Hz, multi-function digital output terminal set off alarm
			2	Inverter stops immediately, and keypad displays "AErr" alarm
			3	Inverter runs continuously according to the frequency command before disconnection. Digital output terminal will set off alarm.
02-25 P.198	Terminal 3-5 minimum input current/ voltage	0.00V	0 ~ 20.00mA/V	---
02-26 P.199	Terminal 3-5 maximum input current/ voltage	10.00V	0 ~ 20.00mA/V	---
02-27 P.196	Percentage corresponds to terminal 3-5 minimum input current/ voltage	0.0%	0% ~ 100.0%	---
02-28 P.197	Percentage corresponds to terminal 3-5 maximum input current/ voltage	100.0%	0% ~ 100.0%	---
02-61 P.141	Polarity of percentage corresponds to terminal 3-5 current/ voltage signal	0	0~11	---
02-62 P.76	Keypad knob on inverter minimum value	0.00Hz	0.00~599.00 Hz	




Terminal 3-5 signal selection, maximum input, Keypad knob maximum input

- ◆ The setting value of 02-21 (P.39) is the target frequency value of the inverter when the input signal of terminal 3-5 is at 20mA (5V/10V) or the knob of the inverter is turned to the maximum.




- ◆ When using the VR knob on built-in keypad to set frequency, if want to set frequency not 0Hz when the knob is turned to the minimum value, set 02-62 (P.76).  
For example: need frequency to be 10Hz when the knob is turned to the minimum value, set 02-62(P.76)=10.00 Hz, then the setting range of the target frequency when the knob is turned is 10.00Hz~02-21 (P.39) setting value, as shown in the figure below:



**Setting** Terminal 3-5 input signal processing


- ◆ Parameters above define the relationship between analog input voltage and set value in analog input. When analog input voltage exceeds maximum or minimum range of the set value, the excess part will be calculated as maximum and minimum input.
- ◆ There are two setting steps when setting maximum and minimum percentage:
  - 1) If users want to adjust the analog input to correspond with a certain type of proportional relationship, Adjust the analog input first and then set the corresponding proportional parameter. Inverter will calculate it by itself, don't need to set the voltage parameter (refer to Example 1.1).
  - 2) If users skip the adjustment of analog input and set proportional relationship directly, first set proportional parameter then set voltage parameters (refer to the example 1.2).

Example 1.1: User adjusts analog input voltage to minimum value A and sets parameter 02-27(P.196) adjusts input voltage to maximum value B, and sets parameter 02-28(P.197) . As shown below:



## Analog input and output parameter group 02


Example 1.2: Set 02-27(P.196) and 02-28(P.197) value, then set 02-25(P.198) and 02-26(P.199). Figure is shown as follows:



If the external analog frequency is selected, the ratio calculated according to the figure above is multiplied by 02-21 (P.39) to be the actual frequency input value ( terminal 3-5 current/voltage input corresponding percentage selections are all positive 02-61( P.141) = 0).

**Setting** Polarity of percentage corresponds to terminal 3-5 current/ voltage signal


◆ The setting of parameter 02-61 (P.141) is set in bits, a total of 2 bits, the meaning of each bit is as follows:




If the input percentage of the given current/voltage is negative, the inverter runs in the reverse direction of the given running direction.

✓ Some application examples of terminal 3-5


Example 1: This example is the most commonly used method. It is used when inverter is in “external mode”, “combined mode 2” or “combined mode 4”, and frequency command is given by terminal 3-5.




Example 2: This example is for users who need the motor to run at 10Hz when the potentiometer is turned to the left end. All frequencies above 10Hz can still be adjusted by the user freely.




Example 3: This example is also frequently used by the industry. The comprehensive usage for all domain of the potentiometer setup elevates the flexibility.




Example 4: This example uses 0~5V to give frequency command.




Example 5: This example is used to avoid signal below 1V given to inverter as *running* frequency in harsh environment, which can greatly avoid the interference of noise.




Example 6: This example is an extension of Example 5. This kind of application is open, user can apply flexibly.



Example 7: This example is an application of inverse slope setting. The industry often uses sensors for pressure, temperature or flow control. Some of the sensors output 10V signal at high voltage or high flow. This signal acts as a reference for the AC motor drive to decelerate or to stop. The setup presented in Example 7 can satisfy this type of application.



Example 8: This example integrates all the application of potentiometer. Together with the application of forward and reverse rotation, it fits in the system easily for complicated application.



- Note: 1. In the "external mode" or "combined mode 2" or "combined mode 4", the target frequency of the inverter is determined by the 3-5 terminal signal.
2. In "external mode" or "combined mode 2" or "combined mode 4", if any of RH, RM, RL or REX is "on", at the same time, the target frequency of the inverter will be given priority to multi-speed.
3. The RH, RM, RL, and REX mentioned in this paragraph are the function names of "multi-function digital input terminals". For the function selection and function of the multi-function digital input terminal, please refer to 03-00 (P.83), 03-01 (P.84), 03-03 (P.80), 03-04 (P.81); For wiring, please refer to section 3.7.
4. Terminal 3-5 analog signal can be given either voltage or current, which is determined by 02-20 (P.17) and AVI-ACI switch function.

## ◆ Terminal 3-5 disconnect function

- 1) If 02-24(P.184) = 0, after disconnection, inverter will slow down to 0Hz, and after reconnection, the inverter will accelerate to current given frequency.
- 2) If 02-24(P.184) = 1 after disconnection, inverter will slow down to 0Hz and at the same time multi-function digital output terminal will set off an alarm; after reconnection, alarm will be released and the inverter will accelerate to the current given frequency.
- 3) If 02-24(P.184) = 2 after disconnection, the keypad will display "AEr" alarm, inverter will stop immediately, and reset is required to release the alarm.
- 4) If 02-24(P.184) = 3, after disconnection, the inverter will continue to run according to the frequency command before disconnection, the multi-function digital output terminal will set off an alarm, which will be released after reconnection.

Note: When 02-20(P.17)=1, 2, terminal 3-5 is voltage signal setting, this disconnection function will be invalid.

## ◆ Terminal 3-5 current/voltage input

Terminal 3-5 cannot receive negative voltage and the minimum input is 4mA when selecting current input.

Note: The function of terminal 3-5 here must first switch AVI-ACI to the corresponding position and make sure it matches the setting value of 02-20 (P.17).

## 5.3.4 Inverter rated current display level

Parameter	Name	Default	Setting Range	Content
02-52 P.56	Inverter rated current display level	Note	0 ~ 500.00A	---

**Setting** Display level

- ◆ Used for inverter current output display.

Note: The default value of parameter 02-52 (P.56) is determined by the model.

## 5.3.5 PWM signal duty cycle

- This parameter is used to set the period of the PWM signal input to the STF terminal.

Parameter	Name	Default	Setting Range	Content
02-63 P.204	PWM signal duty cycle	0	0	Automatically detects the period of PWM pulse input into terminal STF
			1~1000ms	1~1000ms: Set the PWM duty cycle value input into terminal STF

**Setting** PWM signal duty cycle

1. When 02-63 (P.204) is set to 0, SL3 automatically detects the period of PWM signal input to terminal STF.
2. When 02-63 (P.204) is set to a value other than 0, when the period of PWM signal that actually input to terminal STF is not the same as 02-63 (P.204) value, it will cause an error in the output frequency calculation.
3. The PWM signal reference frequency function is only applicable to terminal STF (03-00 (P.83) needs to be set to 41). For details, refer to chapter 5.4.1.

## 5.4 Digital input/ output parameter group 03

Group	Parameter Number	Name	Setting Range	Default	Page
03-00	P.83	Terminal STF input function	0: STF(Inverter runs forward)	0	89
			1: STR(Inverter runs reverse)		
			2: RL(Multi-speed low speed)		
			3: RM(Multi-speed medium speed)		
			4: RH(Multi-speed high speed)		
			5: Reserved		
			6: External thermal relay actuate		
			7: MRS(Stops inverter output immediately)		
			8: RT(Inverter second function)		
			9: EXT(External JOG)		
			10 : STF+EXJ		
			11 : STR+EXJ		
			12 : STF+RT		
			13 : STR+RT		
			14 : STF+RL		
			15 : STR+RL		
			16 : STF+RM		
			17 : STR+RM		
			18 : STF+RH		
			19 : STR+RH		
			20 : STF+RL+RM		
			21 : STR+RL+RM		
			22 : STF+RT+RL		
			23 : STR+RT+RL		
			24 : STF+RT+RM		
			25 : STR+RT+RM		
			26 : STF+RT+RL+RM		
			27 : STR+RT+RL+RM		
			28: RUN(Inverter runs forward)		
			29: STF/STR(use with RUN signal, when ON, motor runs reverse ; when OFF, motor runs forward)		
			30: RES(External reset function)		
			31: STOP(Use as three line control with RUN signal and STF-STR signal)		
			32: REX(Extend multi-speed to 16 levels)		
			33: PO(In "external mode", run programmed operation)		
			34: RES_E (External reset, valid only when alarm.)		
			35: MPO (In "external mode" run manual cycle operation.)		
			36: TRI(Triangle wave function)		



Group	Parameter Number	Name	Setting Range	Default	Page
03-00	P.83	Terminal STF input function	37~38 : Reserved	0	89
			39: STF/STR +STOP (Use with RUN signal, when ON, motor runs reverse, when OFF, motor stops then runs forward.)		
			40: P_MRS (Stops inverter output immediately by pulse signal input)		
			41: PWM set frequency (Only valid with terminal STF and parameter 03-00(P.83))		
			42 : Reserved		
			43: RUN_EN (Enable digital input terminal operation)		
			44: PID_OFF (Enable digital input terminal turning off PID)		
			45: Second frequency command source mode		
03-01	P.84	Terminal STR input function	Same as 03-00	1	89
03-03	P.80	Terminal M0 input function	Same as 03-00	2	89
03-04	P.81	Terminal M1 input function	Same as 03-00	3	89
03-11	P.85	Terminal A-C output function	0: RUN(Output when inverter running)	5	92
			1: SU(Output when reach target frequency)		
			2: FU(Output when reach 03-21 03-22 value )		
			3: OL(Output when overload)		
			4: OMD(Output when output current is zero)		
			5: ALARM(Output when alarm)		
			6: PO1(Output when in program operation step)		
			7: PO2(Output when in program operation cycle)		
			8: PO3(Output when in program operation pause)		
			9~10 : Reserved		
			11 : OMD1(Output when output current is zero 1)		
			12 : OL2(Output when over torque)		
			13 ~ 16 : Reserved		
			17: RY(Output when inverter is powered on and no alarm)		
18: Output when it's time for maintenance					
41: Output when PID feedback signal disconnect					
03-14	P.87	Digital input logic	0 ~ 15	0	93
03-15	P.88	Digital output logic	0 : Terminal A-C output positive logic	0	93
			2 : Terminal A-C output negative logic		
03-16	P.120	Output signal delay time	0 ~ 3600.0s	0.0s	94
03-17	P.157	Digital input terminal filter time	0 ~ 2000	4	94

Digital input/ output parameter group 03

Group	Parameter Number	Name	Setting Range	Default	Page
03-18	P.158	Digital input terminal enable when power on	0: When power on digital terminals work directly	0	95
			1: When power on digital terminals work after switch off then on		
03-20	P.41	Output frequency detection sensitivity	0 ~ 100.0%	10.0%	95
03-21	P.42	Output frequency detection for forward rotation	0 ~ 599.00Hz	6.00Hz	95
03-22	P.43	Output frequency detection for reverse rotation	0 ~ 599.00Hz	99999	95
			99999: Same as the setting of 03-21(P.42)		
03-23	P.62	Zero current detection level	0 ~ 200.0%	5.0%	96
			99999: Off		
03-24	P.63	Zero current detection time	0.05 ~ 100.00s	0.50s	96
			99999: Off		

## 5.4.1 Digital input terminals function selection

- Use the following parameters to change the digital input terminal functions. Each terminal may choose any function between 0 ~ 45 (Note 1)

Parameter	Name	Default	Setting Range	Content
03-00 P.83	Terminal STF input function	0	0	STF(Inverter runs forward)
			1	STR(Inverter runs reverse)
			2	RL(Multi-speed low speed)
			3	RM(Multi-speed medium speed)
			4	RH(Multi-speed high speed)
			5	Reserved
			6	External thermal relay actuate
			7	MRS(Stops inverter output immediately)
			8	RT(Inverter second function)
			9	EXT(External JOG)
			10	STF+EXJ
			11	STR+EXJ
			12	STF+RT
			13	STR+RT
			14	STF+RL
			15	STR+RL
			16	STF+RM
			17	STR+RM
			18	STF+RH
			19	STR+RH
			20	STF+RL+RM
			21	STR+RL+RM
			22	STF+RT+RL
			23	STR+RT+RL
			24	STF+RT+RM
			25	STR+RT+RM
			26	STF+RT+RL+RM
			27	STR+RT+RL+RM
			28	RUN(Inverter runs forward)
			29	STF/STR(use with RUN signal, when ON, motor runs reverse ; when OFF, motor runs forward)
			30	RES(External reset function)
			31	STOP(Use as three line control with RUN signal and STF-STR signal)
			32	REX(Extend multi-speed to 16 levels)
			33	PO(In "external mode", run programmed operation)
			34	RES_E (External reset, valid only when alarm.)
35	MPO (In "external mode" run manual cycle operation.)			

## Digital input/ output parameter group 03

Parameter	Name	Default	Setting Range	Content
03-00 P.83	Terminal STF input function	0	36	TRI(Triangle wave function)
			37	Reserved
			38	Reserved
			39	STF/STR +STOP (Use with RUN signal, when ON, motor runs reverse, when OFF, motor stops then runs forward.)
			40	P_MRS (Stops inverter output immediately by pulse signal input)
			41	PWM set frequency (Only valid with terminal STF and parameter 03-00(P.83))
			42	Reserved
			43	RUN_EN (Enable digital input terminal operation)
			44	PID_OFF (Enable digital input terminal turning off PID)
			45	Second frequency command source mode
03-01 P.84	Terminal STR input function	1	Same as 03-00	Same as 03-00
03-03 P.80	Terminal M0 input function	2	Same as 03-00	Same as 03-00
03-04 P.81	Terminal M1 input function	3	Same as 03-00	Same as 03-00



### Digital input terminals function selection

- ◆ At default, 03-03(P.80)=2 ( RL ), 03-04(P.81)=3 ( RM ), 03-00(P.83)=0 ( STF ), 03-01(P.84)=1 ( STR ) .
- ◆ Changing 03-01(P.84)、03-03(P.80) settings change the function of the terminals. For example, 03-03(P.80)=2 means that M0 terminal acts as RL. If 03-03(P.80) is set to 8, M0 terminal function will change to RT, which will act as “second function”. Another example, 03-00(P.83)=0 means that STF terminal serves as “inverter runs forward” function, and if change 03-00(P.83) to 6, STF terminal function will change to OH, which will serve as the input terminal of external thermal relay.


- ◆ Set value:6 OH(External thermal relay):

Old motors usually come with thermal relay attached to the front of the motor to prevent motor from overheating. When external thermal relay actuate, inverter will alarm and show “OHT”.

- ◆ Four different wiring techniques (1 means ON, 0 means Off, and X = 0 , 1 , 3 , 4 )


1) Two-wire control mode 1:

K0	K1	Run command
0	0	Stop
1	0	Forward
0	1	Reverse
1	1	Stop




2) Two-wire control mode 2:


K0	K1	Run command
0	0	Stop
0	1	Stop
1	0	Forward
1	1	Reverse



3) Three-wire control mode 1 (with seal-in function): K0 is STOP, normal close. When trigger inverter will stop. K1 is forward and K2 is reverse, normal open. All K0 K1 K2 are edge trigger button.



4) Three-wire control mode 2 (with seal-in function): K1 is STOP, normal close. When trigger inverter will stop. K2 is RUN, normal open. K1 K2 are edge trigger buttons. Change direction by STF/STR terminal, set value: 39. When changing the direction, stop the inverter first, then switch K0 state and start inverter again.



◆ Set value: 33 PO(programmed operation):


When in external mode and PO is ON, inverter will be in programmed operation mode. Terminal STF is start. When STF is ON, inverter run programmed operation mode at the first section. When STF is OFF, inverter stop. Terminal STR is pause. When STR is ON, pause the operation. When STR is OFF, operation continues from section before pausing. For details, please refer to 04-15 (P.100), 04-27~04-42 (P.101~P.118), 04-16~04-18 (P.121~P.123), 04-19~04-26(P.131~P.138).

◆ Set value: 35 MPO(manual programmed operation):

In external mode, when MPO is “on” run manual cycle operation. For details, please refer to 04-19~04-26 (P.131~P.138).

◆ Set value: 41 (PWM setting frequency):

Inverter measures and calculates ON time and OFF time in each PWM cycle, use it as its frequency command. When the period of PWM signal that actually input to terminal STF is not the same as 02-63 (P.204) value, it will cause an error in the output frequency calculation. (The allowable PWM signal cycle is within 1ms~1000ms) (Note 1).



$$\text{Frequency command ( Hz )} = \frac{\text{ON time}}{\text{PWM cycle}} \times \text{Maximum frequency 01-00(P.1) (Hz)}$$

◆ Set value : 45 Second mode


When this terminal is on, target frequency is set by 00-17(P.97)。

Note1: 1. The set value "41" is only available for terminal STF. For the description of the input PWM signal cycle, please refer to chapter 5.3.5.

## 5.4.2 Digital output terminals function selection

➤ Detect some information that occurs during the operation of the inverter.

Parameter	Name	Default	Setting Range	Content
03-11 P.85	Terminal A-C output function	5	0	RUN(Output when inverter running): Output signal when inverter run above starting frequency
			1	SU(Output when reach target frequency): Output signal when the output frequency reaches target frequency
			2	FU ( Output when reach certain frequency ) : Output signal when detecting operation above specified frequency
			3	OL ( Output when overload ) : Output signal when current limit function is activated
			4	OMD ( Output when output current is zero ) : When the output current of the inverter is lower than the set value in 03-23 (P.62) for a period of time (03-24 (P.63)), OMD will output a signal
			5	ALARM ( Output when alarm )
			6	PO1 ( Output when in program operation step )
			7	PO2 ( Output when in program operation cycle )
			8	PO3 ( Output when in program operation pause )
			9	Reserved
			10	Reserved
			11	OMD1(Output when output current is zero 1) : When the output frequency of the inverter reaches the target frequency and the output current is lower than the setting value in 03-23 (P.62) for a period of time (setting of 03-24 (P.63)), OMD1 will output a signal
			12	OL2(Output when over torque) : If 06-10 (P.260)=1, when the over-torque signal is output, inverter will alarm OL2 and stop running; if 06-10 (P.260)=0, when the over-torque signal is output, the inverter will not alarm OL2 and continues to run.
			13 ~ 16	Reserved
17	RY(Output when inverter is powered on and no alarm)			
18	Output when it's time for maintenance			
41	Output when PID feedback signal disconnect			


**Setting**

## Digital output terminals function selection

- ◆ Terminal A-C default value (03-11(P.85)) is 5 which means "ALARM". If 03-11(P.85) value is changed, terminal function will change as shown in table above.

### 5.4.3 Terminal logic selection

- The function is bits-setting, if the bit shows 1, it means that the action of multi-function digital input terminal is negative logic; otherwise, it means that the action is positive logic.

Parameter	Name	Default	Setting Range	Content
03-14 P.87	Digital input logic	0	0 ~ 15	---
03-15 P.88	Digital output logic	0	0	Terminal A-C output positive logic
			2	Terminal A-C output negative logic

#### Setting Digital input/output logic

- ◆ The definition of each bit of 03-14(P.87) is as follows:

bit	$2^3$	$2^2$	$2^1$	$2^0$
	M1	M0	STR	STF

For example: A three-wire control type needs the function of STOP to be kept open (negative logic). So if set 03-03(P.80)=31, take M0 terminal as three-wire control STOP function, and 03-03(P.80)=0, 03-01(P.84)=1, and take STF and STR terminals as default positive/negative logic function, the parameter of 03-14(P.87) should be set as follows:

bit	$2^3$	$2^2$	$2^1$	$2^0$
	0	1	0	0

$$\text{So } (03-14)P.87 = 0 \times 2^3 + 1 \times 2^2 + 0 \times 2^1 + 0 \times 2^0 = 4$$

- ◆ The usage of 03-15(P.88) :

For example: 03-11(P.85)=0 (inverter is running and detecting), if set 03-15(P.88) to 0 (positive logic), when inverter runs, multi-relay is on. When inverter stops, multi-relay is off; if set 03-15(P.88) to 2 (negative logic), when inverter runs, multi-relay is off, and when the inverter stops, multi-relay is on.

Note: When “STF” and “STR” terminals are set as negative logic, but signal is not connected with SD, with power on, inverter will output and drive motor. So it is dangerous, please pay attention to it.



#### 5.4.4 Digital output signal delay

- This parameter is used to delay and confirm the digital output signal. Delay time acts like confirmation time, which can prevent some unknown interference.

Parameter	Name	Default	Setting Range	Content
03-16 P.120	Output signal delay time	0.0s	0 ~ 3600.0s	---

**Setting** Output signal delay

- ◆ When set 03-16(P.120)=0 and condition from 03-11 (P.85) is met, signal will output directly.
- ◆ When set 03-16(P.120) = 0.1~3600 and condition from 03-11 (P.85) is met, signal will output after delay time.

#### 5.4.5 Digital input signal filter

- This parameter is used to set response time for digital input signals.

Parameter	Name	Default	Setting Range	Content
03-17 P.157	Digital input terminal filter time	4	0 ~ 2000	---

**Setting** Digital input terminal filter

- ◆ 03-17 (P.157) is used to select the response time of the digital input terminal signal, the terminal includes: STR, STF, M0, M1. The actual delay time is 03-17(P.157)\*2ms, for example, when 03-17(P.157)=100, the actual delay time is 200ms.

#### 5.4.6 Digital input terminal enable when power on

- Choose when power on if digital input terminal operates immediately.

Parameter	Name	Default	Setting Range	Content
03-18 P.158	Digital input terminal enable when power on	0	0	When power on digital terminals work directly
			1	When power on digital terminals work after switch off then on

**Setting** Digital input terminal enable when power on

- ◆ If 03-18(P.158)=1, when terminal function STF, STR, RUN and MPO is already short before power on, after power on inverter will not run immediately, inverter will run only after switch off then on these terminals. If 03-18(P.158)=0, when terminal function STF, STR, RUN and MPO is already short before power on, after power on inverter will run immediately


### 5.4.7 Output frequency detection

➤ Detects the inverter output frequency and output signal.

Parameter	Name	Default	Setting Range	Content
03-20 P.41	Output frequency detection sensitivity	10.0%	0 ~ 100.0%	---
03-21 P.42	Output frequency detection for forward rotation	6.00Hz	0 ~ 599.00Hz	---
03-22 P.43	Output frequency detection for reverse rotation	99999	0 ~ 599.00Hz	---
			99999	Same setting as 03-21(P.42).


**Setting** Output frequency detection range

- ◆ If 03-20(P.41)=5%, SU signal will be output when output frequency falls within “5% range around target frequency”. For example, the target frequency is set to 60Hz and 03-20(P.41)=5%, then when output frequency falls within the range of  $60 \pm 60 \times 5\% = 57\text{Hz} \sim 63\text{Hz}$ , SU signal will be output.



**Setting** Forward/Reverse rotation output frequency detection

- ◆ If 03-21(P.42)=30 and 03-22(P.43)=20, FU signal will output when forward rotation frequency exceeds 30Hz; and when reverse rotation frequency exceeds 20Hz, FU signal will also be output.
- ◆ If 03-21(P.42)=30 and 03-22(P.43)=99999 (default), FU signal will output when forward and reverse rotation frequency exceed 30Hz.



Note: SU and FU mentioned in this paragraph are the function names for digital output. Please refer to 03-11(P.85) for details, and section 3.7 for relevant wiring.

## 5.4.8 Zero current detection


- Detects output current level and send signal to digital output terminal.

Parameter	Name	Default	Setting Range	Content
03-23 P.62	Zero current detection	5.0%	0 ~ 200.0%	---
	level		99999	Off
03-24 P.63	Zero current detection	0.50s	0.05 ~ 100.00s	---
	time		99999	Off

## Setting

Zero current detection

- ◆ Assume inverter is fully loaded at rated value and current is 20A, set 03-23(P.62)=5% and 03-24(P.63)=0.5s, terminal function OMD will output signal when output current is less than  $20 \times 5\% = 1A$  and exceeds 0.5s, as shown below figure:



- ◆ If set 03-23(P.62) or 03-24(P.63) to 99999, zero current detection function is off.

Note: In this paragraph, OMD mentioned in this paragraph are the function names for digital output. Please refer to 03-11(P.85) for details, and section 3.7 for relevant wiring.

## 5.5 Multi-speed parameter group 04

Group	Parameter Number	Name	Setting Range	Default	Page
04-00	P.4	Speed 1 (high speed)	0 ~ 599.00Hz	60.00Hz	99
04-01	P.5	Speed 2 (medium speed)	0 ~ 599.00Hz	30.00Hz	99
04-02	P.6	Speed 3 (low speed)	0 ~ 599.00Hz	10.00Hz	99
04-03	P.24	Speed 4	0 ~ 599.00Hz	99999	99
			99999: Off		
04-04	P.25	Speed 5	Same as 04-03	99999	99
04-05	P.26	Speed 6	Same as 04-03	99999	99
04-06	P.27	Speed 7	Same as 04-03	99999	99
04-07	P.142	Speed 8	0 ~ 599.00Hz	0.00Hz	99
04-08	P.143	Speed 9	Same as 04-03	99999	99
04-09	P.144	Speed 10	Same as 04-03	99999	99
04-10	P.145	Speed 11	Same as 04-03	99999	99
04-11	P.146	Speed 12	Same as 04-03	99999	99
04-12	P.147	Speed 13	Same as 04-03	99999	99
04-13	P.148	Speed 14	Same as 04-03	99999	99
04-14	P.149	Speed 15	Same as 04-03	99999	99
04-15	P.100	Programmed operation minute / second selection	0: Select minute as the time increment.	1	101
			1: Select second as the time increment.		
04-16	P.121	Run direction in each section	0 ~ 255	0	101
04-17	P.122	Programmed operation cycle selection	0:Off	0	101
			1 ~ 8: Start cycle from the set section.		
04-18	P.123	Programmed operation acceleration / deceleration time setting selection	0: Acceleration time is 01-06(P.7), deceleration time is 01-07(P.8).	0	101
			1: Acceleration and deceleration time is set by 04-35(P.111) ~ 04-42(P.118).		
04-19	P.131	Programmed operation mode speed 1	0 ~ 599.00Hz	0.00 Hz	101
04-20	P.132	Programmed operation mode speed 2	0 ~ 599.00Hz	0.00 Hz	101
04-21	P.133	Programmed operation mode speed 3	0 ~ 599.00Hz	0.00 Hz	101
04-22	P.134	Programmed operation mode speed 4	0 ~ 599.00Hz	0.00 Hz	101
04-23	P.135	Programmed operation mode speed 5	0 ~ 599.00Hz	0.00 Hz	101
04-24	P.136	Programmed operation mode speed 6	0 ~ 599.00Hz	0.00 Hz	101
04-25	P.137	Programmed operation mode speed 7	0 ~ 599.00Hz	0.00 Hz	101

Group	Parameter Number	Name	Setting Range	Default	Page
04-26	P.138	Programmed operation mode speed 8	0 ~ 599.00Hz	0.00 Hz	101
04-27	P.101	Programmed operation mode speed 1 operating time	0 ~ 6000.0s	0.0s	101
04-28	P.102	Programmed operation mode speed 2 operating time	0 ~ 6000.0s	0.0s	101
04-29	P.103	Programmed operation mode speed 3 operating time	0 ~ 6000.0s	0.0s	101
04-30	P.104	Programmed operation mode speed 4 operating time	0 ~ 6000.0s	0.0s	101
04-31	P.105	Programmed operation mode speed 5 operating time	0 ~ 6000.0s	0.0s	101
04-32	P.106	Programmed operation mode speed 6 operating time	0 ~ 6000.0s	0.0s	101
04-33	P.107	Programmed operation mode speed 7 operating time	0 ~ 6000.0s	0.0s	101
04-34	P.108	Programmed operation mode speed 8 operating time	0 ~ 6000.0s	0.0s	102
04-35	P.111	Programmed operation mode speed 1 Acc/Dec time	0 ~ 600.00s/0 ~ 6000.0s	0.00s	102
04-36	P.112	Programmed operation mode speed 2 Acc/Dec time	0 ~ 600.00s/0 ~ 6000.0s	0.00s	102
04-37	P.113	Programmed operation mode speed 3 Acc/Dec time	0 ~ 600.00s/0 ~ 6000.0s	0.00s	102
04-38	P.114	Programmed operation mode speed 4 Acc/Dec time	0 ~ 600.00s/0 ~ 6000.0s	0.00s	102
04-39	P.115	Programmed operation mode speed 5 Acc/Dec time	0 ~ 600.00s/0 ~ 6000.0s	0.00s	102
04-40	P.116	Programmed operation mode speed 6 Acc/Dec time	0 ~ 600.00s/0 ~ 6000.0s	0.00s	102
04-41	P.117	Programmed operation mode speed 7 Acc/Dec time	0 ~ 600.00s/0 ~ 6000.0s	0.00s	102
04-42	P.118	Programmed operation mode speed 8 Acc/Dec time	0 ~ 600.00s/0 ~ 6000.0s	0.00s	102

## 5.5.1 16 steps speed


- With the combination of digital input terminal RL, RM, RH and REX, 16 steps speed can be selected (up to 16 speeds)

Parameter	Name	Default	Setting Range	Content
04-00 P.4	Speed 1 (high speed)	60.00Hz	0 ~ 599.00Hz	---
04-01 P.5	Speed 2 (medium speed)	30.00Hz	0 ~ 599.00Hz	---
04-02 P.6	Speed 3 (low speed)	10.00Hz	0 ~ 599.00Hz	---
04-03 P.24	Speed 4	99999	0 ~ 599.00Hz	99999: Off
			99999	
04-04 P.25	Speed 5	99999	Same as 04-03	Same as 04-03
04-05 P.26	Speed 6	99999	Same as 04-03	Same as 04-03
04-06 P.27	Speed 7	99999	Same as 04-03	Same as 04-03
04-07 P.142	Speed 8	0.00Hz	0 ~ 599.00Hz	---
04-08 P.143	Speed 9	99999	Same as 04-03	Same as 04-03
04-09 P.144	Speed 10	99999	Same as 04-03	Same as 04-03
04-10 P.145	Speed 11	99999	Same as 04-03	Same as 04-03
04-11 P.146	Speed 12	99999	Same as 04-03	Same as 04-03
04-12 P.147	Speed 13	99999	Same as 04-03	Same as 04-03
04-13 P.148	Speed 14	99999	Same as 04-03	Same as 04-03
04-14 P.149	Speed 15	99999	Same as 04-03	Same as 04-03

## Setting

16 steps speed

- ◆ If all the values of 04-03~04-06(P.24~P.27), 04-08~04-14(P.143~P.149) are not 99999, "16 steps speed" is active. It means with the combination of RL, RM, RH and REX, there are 16 speeds in total. To set target frequency for inverter, please refer to the figure below:



- ◆ When one of parameters 04-03~04-06(P.24~P.27), 04-08~04-14(P.143~P.149) value is 99999, the target frequency is determined by the speed of RL, RM and RH, which is shown as below (the priority of terminals is  $RL > RM > RH$ ):

Parameter \ Target frequency	04-03 (P.24) =99999	04-04 (P.25) =99999	04-05 (P.26) =99999	04-06 (P.27) =99999	04-08 (P.143) =99999	04-09 (P.144) =99999	04-10 (P.145) =99999	04-11 (P.146) =99999	04-12 (P.147) =99999	04-13 (P.148) =99999	04-14 (P.149) =99999
RL ( 04-02 )	○	○		○	○		○		○		○
RM ( 04-01 )			○			○				○	
RH ( 04-00 )								○			

For example, when 04-05(P.26) = 99999, the target frequency is determined by RM(the setting value of 04-01(P.5)).

Note: 1. Multi-speed is only valid in “external mode”, “combination mode 2” or “combined mode 4”.

2. RL, RM, RH and REX mentioned in this section are the function names of the “multi-function digital input terminal”. ( For example, when 03-03(P.80)=2, select the M0 terminal to perform the RL function ) Please refer to 03-00(P.83), 03-01(P.84), 03-03(P.80), 03-04(P.81) for function selection and purposes of the multi-function digital input terminal. For related wiring, please refer to Section 3.7.

## 5.5.2 Programmed operation mode

- The application of this parameter can be used as the operation process control for general small machinery, food processing machinery and washing equipment, which can replace some traditional relays, switches, timer and other control circuit, etc.

Parameter	Name	Default	Setting Range	Content
04-15 P.100	Programmed operation minute / second selection	1	0	Select minute as the time increment.
			1	Select second as the time increment.
04-16 P.121	Run direction in each section	0	0 ~ 255	---
04-17 P.122	Programmed operation cycle selection	0	0	Off
			1 ~ 8	Start cycle from the set section.
04-18 P.123	Programmed operation acceleration / deceleration time setting selection	0	0	Acceleration time is 01-06(P.7), deceleration time is 01-07(P.8).
			1	Acceleration and deceleration time is set by 04-35(P.111) ~ 04-42(P.118).
04-19 P.131	Programmed operation mode speed 1	0.00Hz	0 ~ 599.00Hz	---
04-20 P.132	Programmed operation mode speed 2	0.00Hz	0 ~ 599.00Hz	---
04-21 P.133	Programmed operation mode speed 3	0.00Hz	0 ~ 599.00Hz	---
04-22 P.134	Programmed operation mode speed 4	0.00Hz	0 ~ 599.00Hz	---
04-23 P.135	Programmed operation mode speed 5	0.00Hz	0 ~ 599.00Hz	---
04-24 P.136	Programmed operation mode speed 6	0.00Hz	0 ~ 599.00Hz	---
04-25 P.137	Programmed operation mode speed 7	0.00Hz	0 ~ 599.00Hz	---
04-26 P.138	Programmed operation mode speed 8	0.00Hz	0 ~ 599.00Hz	---
04-27 P.101	Programmed operation mode speed 1 operating time	0.0s	0 ~ 6000.0s	---
04-28 P.102	Programmed operation mode speed 2 operating time	0.0s	0 ~ 6000.0s	---
04-29 P.103	Programmed operation mode speed 3 operating time	0.0s	0 ~ 6000.0s	---
04-30 P.104	Programmed operation mode speed 4 operating time	0.0s	0 ~ 6000.0s	---
04-31 P.105	Programmed operation mode speed 5 operating time	0.0s	0 ~ 6000.0s	---
04-32 P.106	Programmed operation mode speed 6 operating time	0.0s	0 ~ 6000.0s	---




Parameter	Name	Default	Setting Range	Content
04-33 P.107	Programmed operation mode speed 7 operating time	0.0s	0 ~ 6000.0s	---
04-34 P.108	Programmed operation mode speed 8 operating time	0.0s	0 ~ 6000.0s	---
04-35 P.111	Programmed operation mode speed 1 Acc/Dec time	0.00s	0 ~ 600.00s/ 0 ~ 6000.0s	---
04-36 P.112	Programmed operation mode speed 2 Acc/Dec time	0.00s	0 ~ 600.00s/ 0 ~ 6000.0s	---
04-37 P.113	Programmed operation mode speed 3 Acc/Dec time	0.00s	0 ~ 600.00s/ 0 ~ 6000.0s	---
04-38 P.114	Programmed operation mode speed 4 Acc/Dec time	0.00s	0 ~ 600.00s/ 0 ~ 6000.0s	---
04-39 P.115	Programmed operation mode speed 5 Acc/Dec time	0.00s	0 ~ 600.00s/ 0 ~ 6000.0s	---
04-40 P.116	Programmed operation mode speed 6 Acc/Dec time	0.00s	0 ~ 600.00s/ 0 ~ 6000.0s	---
04-41 P.117	Programmed operation mode speed 7 Acc/Dec time	0.00s	0 ~ 600.00s/ 0 ~ 6000.0s	---
04-42 P.118	Programmed operation mode speed 8 Acc/Dec time	0.00s	0 ~ 600.00s/ 0 ~ 6000.0s	---

### Setting

#### Programmed operation mode

##### ◆ Programmed operation mode

- The calculation method of running time and acceleration/deceleration time for each speed is shown in the following figure:



- Setting method of operation direction: set in binary (8 bit), then convert into decimal and set in parameter 04-16(P.121) Wherein, 1 means forward rotation, 0 means reverse rotation, the highest bit is the direction of speed 8, and the lowest bit is the direction of speed 1.


For example: if speed 1 is forward, speed 2 is reverse, speed 3 is reverse, speed 4 is forward, speed 5 is reverse, speed 6 is forward, speed 7 is forward, and speed 8 is reverse, then the binary number is 01101001.

## Multi-speed parameter group 04

$$04-16(P.121) = 0 \times 2^7 + 1 \times 2^6 + 1 \times 2^5 + 0 \times 2^4 + 1 \times 2^3 + 0 \times 2^2 + 0 \times 2^1 + 1 \times 2^0 = 105$$


3. When 04-16(P.121) is set to 0, there will be no cycle operation.
4. When 04-17(P.122) is 1~8, it is the section that will cycle to after the first cycle.  
For example: When 04-17(P.122)=3, the cycle operation will start from speed 3 after the speed 1 to speed 8 operations have been completed.
5. When 04-18(P.123) is set to 0, the acceleration time is 01-06 ( P.7 ) and the deceleration time is 01-07(P.8).
6. When 04-18(P.123) is set to 1, the acceleration time and deceleration time are both determined by 04-35~04-42 ( P.111~P.118). If any value in 04-35 ( P.111 ) ~ 04-42 ( P.118) is set to 0, the acceleration time will still be 01-06 ( P.7), 01-07 ( P.8).

### ◆ Manual cycle mode



Wiring diagram for manual cycle mode

1. Connect a push button between M0 and SD.
2. After powered on, set the correspond parameter 03-03(P.80) to 35 according to the terminal. At this time, the inverter is in standby state.
3. Operation is shown in the figure below:



Note:1. This program can run 8 speeds at most, which can be set by 04-19~04-26(P.131~P.138).

2. Settings for parameters 04-15~04-18(P.100、 P.121~P.123)、 04-27~04-42(P.101~P.118) are only for the programmed operation mode not manual cycle mode. For the acceleration and deceleration time of manual cycle mode, please refer to 01-06(P.7), 01-07(P.8), 01-22(P.44), 01-23(P.45).
3. If any segment is set to zero, inverter will return to standby state when run to this segment. This means that when this mode is selected, 04-19(P.131) cannot be 0. As shown in the above diagram, if 04-24(P.136) is 0, regardless of the values of 04-25(P.137) and 04-26(P.138), inverter will stop running when the switch is pressed for the sixth time.

4. Manual cycle function rotation direction is single direction, which has nothing to do with the operation direction parameter 04-16(P.121) of each speed in the programmed operation mode, and has nothing to do with STF and STR signals.
5. For 04-35~04-42(P.111~P.118) please refer to acceleration and deceleration time increments parameter 01-08(P.21).

## 5.6 Motor parameter group 05

Group	Parameter Number	Name	Setting Range	Default	Page
05-01	P.302	Motor rated power	0 ~ 160.00kW	0.00kW	105
05-02	P.303	Motor poles	0 ~ 48	4	105
05-03	P.304	Motor rated voltage	0 ~ 510V	According to voltage	105
05-04	P.305	Motor rated frequency	50Hz system : 0 ~ 599.00Hz	50.00Hz	105
			60Hz system : 0 ~ 599.00Hz	60.00Hz	
05-05	P.306	Motor rated current	0~500.00A	According to kw	105
05-06	P.307	Motor rated rotation speed	50Hz system:0 ~ 9998r/min	1410r/min	105
			60Hz system: 0 ~ 9998r/min	1710r/min	
05-07	P.308	Motor excitation current	0~500.00A	According to kw	105
05-08	P.309	IM motor stator resistance	0 ~ 99.98Ω	According to kw	105

### 5.6.1 Motor parameter

- Inverter has built-in standard parameters for motor. Modify the default values according to the actual situation to conform to the actual values as much as possible.

Parameter	Name	Default	Setting Range	Content
05-01 P.302	Motor rated power	0.00kW	0 ~ 160kW	---
05-02 P.303	Motor poles	4	0 ~ 48	---
05-03 P.304	Motor rated voltage	380V/440V	0 ~ 510V	440V 50Hz/60Hz system
		220V		220V system
05-04 P.305	Motor rated frequency	50.00Hz	0 ~ 599.00Hz	50Hz system (when 00-24(P.189)=1)
		60.00Hz		60Hz system (when 00-24(P.189)=0)
05-05 P.306	Motor rated current	According to kW	0 ~ 500.00A	
05-06 P.307	Motor rated rotation speed	1410r/min	0 ~ 9998r/min	50Hz system (when 00-24(P.189)=1)
		1710r/min		60Hz system (when 00-24(P.189)=0)
05-07 P.308	Motor excitation current	According to kW	0 ~ 500.00A	
05-08 P.309	IM motor stator resistance	According to kW	0 ~ 99.98Ω	

#### Setting

#### Motor parameter

- ◆ The user needs to write the motor parameters correctly according to the motor nameplate.

Note:1. When inverter is used with different size motor, please be sure to set parameters 05-01~05-06(P.302~P.307).  
 2. If one or more parameter values in 05-01~05-08(P.302~P.309) have been manually modified, reset the inverter to reload the new parameter values.

## 5.7 Protection parameter group 06

Group	Parameter Number	Name	Setting Range	Default	Page
06-00	P.9	Electronic thermal relay capacity	0~500.00A	0.00	107
06-01	P.22	Stall prevention operation level	0 ~ 200%	150%	108
06-02	P.23	Stall prevention operation level correction factor	0 ~ 200% 99999: Stall prevention operation level is the setting value of 06-01(P.22).	99999	108
06-03	P.66	Stall prevention operation reduction starting frequency	50Hz system: 0 ~ 599.00Hz 60Hz system: 0 ~ 599.00Hz	50.00Hz 60.00Hz	108
06-08	P.155	Over torque detection level	0 ~ 200.0%	0.0%	110
06-09	P.156	Over torque detection time	0 ~ 60.0s	1.0s	110
06-10	P.260	Action when detect over torque	0: OL2 alarm will not be reported after over torque detection, and inverter keeps running. 1: OL2 alarm will be reported after over torque detection, and inverter stops.	1	110
06-13	P.281	Input phase loss protection	0: Off 1: When input phase loss, built-in keypad shows IPF alarm and inverter stops	0	111
06-17	P.261	Maintenance alarm function	0: Off 1 ~ 9998day: Used to set the time for maintenance alarm output signal	0	110
06-18	P.280	Short circuit protection function	X0: Turn off short circuit to ground detect when inverter start X1: Short circuit to ground detect when inverter start 0X: Turn off output short circuit, 1X: When output short circuit, built-in keypad shows SCP alarm and inverter stops	10	110
06-27	P.292	Total inverter operation time (minutes)	0 ~ 1439 min	0min	111
06-28	P.293	Total inverter operation time (days)	0 ~ 9999 day	0day	111
06-29	P.296	Total inverter power on time (minutes)	0 ~ 1439min	0min	111
06-30	P.297	Total inverter power on time (days)	0 ~ 9999day	0day	111
06-40	P.288	Alarm record code query	Choose 0 ~ 12 recorded alarm	0	112
06-41	P.289	Alarm record code display	Read only	Read only	112
06-42	P.290	Alarm record message query	Choose 0 ~ 10 recorded alarm	0	112
06-43	P.291	Alarm record message display	Read only	Read only	112

### 5.7.1 Electronic thermal relay capacity

- “Electronic thermal relay” uses inverter computing power to simulate a thermal relay for preventing motor from overheating.

Parameter	Name	Default	Setting Range	Content
06-00 P.9	Electronic thermal relay capacity	0.00	0~500.00A	---

**Setting** Electronic thermal relay capacity

- ◆ Please set the value of 06-00(P.9) as the rated current value of the motor at the rated frequency. Rated frequencies of squirrel cage induction motors manufactured in different countries and regions are different. Please refer to the motor nameplate for specific data.
- ◆ If 06-00(P.9)=0, electronic thermal relay is off.
- ◆ When the electronic thermal relay calculates that the motor has accumulated too much heat, the keypad will display a fault code **F H  $\bar{N}$**  and the output will stop.

Note: 1. After the inverter is reset, the heat accumulation record of the electronic thermal relay will return to zero, this should be paid attention to during use.

2. If two or more motors are connected to the inverter, the electronic thermal relay cannot be used as overheat protection for the motors. Please install external thermal relay on each motor.

3. When special motors are used, electronic thermal relay cannot be used for protection. Please install external thermal relay on the motor.

4. Please refer to 03-00(P.83), 03-01(P.84), 03-03(P.80), 03-04(P.81) for the use and wiring method of thermal relay.

### 5.7.2 Current stalling protection


➤ In order to avoid the alarm and stop of the inverter due to overcurrent and overvoltage, the output current is monitored to automatically change the output frequency. It can realize stall prevention during acceleration and deceleration process or during electric regeneration, and make high response current limit valid.

Parameter	Name	Default	Setting Range	Content
06-01 P.22	Electronic thermal relay capacity	150%	0 ~ 200%	---
06-02 P.23	Stall prevention operation level	99999	0 ~ 200%	---
			99999	Stall prevention operation level is the setting value of 06-01(P.22).
06-03 P.66	Stall prevention operation level correction factor	50.00Hz	0 ~ 599.00Hz	50Hz system(00-24(P.189)=1): 0 ~ 650.00Hz
		60.00Hz		60Hz system(00-24(P.189)=0): 0 ~ 650.00Hz



#### Setting Current stalling protection

◆ When heavy load and motor starts or target frequency changes (increases), the rotating speed of motor often cannot keep up with the speed of output frequency change. When the rotation speed of motor is lower than output frequency, output current will increase to enhance output torque. However, if the difference between output frequency and motor speed is too large, motor torque will be reduced, which is called “stall”



Formula for stall prevention level:

$$\text{Level percentage} = A + B \times \frac{06-01(P.22) - A}{06-01(P.22) - B} \times \frac{06-02(P.23) - 100}{100}$$

$$A = \frac{(06-23(P.66)) \times (06-01(P.22))}{\text{Output frequency}} \quad B = \frac{(06-23(P.66)) \times (06-01(P.22))}{400}$$




### 5.7.3 Over torque detection

➤ Output current detection function can be used for over torque detection.

Parameter	Name	Default	Setting Range	Content
06-08 P.155	Over torque detection level	0.0%	0	No over torque detection.
			0.1~200%	Over torque detection.
06-09 P.156	Over torque detection time	1.0s	0 ~ 60.0s	---
06-10 P.260	Action when detect over torque	1	0	OL2 alarm will not be reported after over torque detection, and inverter keeps running.
			1	OL2 alarm will be reported after over torque detection, and inverter stops.

#### Setting Over torque detection

- ◆ If set value of 06-08(P.155) is not zero, over-torque detection function is on.
- ◆ If output current exceeds over-torque detection level (06-08(P.155)) and over-torque detection time (06-09(P.156)), inverter will trigger OL2 alarm and stop. If relay output terminals A-C(03-11(P.85)) is set to over-torque alarm (set value is 12), inverter will output a signal. If relay output terminals A-C (03-11(P.85) ) is set to over-load alarm (set value is 3), and 06-10 (P.260) =1, inverter will output a signal. Please refer to Chapter 5 03-11(P.85) for details.



## 5.7.4 Maintenance alarm function

- Inverter counts operation time and trigger maintenance alarm output signal after time set.

Parameter	Name	Default	Setting Range	Content
06-17 P.261	Maintenance alarm	0	0	Off
	function		1 ~ 9998 day	Used to set the time for maintenance alarm output signal

#### Setting Maintenance alarm function

- ◆ When the multi-function digital output terminal function selection (03-11 (P.85)) is equal to 18, it is the maintenance alarm function. That is, when the number of operating days of the inverter reaches the setting value of the maintenance alarm function 06-17 (P.261) value, the inverter multi-function relay will output a signal.

## 5.7.5 Short circuit protection

- Use parameters to turn on the short-circuit detection protection function.

Parameter	Name	Default	Setting Range	Content
06-18 P.280	Short circuit protection function	10	X0	Turn off short circuit to ground detect when inverter start
			X1	Short circuit to ground detect when inverter start
			0X	Turn off output short circuit,
			1X	When output short circuit, built-in keypad shows SCP alarm and inverter stops

#### Setting Short circuit detection protection function

- ◆ Parameter 06-18 (P.280) ones digits is used to set whether to detect the ground leakage current at motor start. If the function is selected, and inverter detects output short-circuit current to ground, the inverter will stop output and alarm "GF".
- ◆ Parameter 06-18 (P.280) tens digits is used to set whether to detect the output side short-circuit at motor start. If the function is selected, and inverter detects output side short-circuit, the inverter will stop output and alarm "SCP".

Note: 1. 06-18 (P.280) short-circuit detection protection function is only implemented after the start signal is input in the inverter.

### 5.7.6 Input phase loss protection

- Turn on input phase failure protection

Parameter	Name	Default	Setting Range	Content
06-13 P.281	Input phase loss protection	0	0	Off
			1	When input phase loss, built-in keypad shows IPF alarm and inverter stops

**Setting** Input phase loss protection

- ◆ When 06-13(P.281)=1, input phase loss protection is on; when input power is out of phase or three phases are imbalance, inverter will trigger alarm IPF.

### 5.7.7 Time record function

- It is used to record the inverter accumulative operation time.

Parameter	Name	Default	Setting Range	Content
06-27 P.292	Total inverter operation time (minutes)	0 min	0 ~ 1439min	---
06-28 P.293	Total inverter operation time (days)	0 day	0 ~ 9999day	---
06-29 P.296	Total inverter power on time (minutes)	0 min	0 ~ 1439min	---
06-30 P.297	Total inverter power on time (days)	0 day	0 ~ 9999day	---

**Setting** Time record function

- ◆ 06-27(P.292)/06-29(P.296) is operation minutes of the inverter. The value cannot be changed when 00-02=3 (P.998=1) is executed or power is cut off, but can be cleared when set 06-27(P.292)/06-29(P.296) to 0.
- ◆ 06-28(P.293)/06-30(P.297) is operation days of the inverter. The value cannot be changed when 00-02=3 (P.998=1) is executed or power is cut off, but can be cleared when set 06-28(P.293)/06-30(P.297) to 0.

### 5.7.8 Alarm query function

➤ This function provides users with information about latest 12 alarm codes.

Parameter	Name	Default	Setting Range	Content	
06-40 P.288	Alarm record code query	0	0 ~ 12	06-40 (P.288) value 1~12 corresponds to 06-41(P.289)'s alarm E1~E12.	
06-41 P.289	Alarm record code display	Read only	Read only		
06-42 P.290	Alarm record message query	0	0 ~ 12	Alarm of current and prior alarm	06-42 ( P.290 ) =1 , 06-43 ( P.291 ) displays current frequency of present alarm
06-43 P.291	Alarm record message query	Read only	Read only		06-42 ( P.290 ) =2 , 06-43 ( P.291 ) displays current current of present alarm. 06-42 ( P.290 ) =3 , 06-43 ( P.291 ) displays current voltage of present alarm 06-42 ( P.290 ) =4 , 06-43 ( P.291 ) displays current temperature rising accumulation rate of present alarm 06-42 ( P.290 ) =5 , 06-43 ( P.291 ) displays current PN voltage of present alarm 06-42 ( P.290 ) =6 , 06-43 ( P.291 ) displays current inverter operation time of present alarm 06-42 ( P.290 ) =7 , 06-43 ( P.291 ) displays frequency of previous alarm 06-42 ( P.290 ) =8 , 06-43 ( P.291 ) displays current of previous alarm 06-42 ( P.290 ) =9 , 06-43 ( P.291 ) displays voltage of previous alarm 06-42( P.290 )=10 ,06-43( P.291 )displays temperature rising accumulation rate of previous alarm 06-42 ( P.290 )=11 ,06-43 ( P.291 )displays PN voltage of previous alarm 06-42 ( P.290 )=12 , 06-43 ( P.291 ) displays inverter operation time of previous alarm

**Setting** Alarm query function

- ◆ User can read this parameter to know previous 12 alarms and their corresponding information such as frequency, current and voltage. Alarm number recorded by this parameter and status information when alarm occurs will be cleared if perform 00-02=1(P.996=1) operation.
- ◆ If parameters 06-40(P.288) and 06-42(P.290) are both 0, 06-41(P.289) and 06-43(P.291) will also display 0.
- ◆ Alarm number corresponded alarm code :

Alarm number	Alarm code	Alarm number	Alarm code	Alarm number	Alarm code	Alarm number	Alarm code	Alarm number	Alarm code
00	No	32	OV1	49	THN	85	HDC	144	OHT
16	OC1	33	OV2	50	NTC	97	OLS	160	OPT
17	OC2	34	OV3	64	EEP	98	OL2	179	SCP
18	OC3	35	OV0	66	PIDE	128	GF	192	CPU
19	OC0	48	THT	82	IPF	129	AErr	193	CPR

## 5.8 Communication parameter group 07

Group	Parameter number	Name	Setting range	Default	Page
07-00	P.33	Communication protocol selection	0 : Modbus protocol	1	114
			1 : Shihlin protocol		
07-01	P.36	Inverter communication station number	0 ~ 254	0	114
07-02	P.32	Serial communication baud rate	0 : baud rate :4800bps	1	114
			1 : baud rate :9600bps		
			2 : baud rate :19200bps		
			3 : baud rate :38400bps		
07-03	P.48	Data length	0 : 8bit	0	114
			1 : 7bit		
07-04	P.49	Stop bit length	0 : 1bit	0	114
			1 : 2bit		
07-05	P.50	Parity check selection	0 : No parity check	0	114
			1 : Odd		
			2 : Even		
07-06	P.51	CR/LF selection	1:CR only	1	114
			2 : <b>Both</b> CR and LF		
07-07	P.154	Modbus communication format	0 : 1, 7, N, 2 (Modbus, ASCII)	4	114
			1 : 1, 7, E, 1 (Modbus, ASCII)		
			2 : 1, 7, O, 1 (Modbus, ASCII)		
			3 : 1, 8, N, 2 (Modbus, RTU)		
			4 : 1, 8, E, 1 (Modbus, RTU)		
			6 : 1, 8, N, 1 (Modbus, RTU)		
07-08	P.52	Number of communication retries	0 ~ 10	1	114
07-09	P.53	Communication interval allowed time	0 ~ 999.8s : Check communication timeout with the set value	99999	114
			99999 : No timeout check		
07-10	P.153	Communication alarm action	0 : Alarm and stop freely	1	114
			1 : No alarm and continuing to operation		
07-11	P.34	Communication EEPROM write-in selection	0 : When writing parameters in communication mode, write in RAM and EEPROM	0	129
			1 : When writing parameters through communication, only write into RAM		

### 5.8.1 Shihlin protocol and Modbus protocol

- These protocols can link and communicate with upper controller through RS-485 communication port of inverter for parameter setting, monitoring, etc.

Parameter	Name	Default	Setting Range	Content
07-00 P.33	Communication protocol selection	1	0	Modbus protocol
			1	Shihlin protocol
07-01 P.36	Inverter communication station number	0	0 ~ 254	Maximum inverter connect number is determined by wiring method and impedance matching. Please set its value to a non-zero value when using Modbus protocol
07-02 P.32	Serial communication baud rate	1	0	Baud rate: 4800bps
			1	Baud rate: 9600bps
			2	Baud rate: 19200bps
			3	Baud rate: 38400bps
07-03 P.48	Data length	0	0	8bit
			1	7bit
07-04 P.49	Stop bit length	0	0	1bit
			1	2bit
07-05 P.50	Parity check selection	0	0	No parity check
			1	Odd
			2	Even
07-06 P.51	CR/LF selection	1	1	CR only
			2	Both CR and LF
07-07 P.154	Modbus communication format	4	0	1, 7, N, 2 (Modbus, ASCII)
			1	1, 7, E, 1 (Modbus, ASCII)
			2	1, 7, O, 1 (Modbus, ASCII)
			3	1, 8, N, 2 (Modbus, RTU)
			4	1, 8, E, 1 (Modbus, RTU)
			5	1, 8, O, 1 (Modbus, RTU)
07-08 P.52	Number of communication retries	1	0 ~ 10	If communication error times exceed set value of 07-08 (P.52) and 07-10 (P.153) is set to 0, alarm OPT will be reported.
			0 ~ 999.8s	Checking communication timeout with the set value
07-09 P.53	Communication interval allowed time	99999	99999	No timeout check
			0	Alarm and stop freely
07-10 P.153	Communication alarm action	1	1	No alarm and continuing to operation

#### Setting Shihlin protocol and Modbus protocol

- ◆ If any communication parameter is changed, please power off and restart inverter
- ◆ SL3 series inverters offer two protocols to choose from: Shihlin protocol and Modbus protocol. Parameters 07-02(P.32), 07-01(P.36), 07-08(P.52), 07-09(P.53) and 07-10(P.153) are for both protocols. Parameter 07-03(P.48)~07-06(P.51) only applies to Shihlin protocol and parameter 07-07(P.154) applies only to Modbus protocol. Please refer to communication protocol for details.

Note:1. Maximum inverter connect number is determined by wiring method and impedance matching. Please set station number value to non-zero when using Modbus protocol.


2. If communication error times exceed set value of 07-08(P.52), and 07-10(P.153) is set to 0, OPT alarm will trigger.

3. Modbus protocol is expressed according to start bit, data bit, parity check bit and stop bit. In addition, N means no parity check, E means 1-bit even check, and O means 1-bit odd check.


4. In shilin protocol, please check the settings of parameter 07-03~07-05(P.48~P.50).If 07-04(P.49) is set to 1(stop bit 2 bit) , set 07-05(P.50) to 0 and select no parity check ; the format of 07-03(P.48)=1, 07-04(P.49)= 07-05 (P.50)=0 is unusable.

✓ Composition and wiring of SL3 RS-485 communication interface


1. Terminal configuration of SL3 RS-485 communication interface



2. Communication between upper controller and a single inverter (take PLC as an example)



3. Communication between upper controller and multiple inverters (take PLC as an example)




4. SL3 series inverter support Shihlin communication protocol and MODBUS communication protocol

✓ Shihlin protocol

1. Upper controller and inverter automatically converted into ASCII code (hexadecimal) for communication
2. Please follow the steps to perform data communication between upper controller and inverter.

## Communication parameter group 07



Please refer to the following table for descriptions of communication actions and communication data format type in the above steps:

No	Action	Run command	Frequency write	Parameter write	Inverter reset	Monitoring	Parameter readout
①	Upper controller user program sends a communication request to inverter	A	A	A	A	B	B
②	Inverter data processing time	Yes	Yes	Yes	Yes	Yes	Yes
③	Inverter return information (check data ① for error)	No error (accept request)	C	C	C	No	E
		Error (request denied)	D	D	D	No	D
④	Upper controller processing delay time	No	No	No	No	No	No

### ① Data of communication request sent by upper controller to inverter

Format	Data number													
	1	2	3	4	5	6	7	8	9	10	11	12	13	14
A (Data write)	ENQ *1)	Inverter station number		Command code	Waiting time *2)		Data			Check code Sum check*7)		End symbol*3)		
B (Data read)	ENQ *1)	Inverter station number		Command code	Waiting time *2)		Check code Sum check*7)		End symbol*3)					

### ③ Inverter return information

#### Data write-in

Format	Data number					
	1	2	3	4	5	6
C ( correct )	ACK*1)		Inverter station number		End symbol*3)	
D ( error )	NAK*1)		Inverter station number		Error code*5)	

#### Data read-out

Format	Data number												
	1	2	3	4	5	6	7	8	9	10	11	12	13
E(correct)	STX*1)	Inverter station		Data read-out				Unit*4)	ETX	Check code Sum check*7)		End symbol*3)	
D(error)	NAK*1)	Inverter station		Error code*5)		End symbol*3)							

\*1) Control code



Signal	ASCII code	Content	Signal	ASCII Code	Content
NUL	H00	NULL	ACK	H06	Acknowledge
STX	H02	Start of Text	LF	H0A	Line Feed
ETX	H03	End of Text	CR	H0D	Carriage Return
ENQ	H05	Enquiry	NAK	H15	Negative Acknowledge

\*2) Waiting time set from 0 to 15 with 10ms unit. Example: set value 5 --->50ms.

\*3) End symbol (CR, LF codes)

When performing data communication from upper controller to inverter, CR and LF codes at the end of message will be automatically set according to upper controller mode. At this time, inverter must also make necessary settings to cooperate with upper controller. If only CR is selected, only one register is occupied; If both CR and LF are selected, two registers will be occupied.

\*4) Unit: 0---> Unit 1, 1---> Unit 0.1, 2---> Unit 0.01, 3---> Unit 0.001

\*5) Error code :

Error code	Error item	Communication error content
H01	Parity check error	Parity check of data received by inverter is different from parity check initially set
H02	Sum Check error	Sum Check value calculated by inverter according to received data is different from received Sum Check value
H03	Communication protocol error	Structure of the data received by inverter is incorrect; or data has not been received within specified time; or CR and LF codes are different from those initially set
H04	Frame error	Stop bit of data received by inverter is inconsistent with stop bit initially set
H05	Overflow error	When inverter is receiving data (not all data have been received yet), upper controller transmits next data to it.
H0A	Wrong mode	Write when inverter is running or mode setting requirements are not met
H0B	Command code error	A command code that cannot be processed by inverter is specified
H0C	Data range error	When setting parameters and frequencies, data outside the set range are specified

\*6) When the parameter has the characteristics of 99999, the write-in or read-out of 99999 will be replaced by HFFFF

\*7 ) Request sum check code

ASCII-converted code of the data is added in binary code, and the lower bit (lower 8 bits) of the result (summation) is converted to ASCII 2 bits (hexadecimal), which is called SumCheck Code.

✓ Communication example:

Example 1. Upper controller sends a forward rotation command to inverter:

Step 1: Use the upper controller to send a FA command in Format A :

ENQ	Inverter station Number 0	Command code HFA	Waiting time	data H0002	Check code Sum Check	CR
H05	H30 H30	H46 H41	H30	H30 H30 H30 H32	H44 H39	H0D

Sum Check calculation :  $H30 + H30 + H46 + H41 + H30 + H30 + H30 + H30 + H32 = H1D9$ , take the lower eight bits D9 to convert to ASCII code H44 and H39

Step 2: After receive and processing the data without error, inverter will send reply to upper controller in Format C:

ACK	Inverter station number 0	CR
H06	H30 H30	H0D

Example 2. Upper controller sends a stop rotation command to inverter:

Communication parameter group 07

Step 1: Use upper controller to send FA command in Format A :

ENQ	Inverter station number 0	Code HFA	Waiting time	Data H0000	Check code Sum Check	CR
H05	H30 H30	H46 H41	H30	H30 H30 H30 H30	H44 H37	H0D

Step 2: After receive and processing the data without error, inverter will send reply to upper controller in Format C :

ACK	Inverter station number 0	CR
H06	H30 H30	H0D

Example 3. Upper controller reads the value of 01-28(P.162) :

Step1: Upper controller sends write and page change command, using Format A :

ENQ	Inverter station number 0	Code HFF	Waiting time	Data H0001	Check code Sum Check	CR
H05	H30 H30	H46 H46	H30	H30 H30 H30 H31	H44 H44	H0D

↓  
P.162 is on page 1

Step 2: After receive and processing the data without error, inverter will send reply to upper controller in Format C :

ACK	Inverter station number 0	CR
H06	H30 H30	H0D

Step 3: Upper controller requests inverter for reading 01-28(P.162) value using Format B :

ENQ	Inverter station number 0	Code H3E	Waiting time	Check code Sum Check	CR
H05	H30 H30	H33 H45	H30	H30 H38	H0D

↓  
Subtract 100 from 162 (=62) , convert 62 to H3E in hex , then convert E to H33、 H45 in ASCII

Step 4: Once inverter receives and processes the data without error, 01-28(P.162) value will be sent to upper controller in Format E:

STX	Inverter station number 0	Read out data HFFFF	Unit	ETX	Check data Sum Check	CR
H02	H30 H30	H46 H46 H46 H46	H32	H03	H41 H41	H0D

Example 4. Change the content of 01-28(P.162) to 50 (Default setting is 99999).

Step 1~2 are the same as Step 1~2 of Example 3;

Step 3: Upper controller requests inverter to write 50 in 01-28(P.162) in Format A :

ENQ	Inverter station number 0	Reference code HBE	Waiting time	Data H1388	Check code Sum Check	CR
H05	H30 H30	H42 H45	H30	H31 H33 H38 H38	H45 H42	H0D

↓ ↓  
Subtract 100 from 162(=62) ,  
Convert 62 to H3E in hex ,  
H3E+H80=HBE

minimum unit of 01-28 is 0.01, hence 50×100=5000,  
then convert 5000 to H1388 in hex,  
then convert 1、 3、 8、 8 to ASCII for transmission

Step 4: After receive and processing the data without error, inverter will send reply to upper controller in Format C :

ACK	Inverter station number 0	CR
H06	H30 H30	H0D

Example 5. Write 600 into 01-28(P.162) (this parameter range is set from 0 to 599.00)

Step 1~2 are the same as Step 1~2 of Example 3;

Step 3: Upper controller requests inverter to write 600 in 01-28(P.162) in Format A:

ENQ	Inverter station number 0	Reference code HDE	Waiting time	Data HEA60	SUM CHECK	CR
H05	H30 H30	H42 H45	H30	H45 H41 H36 H30	H30 H33	H0D


Step 4: After receiving and processing the data, the data exceed the range of 01-28(P.162), so data range is incorrect. Inverter will reply error to upper controller in Format D :

NAK	Inverter station number 0	Error code H0C	CR
H15	H30 H30	H43	H0D

Note: In above examples, parameters 01-28 (P.162) reading and writing are all using P parameter mode. To use parameter group mode, please note the difference between page number and parameter number. Please refer to the communication command list for relevant contents.

- ✓ MODBUS communication protocol
- ✓ Message format

MODBUS serial transmission can be divided into two types: ASCII (American Standard Code for Information Interchange) and RTU(Remote Terminal Unit)



- (1) Query  
Upper controller (master address) sends data to Slave (slave address) with specified address.
- (2) Normal Response  
After receiving the query from Master, Slave will execute requested function and ask Master to send normal response.
- (3) Error Response  
When receiving wrong function codes, address or data, inverter will send this response to Master.
- (4) Broadcast  
After Master specifies address 0, it can send data to all Slave. All Slave that received Master data will perform the requested function but will not return a respond to Master.

## Communication parameter group 07

### ✓ Communication format :

In general, Master sends Query Message to Slave, which returns Response Message to Master. During normal communication, address codes and function codes are copied. During abnormal communication, function code bit7 is set to "1" (=H80), and Data Byte is set to error code

### ✓ Message compensation :

Format	Start	① Address	② Function	③ Data	④ Error check	Stop
ASCII	H3A	8bit	8bit	n×8bit	2×8bit	0D 0A
RTU	>=10ms					>=10ms

Message	Content															
①Address information group	Setting range: 0~254. 0 is for broadcast address, 1~254 for slave device (inverter) address. 07-01 ( P.36 ) is used to set the Slave device address when Master device sends information to the Slave device and the Slave device replies information to Master device															
② 3 Function information group	At present, there are four functions. Slave device acts according to the request of Master device. If Master device sets a function code other than the table below, Slave device will return an error response. Normal function code will be returned when response is normal, and H80+ function code will be returned when response is wrong. <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>Function name</th> <th>Function code</th> <th>Function description</th> </tr> </thead> <tbody> <tr> <td>Read multiple registers</td> <td>H03</td> <td>Read Slave's continuous register content.</td> </tr> <tr> <td>Write single register</td> <td>H06</td> <td>Write data into Slave's single register.</td> </tr> <tr> <td>Function diagnosis</td> <td>H08</td> <td>Function diagnosis(only for communication check)</td> </tr> <tr> <td>Write multiple registers</td> <td>H10</td> <td>Data can be written to Slave's multiple registers.</td> </tr> </tbody> </table>	Function name	Function code	Function description	Read multiple registers	H03	Read Slave's continuous register content.	Write single register	H06	Write data into Slave's single register.	Function diagnosis	H08	Function diagnosis(only for communication check)	Write multiple registers	H10	Data can be written to Slave's multiple registers.
Function name	Function code	Function description														
Read multiple registers	H03	Read Slave's continuous register content.														
Write single register	H06	Write data into Slave's single register.														
Function diagnosis	H08	Function diagnosis(only for communication check)														
Write multiple registers	H10	Data can be written to Slave's multiple registers.														
③Data information group	Change according to function code, including initial address, number of registers written and read, data written, etc.															
④Error checking information group	ASCII is the check method for LRC, while RTU is the check method for CRC															

### Calculation of LRC check value in ASCII mode:

LRC check is relatively simple, which is used in ASCII mode and can detect all contents in the information domain except the starting colon and the ending carriage return character, it superimpose each data to be transmitted according to bytes (not ASCII code). If the obtained result is greater than hexadecimal H100, remove the excess part (for example, if hexadecimal H136 is obtained, only retain H36), obtain the inverse code of the remaining part and add 1 to it.

### Calculation of CRC check value in RTU mode:

1. Add a 16-bit register with every bit set to 1.
2. Perform an xor operation between the upper byte of the 16-bit register and the initial 8-bit byte, the result of which is put into this 16-bit register.
3. Move this 16-bit register one bit to the right.
4. If the bit moved to the right (marked bit) is 1, perform an xor operation between the generated polynomial 1010000000000001 with this register. If the bit moved to the right is 0, 3 will be returned.
5. Repeat steps 3 and 4 until 8 bits are removed.
6. Perform an xor operation between another 8 bits with this 16-bit register.
7. Repeat steps 3 to 6 until all bytes of the message are performed xor operation with the 16-bit register and bit has been moved for 8 times.
8. The content of this 16-bit register is the 2-byte CRC error check code, which will be added to the highest significant bit of the message.

When adding CRC to the message, the low byte is added first, then the high byte.

✓ Communication format:

### 1. Data readout ( H03 )

Mode	Start	Address*1 )	Function*2 )	Start address*3 )	Number of register*4 )	Check	Stop
ASCII	H3A	2char	2char	4char	4char	2char	0D 0A
RTU	>=10ms	8bit	8bit	2byte	2byte	2byte	>=10ms

#### Normal response

Mode	Start	Address*1 )	Function*2 )	Readout data number*5 )	Readout data*6 )	Check	Stop
ASCII	H3A	2char	2char	2char	4char ...2N×8bit	2char	0D 0A
RTU	>=10ms	8bit	8bit	1byte	2byte ...N×8bit	2byte	>=10ms

Message	Content
*1)Address	Set the address for sending information, 0 is invalid
*2)Function code	H03
*3)Start address	Set the address of the register to be read
*4)Number of registers	Set the number of registers to be read. The maximum number is 20.
*5)Read data number	Twice as much as *4)
*6)Read data	Set the data specified in *4)and read the data from high byte to low byte.

### 2. Data write in ( H06 )

Mode	Start	Address*1)	Function*2)	Start Address*3)	Write-in data*4)	Check	Stop
ASCII	H3A	2char	2char	4char	4char	2char	0D 0A
RTU	>=10ms	8bit	8bit	2byte	2byte	2byte	>=10ms

#### Normal response

Mode	Start	Address*1)	Function*2)	Start Address*3)	Write-in data*4)	Check	Stop
ASCII	H3A	2char	2char	4char	4char	2char	0D 0A
RTU	>=10ms	8bit	8bit	2byte	2byte	2byte	>=10ms

Message	Content
*1)Address	Set the address for sending information
*2)Function code	H06
*3)Start address	Set as the start address of the register that needs to be written
*4)Write data	Write data to the specified register, fixed at 16bit.

Note: The content of normal response is the same as query information

### 3. Write multiple registers ( H10 )

Mode	Start	Address *1)	Function *2)	Start Address *3)	Number of register *4)	Data*5)	Write-in data *6)	Check	Stop
ASCII	H3A	2char	2char	4char	4char	2char	4char ...2N×8bit	2char	0D 0A
RTU	>=10ms	8bit	8bit	2byte	2byte	1byte	2byte ...N×16bit	2byte	>=10ms

## Communication parameter group 07

### Normal response

Mode	Start	Address*1)	Function*2)	Start Address*3)	Number of register *4)	Check	Stop
ASCII	H3A	2char	2char	4char	4char	2char	0D 0A
RTU	>=10ms	8bit	8bit	2byte	2byte	2byte	>=10ms

Message	Content
*1)Address	Set the address for sending information
*2)Function code	H10
*3)Start address	Set as the start address for the register that needs to be written
*4) Number of registers	Sets the number of registers written. The maximum number is 20.
*5) Number of data	Setting range is 2~24. Set 2 times the value specified in *4).
*6) Write data	Set data division specified in *4). Write data is set in the order of high byte to low byte. Setting is performed in the order of starting address data, starting address +1 data, starting address +2 data ...

#### 4. Function diagnosis (H08)

In order to send the query information, the query information (function of subfunction code H00) is returned as it is, and communication check can be performed.

Sub-function code H00 (return of query data)

#### The query information

Mode	Start	Address*1)	Function*2)	Subroutine *3)	Data *4)	Check	End
ASCII	H3A	2char	2char	4char	4char	2char	0D 0A
RTU	>=10ms	1byte	1byte	2byte	2byte	2byte	>=10ms

### Normal response

Mode	Start	Address*1)	Function*2)	Sub-function *3)	Data *4)	Check	End
ASCII	H3A	2char	2char	4char	4char	2char	0D 0A
RTU	>=10ms	1byte	1byte	2byte	2byte	2byte	>=10ms

#### Query information setting

Message	Content
*1)Address	Set the address for sending information, but be unable to broadcast communication (0 is invalid)
*2)Function code	H08
*3)Sub-function code	H0000
*4)Data	The data can be set arbitrarily if the length is 2 byte. Set range is H0000~HFFFF.

#### Error response

If error is contained in the function/address/data received from the device, do function diagnosis;

However, when using function code H03 or H10 to access more than one address, if one or more data can still operated, it will not be seen as an error.

Mode	Start	Address*1)	Function*2) H80+function	Error code * 3)	Check	End
ASCII	H3A	2char	2char	2char	2char	0D 0A
RTU	>=10ms	8bit	8bit	8bit	2byte	>=10ms

Message	Content
*1) Address	Set the address for sending information
*2) Function code	Function code set by Master + H80
*3)Error code	Set code in the following table

Error code list:

Source	Code	Meaning	Remarks
Slave reply	H01	illegal function code	In query information sent by Master, the function code cannot be processed by slave device. Function codes are not H03, H06, H08, H10 (Suppose).
	H02	illegal data address	In query information sent by Master, the address cannot be processed by Slave (outside the addresses listed in the table, the reserved parameters, the parameters not allowed to be read, the parameters not allowed to be written).
	H03	illegal data value	In query information sent by Master, the data cannot be processed by the Slave (outside parameter writing range, required specified mode, other error, etc.).

Note: When read multiple parameters, it is not an error even if they are reserved parameters.

In data sent by Master, Slave (inverter) will detect the following errors, but will not respond when it detects the error.

Error detection item table:

Error item	Error content
Parity error	The parity test for data received by the inverter is different from the parity test set at the initial stage.
Frame error	The stop byte of the data received by the inverter mismatches the stop byte set at the initial stage.
Overflow error	When the inverter is receiving data, the host computer sends the next set of data before the inverter finishes receiving the current one.
Error test	The LRC/CRC calculated by the inverter according to the received data is different from the received LRC/CRC.

#### ✓ Communication example

Example 1. CU operation mode written by communication

Step 1: Upper controller modifies operation mode of inverter

Mode	Start	Address	Function	Start address		Write data		Check	Stop
ASCII	H3A	H30 H31	H30 H36	H31 H30	H30 H30	H30 H30	H30 H30	H45 H39	0D 0A
RTU	>=10ms	01	06	10	00	00	00	8D 0A	>=10ms

Step 2: After receiving and processing the data without error, inverter will send a reply to upper controller

Mode	Start	Address	Function	Start address		Write data		Check	Stop
ASCII	H3A	H30 H31	H30 H36	H31 H30	H30 H30	H30 H30	H30 H30	H45 H39	0D 0A
RTU	>=10ms	01	06	10	00	00	00	8D 0A	>=10ms

Example 2. Read parameter 01-28 ( P.162 ) value by upper controller

Step 1: Upper controller sends message to inverter to read 01-28 ( P.162 ) value. 01-28 ( P.162 ) address is H00A2.

Mode	Start	Address	Function	Start address		Number of registers		Check	Stop
ASCII	H3A	H30 H31	H30 H33	H30 H30	H41 H32	H30 H30	H30 H31	H35 H39	0D 0A
RTU	>=10ms	01	03	00	A2	00	01	25 E8	>=10ms

Step 2: After receive and processing the data without error, inverter will send 01-28 ( P.162 ) to upper controller

Mode	Start	Address	Function	Number of data read	Read data		Check	Stop
ASCII	H3A	H30 H31	H30 H33	H30 H32	H46 H46	H46 H46	H46 H43	0D 0A
RTU	>=10ms	01	03	02	FF	FF	B9 F4	>=10ms

## Communication parameter group 07

Example 3. Upper controller change inverter 01-28 ( P.162 ) value to 50.

Step 1: Upper controller sends message to inverter to write 50 into 01-28 ( P.162 ) .

Mode	Start	Address	Function	Start address		Write data		Check	Stop
ASCII	H3A	H30 H31	H30 H36	H30 H30	H41 H32	H31 H33	H38 H38	42 43	0D 0A
RTU	>=10ms	01	06	00	A2	13	88	25 7E	>=10ms

Step 2: After receive and processing the data without error, inverter will send a reply to upper controller

Mode	Start	Address	Function	Start address		Write data		Check	Stop
ASCII	H3A	H30 H31	H30 H36	H30 H30	H41 H32	H31 H33	H38 H38	H42 H43	0D 0A
RTU	>=10ms	01	06	00	A2	13	88	25 7E	>=10ms

Example 4. Upper controller read parameters 01-10(P.0), 01-00(P.1), 01-01(P.2), 01-03(P.3), 04-00~04-02/P.4~P.6, 01-06~01-07/P.7~P.8, 06-00(P.9),10-00~10-01/P.10~P.11.

Step 1: Upper controller sends message to inverter for reading 01-10(P.0), 01-00(P.1), 01-01(P.2), 01-03(P.3), 04-00~04-02/P.4~P.6, 01-06~01-07/P.7~P.8, 06-00(P.9), 10-00~10-01 /P.10~P.11 value. Start address is H0000.

Mode	Start	Address	Function	Start address		Number of registers		Check	Stop
ASCII	H3A	H30 H31	H30 H33	H30 H30	H30 H30	H30 H30	H30 H43	H46 H30	0D 0A
RTU	>=10ms	01	03	00	00	00	0C	45 CF	>=10ms

Step 2: After receive and processing the data without error, inverter will send a reply to upper controller

Mode	Start	Address	Function	Start address		Number of registers		Check	Stop
ASCII	H3A	H30 H31	H30 H33	H31 H38		... 12×4 char		2char	0D 0A
RTU	>=10ms	01	03	18		... 12×2 byte		2byte	>=10ms

Example 5. Upper controller write parameters 01-10(P.0), 01-00(P.1), 01-01(P.2), 01-03(P.3), 04-00~04-02/P.4~P.6, 01-06~01-07/P.7~P.8, 06-00(P.9), 10-00~10-01/P.10~P.11.

Step 1: Upper controller sends message to inverter for writing 01-10(P.0), 01-00(P.1), 01-01(P.2), 01-03(P.3), 04-00~04-02/P.4~P.6, 01-06~01-07/P.7~P.8, 06-00(P.9),10-00~10-01/P.10~P.11

Mode	Starting	Address	Function	Start address		Number of registers		Data volume	Write-in data	Check	Stop
ASCII	H3A	H30 H31	H30 H30	H30 H30	H30 H30	H30 H30	H30 H43	H31 H38	...N×4 char	2char	0D 0A
RTU	>=10ms	01	10	00	00	00	0C	18	...N×2byte	2byte	>=10ms

Step 2: After receive and processing the data without error, inverter will send a reply to upper controller

Mode	Start	Address	Function	Start address		Number of registers		Check	Stop
ASCII	H3A	H30 H31	H31 H30	H30H30	H30 H30	H30 H30	H30 H43	H45 H33	0D 0A
RTU	>=10ms	01	10	00	00	00	0C	00 18	>=10ms

Note: In above examples, parameters 01-28 ( P.162 ) reading and writing are all using P parameter mode. To use parameter group mode, please note the difference in address. Please refer to the communication command list for relevant contents.



◆ Communication command list

Set the following command codes and data to perform various operation control, monitoring, etc.

Item		Shihlin protocol command code	Modbus command code	Modbus address	Data content and function description										
Operation mode read out		H7B	H03	H1000	H0000: Communication mode; H0001: External mode; H0002: JOG Mode; H0003: Combined mode 1; H0004: Combined mode 2; H0005: Combined mode 3; H0006: Combined mode 4; H0007: Combined mode 5; H0008: PU Mode;										
Operation mode write in		HFB	H06/H10												
Inverter status monitoring		H7A	H03	H1001	H0000~H00FF b15 : during tuning b14: during inverter reset b13, b12: Reserved b11: inverter E0 status b10~8: Reserved b7 : alarm occurred b6 : frequency detect b5 : Parameters reset end b4: overload b3: frequency arrive b2: during reverse rotation b1: during forward rotation b0: running										
Target frequency write-in	EEPROM	HEE	H06/H10	H1009	H0000~ HE9FC : 0~599.00Hz										
	RAM	HED		H1002											
Special monitor codes read out		H7D	H03	H1013	H0000~H0010: monitor selected information. Please refer to special monitoring code table (H0009 reserved)										
Special monitor codes write in		HF3	H06/H10												
Monitor external operation		H7C	H03	H1012	H0000~H000F : <table border="1" style="display: inline-table; vertical-align: middle;"><tr><td style="text-align: center;">b15~b4</td><td style="text-align: center;">b3</td><td style="text-align: center;">b2</td><td style="text-align: center;">b1</td><td style="text-align: center;">b0</td></tr><tr><td style="text-align: center;">0000 0000 0000</td><td style="text-align: center;">MRS</td><td style="text-align: center;">STR</td><td style="text-align: center;">STF</td><td style="text-align: center;">RES</td></tr></table>	b15~b4	b3	b2	b1	b0	0000 0000 0000	MRS	STR	STF	RES
b15~b4	b3	b2	b1	b0											
0000 0000 0000	MRS	STR	STF	RES											
Inverter reset		HFD	H06/ H10	H1101	H9696: function of 00-02=2/P.997=1. When communicating with upper controller, inverter cannot return data to upper controller because inverter is reset.										
Parameter clear		HFC	H06/ H10	H1104	H5A5A	Please refer to parameter recovery table for details.									
					H5566										
					H5959										
				H1103	H9966										
				H1106	H9696										
					H99AA										
					H9A9A										
H1105	H55AA														
H1102	HA5A5														

Communication parameter group 07

Item	Shihlin protocol command code	Modbus command code	Modbus address	Data content and function description
Parameter read-out	H00~H63	H03	P mode: H0000~H018F Parameter group mode: H2710~H2CFF	1.Please refer to the parameter table for data range and decimal point position 2.Modbus address of each parameter in P parameter mode corresponds to hexadecimal value of parameter number. For example, Modbus address of 04-26 (P.138) is H008A. 3. Modbus address of each parameter in parameter group mode corresponds to hexadecimal value of parameter number +10000. For example, Modbus address of 04-26 (P.138) is 0x28BA.
Parameter write-in	H80~HE3	H06/ H10		
Operation command write	HFA	H06/ H10	H1001	H0000~HFFFF b8~b15 : reserve b7 : Emergency stop ( MRS ) b6 : Second function (RT) b5 : High speed (RH) b4 : Middle speed (RM) b3 : Low speed (RL) b2 : Reverse(STR) b1 : Forward (STF) b0 : reserve
Monitor inverter real time value	---	H03	H1014~ H1020	Modbus address is as follows : H1014 : digital input terminal state H1015 : digital output terminal state H1016 : reserve H1017 : terminal 3-5 input current/voltage H1018 : reserve H1019 : DC bus voltage H101A: inverter electronic thermal accumulation rate H101B: inverter output wattage H101C: inverter temperature rising accumulation rate H101D: inverter NTC temperature accumulation rate H101E: motor electronic thermal accumulation rate H101F: PID control target pressure H1020: PID control feedback pressure
Page change for parameter reading and writing	Read	H7F	---	P parameter mode : H0000 : P.0~P.99 ; H0001 : P.100~P.199 ; H0002 : P.200~P.299 ; H0003 : P.300~P.399 ; Parameter group mode : H0064 : 00-00~00-99 ; H0065 : 01-00~01-99 ; H0066 : 02-00~02-99 ; H0067 : 03-00~03-99 ; H0068 : 04-00~04-99 ; H0069 : 05-00~05-99 ; H006A : 06-00~06-99 H006B : 07-00~07-99 H006C : 08-00~08-99 H006E : 10-00~10-99 H0071 : 13-00~13-99 H0073 : 15-00~15-99
	Write	HFF		

Item		Shihlin protocol command code	Modbus command code	Modbus address	Data content and function description			
Monitor	Frequency	EEPROM	H73	H03	H1009 H1002	H0000~HE9FC(two decimal points when 00-08=0; one decimal point when non-zero)		
		RAM	H6D					
	Output frequency		H6F		H1003	H0000~HE9FC ( same as above )		
	Output current		H70		H1004	H0000~HFFFF(two decimal points)		
	Output voltage		H71		H1005	H0000~HFFFF(two decimal points)		
	Error code		H74		H1007	H0000~HFFFF : last two alarm error code H74/H1007 : Error code 1 and 2 ; b15                      b8 b7                      b0 <table border="1" style="width:100%; border-collapse: collapse;"><tr><td style="width:50%;">Error code 2</td><td style="width:50%;">Latest error code</td></tr></table>	Error code 2	Latest error code
			Error code 2				Latest error code	
H75	H1008	H75/H1008 : Error code 3 and 4 b15                      b8 b7                      b0 <table border="1" style="width:100%; border-collapse: collapse;"><tr><td style="width:50%;">Error code 4</td><td style="width:50%;">Error code 3</td></tr></table> For the alarm codes of 06-40 (P.288)~06-43 (P.291), please refer to the alarm code table in the alarm record parameters 06-40 (P.288)~06-43 (P.291).	Error code 4	Error code 3				
Error code 4	Error code 3							

◆ Table for parameter recovery

Data content	P parameter operation	Communication p parameter (Note 1)	Table 1 (Note 2)	Table 2 (Note 2)	User registered parameter	Other p parameter	Error code
H5A5A	00-02=4(P.999=1)	o(Note 3)	x(Note 4)	x	o	o	x
H5566	00-02=5(P.999=2)	o	x	o	x	o	x
H5959	00-02=6(P.999=3)	o	x	x	x	o	x
H9966	00-02=3(P.998=1)	o	x	o	o	o	x
H9696	Communication 999 1	x	x	x	o	o	x
H99AA	Communication 999 2	x	x	o	x	o	x
H9A9A	Communication 999 3	x	x	x	x	o	x
H55AA	Communication 998	x	x	o	o	o	x

Note: 1. Communication P parameters includes 07-02(P.32), 07-00(P.33), 07-01(P.36), 07-03(P.48)~ 07-09(P.53), 00-16(P.79), 07-10(P.153) and 07-07(P.154).  
 2. Table 1 and table 2 refer to Section 5.1.2 table1 and table 2  
 3.“o”means that parameter can be restored to default value or error can be cleared.  
 4.“x”means that parameter or error cannot be cleared.

Communication parameter group 07

◆ Special monitor code table

Data	Content	Unit
H0000	Monitor digital input terminal state.	Note.1
H0001	Monitor digital output terminal state.	Note.2
H0003	Monitor voltage across terminal 3-5	0.01mA/0.01V
H0005	DC bus voltage	0.1V
H0006	Monitor electronic thermal accumulation rate	0.01
H0007	Inverter temperature rising accumulation rate	0.01
H0008	Inverter output power	0.01Kw
H0009	Inverter NTC temperature accumulation	---
H000A	Motor electronic thermal accumulation rate	0.01
H000B	PID control target pressure	0.1%
H000C	PID control feedback pressure	0.1%

Note: 1. Digital input terminal state details

b3	b2	b1	b0
M1	M0	STR	STF

2. Digital output terminal state details

b1	b0
A-C	0

## 5.8.2 Communication EEPROM write selection

- Use this function if parameter settings are frequently written by communication

Parameter	Name	Default	Setting Range	Content
07-11 P.34	Communication EEPROM write-in selection	0	0	When writing parameters in communication mode, write in RAM and EEPROM
			1	When writing parameters through communication, only write into RAM

### Setting Communication EEPROM write selection

- ◆ When parameter write in is performed by RS485, parameters can store in EEPROM + RAM or RAM only.
- ◆ If change parameter value frequently, set "1" in 07-11(P.34). When 07-11(P.34) set to "0" EEPROM lifetime will be shorter due to constantly write in.

Note: Set 07-11 (P.34) =1 (RAM only), when the power of inverter is turned off, parameters changed will not be memorized. When power on again, all parameters will still be the setting previously saved in EEPROM.

## 5.9 PID parameter group 08

Group	Parameter number	Name	Setting range	Default	Page
08-00	P.170	PID function selection	0: Off	0	131
			2 : Parameter 08-03(P.225) as target value, terminal 3-5 current/voltage input as feedback source		
08-01	P.171	PID feedback control method	0: Negative feedback control.	0	131
			1: Positive feedback control.		
08-03	P.225	PID target value from keypad	0 ~ 08-43 ( P.251 )	20.0%	131
08-04	P.172	Proportional gain	1~100	20	131
08-05	P.173	Integral time	0 ~ 100.0s	1.0s	131
08-06	P.174	Differential time	0 ~ 10000ms	0ms	131
08-07	P.175	Abnormal deviation	0 ~ 100.0%	0.0%	131
08-08	P.176	Abnormal duration time	0 ~ 600.0s	30.0s	131
08-09	P.177	Abnormal processing mode	0: Stop freely	0	131
			1: Slow down to stop		
			2: Alarm and continue operation		
08-10	P.178	Sleep detection deviation	0 ~ 100.0%	0.0%	131
08-11	P.179	Sleep detection duration time	0 ~ 255.0s	1.0s	132
08-12	P.180	Wake-up level	0 ~ 100.0%	90.0%	132
08-13	P.181	Stop level	0 ~ 120.00Hz	40.00Hz	132
08-14	P.182	Upper integral limit	50Hz system:0 ~ 120.00Hz	50.00Hz	132
			60Hz system:0 ~ 120.00Hz	60.00Hz	
08-15	P.183	Deceleration step length when stable	0 ~ 10.00Hz	0.50Hz	132
08-18	P.223	Analog feedback signal bias	0 ~ 100.0%	0.0%	132
08-19	P.224	Analog feedback signal gain	0 ~ 100.0%	100.0%	132
08-43	P.251	PID pressure range (Bar) setting	1.0~100.0	100.0	135
08-45	P.253	Analog signal feedback loss detection time	0 ~ 600.0	0.0 s	135
08-46	P.254	Analog signal feedback loss action selection	0 : Alarm AErr and inverter stop freely	0	135
			1 : Slow down to stop then alarm AErr		
			2 : Alarm AErr and continue operation		

### 5.9.1 PID function selection

- Inverter can control flow, volume or pressure by PID control. By using analog signal or parameter setting as target source, and with analog signal as feedback source, it forms a closed loop control system.

Parameter	Name	Default	Setting Range	Content
08-00 P.170	PID function selection	0	0	Off
			2	Target depends on 08-03(P.225),feedback depends on 3-5 terminal current/input voltage
08-01 P.171	PID feedback control method	0	0	Negative feedback control
			1	Positive feedback control

#### Setting PID function selection

- ◆ During PID control, frequency displayed on screen is inverter output frequency.
- ◆ For terminal 3-5 input signal filtering please refer to parameters 02-10(P.60).

### 5.9.2 PID parameter group

- By setting PID parameters users can realize automatic adjustment of process control

Parameter	Name	Default	Setting Range	Content
08-03 P.225	PID target value from keypad	20.0%	0~08-43(P.251)	When 08-00 (P.170) is set to 2, the target value is set by 08-03(P.225)
08-04 P.172	Proportional gain	20	1~100	This gain determines the proportion controller's response on feedback deviation. The greater the gain, the faster the response. Gain set too high will cause vibration.
08-05 P.173	Integral time	1.0s	0 ~ 100.0s	This parameter determines integral controller's integral time. When integral gain is too high, integral effect will be too weak to eliminate steady state deviation. When integral gain is rather small, the system vibration time will increase, and too small integral gain will cause system unstable.
08-06 P.174	Differential time	0ms	0 ~ 1000ms	This gain determines deviation controller's response to deviation change rate. Appropriate deviation time can reduce overshooting and vibrating between proportion controller and integral controller. Deviation time set too long will cause system vibration.
08-07 P.175	Abnormal deviation	0.0%	0 ~ 100.0%	---
08-08 P.176	Abnormal duration time	30.0s	0 ~ 600.0s	---
08-09 P.177	Abnormal processing mode	0	0	Stop freely
			1	Slow down to stop
			2	Alarm and continue operation
08-10 P.178	Sleep detection deviation	0.0%	0 ~ 100.0%	---

## PID parameter group 08

Parameter	Name	Default	Setting Range	Content	
08-11 P.179	Sleep detection duration time	1.0s	0 ~ 255.0s	---	
08-12 P.180	Wake-up level	90.0%	0 ~ 100.0%	---	
08-13 P.181	Stop level	40.00Hz	0 ~ 120.00Hz	---	
08-14 P.182	Upper integral limit	50.00Hz	0 ~ 120.00Hz	50Hz	When the deviation value accumulated by integral time, need to set an upper limit for deviation accumulation. For example, the upper integral limit of frequency is equal to 01-03(P.3) * 08-14(P.182)
		60.00Hz		60Hz	
08-15 P.183	Deceleration step length when stable	0.50Hz	0 ~ 10.00Hz	When feedback pressure reach stopping deviation value and time (in seconds), inverter will decrease frequency by 08-15 (P.183) value per second	
08-18 P.223	Analog feedback signal bias	0.0%	0 ~ 100.0%	Feedback signal correction , unify inverter feedback terminal and actual feedback signal to make inverter and display value the same	
08-19 P.224	Analog feedback signal gain	100.0%	0 ~ 100.0%		



### Setting PID parameter group

#### ◆ Calibration instructions for the offset and gain of the analog feedback signal:

- The user does not connect the feedback signal for correction, the corresponding relationship is as follows:

3-5 input analog voltage signal		3-5 input analog current signal	
Correction voltage	Correction ratio	Correction current	Correction ratio
0.1V	08-18(P.223)	4mA	08-18(P.223)
5V	08-19(P.224)	20mA	08-19(P.224)

Note: 1. The default setting corresponds to a range of 0.1~5V. If it does not match the range needed, please set 08-18 (P.223) and 08-19 (P.224). Also need to set 08-00 (P. 170)at the end to achieve uniform range.

- To use terminal 3-5 as the PID feedback source, be sure to set 02-20 (P.17) and AVI-ACI switch first, to select the voltage/current for terminal 3-5 signal.

Example 1 : Use 0~7V for feedback signal on terminal 3-5

$$1) \quad 08-18(P.223) = 0.1 / 7 * 100.0 = 1.4$$

$$08-19(P.224) = 5 / 7 * 100.0 = 71.4$$

After setting 08-18 (P.223) and 08-19 (P.224) according to the above calculated value, set 08-00 (P.170)=2, then the range after calibration is 0~7V.

Example 2: Use 0~20mA for feedback signal on terminal 3-5

$$1) \quad 08-18(P.223) = 4 / 20 * 100.0 = 20.0$$

$$08-19(P.224) = 20 / 20 * 100.0 = 100.0$$

After setting 08-18 (P.223) and 08-19 (P.224) according to the above calculated value, set 08-00 (P.170)=2, then the range after calibration is 0~20mA.



2. Needs to calibrate the feedback signal

Adjust the feedback signal to a certain value, calculate the ratio of this value to the feedback range, and then write this ratio value to 08-18 (P.223);


Re-adjust the feedback signal to another value and calculate the ratio of this value to the feedback range, and then write this ratio value to 08-19 (P.224).

Example 1: Feedback range is 0~10kg

Adjust the feedback signal to 4kg, then write 08-18 (P.223) =  $(4 / 10) * 100.0 = 40$ ,


Adjust the feedback signal to 6kg, then write 08-19 (P.224) =  $(6 / 10) * 100.0 = 60$ .

Note: The user must connect the actual feedback signal for this type of calibration, and must set 08-00 (P.170) = 2 before performing the calibration.




- ◆ When output frequency reaches 01-03 (P.3) \* 08-14 (P.182), the feedback value < target value \* 08-07 (P.175), and the duration exceeds 08-08 (P.176) , PID is considered abnormal, and it will be handled according to 08-09 (P.177) value.

Example: Set 08-07(P.175)=60%, 08-08(P.176)=30s, 08-09(P.177)=0, 01-03(P.3) = 50Hz, 08- 14(P.182)=100%, when the output frequency reaches 50Hz, the feedback value is lower than 60% of the target value and lasts for 30s, inverter alarms **PID E** and stops freely.




- ◆ If 08-10 (P.178) is set to 0, then 08-11 (P.179), 08-12 (P.180), 08-13 (P.181), 08-15 (P.183) value is invalid. If the value of 08-10 (P.178) is not 0, the PID sleep function will be enabled. When the absolute value of the deviation between the feedback value and the target feedback value is less than the sleep detection deviation and lasts for 08-11 (P.179) sleep detection time, the inverter will gradually reduce the output frequency, when the inverter output frequency is lower than 08-13 (P.181) stop level, inverter will decelerate to stop. When the feedback value is lower than the wake-up level, the inverter output frequency is controlled by PID again.

Example: 08-10(P.178)=5%, 08-11(P.179)=1.0s, 08-12(P.180)=90%, 08-13(P.181)=40Hz, 08-15(P.183)=0.5Hz. When the feedback value is greater than 95% of the target feedback value and less than 105% of the target feedback value, it is in stable zone. In the stable zone, inverter reduces the output frequency based on 0.5 Hz per second. When the inverter output frequency is lower than 40 Hz, inverter will directly decelerate to stop. When the feedback value is lower than 90% of the target feedback value, inverter will wake up and the output frequency will be controlled by PID again.




- ◆ Simple setting of PID gain:

1. When the PID target value is changed, if the output response is slow, increase the proportional gain; If the output response is fast but unstable, reduce the proportional gain (KP=08-04(P.172)).



2. When PID target and feedback are not equal, reduce the integration time; When target and feedback are equal after oscillation, increase the integration time (KI=08-05 (P.173)).



- ◆ After increasing the proportional gain, if the output response is still slow, increase the differential gain;  
If the output is unstable, reduce the differential gain (KD=08-06(P.174)).

Note: 1. When 08-09(P.177)=2, there is no alarm display on the keypad, multi-function digital output terminal output a signal. After the inverter stops, the digital output terminal is automatically off.

### 5.9.3 PID pressure range setting

- Set the range of PID target and feedback.

Parameter	Name	Default	Setting Range	Content
08-43 P.251	PID pressure range (Bar) setting	100.0	1.0~100.0	Set the range of PID target and feedback

#### Setting PID pressure range

- ◆ The setting of the PID target value can be %, bar, Kg, etc. Set 08-43 (P.251) if need the setting of the PID target value corresponds to the dimension of the actual system, generally set as feedback system sensor range.
- ◆ For example: If the pressure sensor feedback range is 0~10V, the corresponding pressure range is 0~16.0bar, then 08-43 (P.251) set 16.0, and 08-03 (P.225)=8.0, then 00- 07 (P.161) = 3 (monitor target pressure) monitoring is: 8.0.

### 5.9.4 PID analog signal feedback loss

- Used to detect whether the PID feedback is disconnected.

Parameter	Name	Default	Setting Range	Content
08-45 P.253	Analog signal feedback loss detection time	0.0 s	0.0~600.0 s	Set the time of feedback disconnect detection, set to 0 to turn off the function
08-46 P.254	Analog signal feedback loss action selection	0	0	Alarm AErr and inverter stop freely
			1	Slow down to stop then alarm AErr
			2	Alarm AErr and continue operation

#### Setting PID disconnection function

- ◆ Set 08-45 (P.253) to a non-zero value, when inverter is running, PID feedback disconnect exceeds the time set in 08-45 (P.253), inverter react as action set in 08-46 (P.254).
- ◆ Set 08-45 (P.253) to 0, the feedback disconnection detection function is off.

Note: This function is only suitable for 4-20mA terminal 3-5 signal type.

## 5.10 Application parameter group 10

Group	Parameter Number	Name	Setting Range	Default	Page
10-00	P.10	DC brake operating frequency	0 ~ 120.00Hz	3.00Hz	138
10-01	P.11	DC brake operating time	0 ~ 60.0s	0.5s	138
10-02	P.12	DC brake operating voltage	0 ~ 30.0%	4.0%	138
10-03	P.151	Zero-speed control function selection	0: Off.	0	139
			1: DC voltage braking		
10-04	P.152	Voltage at zero-speed control	0 ~ 30.0%	5.0%	139
10-05	P.242	DC brake before inverter start	0: Off	0	139
			1: Before starting operate DC brake first.		
10-06	P.243	DC brake time before inverter start	0 ~ 60.0s	0.5s	139
10-07	P.244	DC brake voltage before inverter start	0 ~ 30.0%	4.0%	139
10-08	P.150	Restart mode selection	X0 : No frequency search.	0	140
			X1 : Reserved		
			X2 : Decrease voltage mode		
			0X : Power on once.		
			1X : Start each time.		
			2X : Only instantaneous stop and restart		
10-09	P.57	Restart idling time	0 ~ 30.0s	99999	140
			99999: Off.		
10-10	P.58	Restart rising time	0 ~ 60.0s	10.0s	140
10-11	P.61	Remote control function	0: Off	0	141
			X1 : Remote control function, frequency save in memory		
			X2 : Remote control function, frequency won't save		
			X3 : Remote control function, frequency won't save, clear frequency setting every time STF/STR "turn off".		
			X4: Remote control function, frequency save in memory every 5s		
			1X:Frequency command range 01-01(P.2)~01-00(P.1), frequency command value from RH, RM setting		

Group	Parameter Number	Name	Setting Range	Default	Page
10-12	P.65	Auto reset function	0: Off.	0	144
			1: When over-voltage, inverter will reset.		
			2: When over-current, inverter will reset.		
			3: When either over-voltage or over-current, inverter will reset.		
			4: When any alarm occurs, inverter will reset.		
10-13	P.67	Auto reset times	0: Off. 1 ~ 10: If the alarm exceeds 10-13(P.67) times, inverter will not reset.	0	144
10-14	P.68	Auto reset waiting time	0 ~ 360.0s	6.0s	144
10-15	P.69	Auto reset times count	Read only	0	144
10-16	P.119	Forward and reverse rotation dead time	0 ~ 3000.0s	0.0s	145
10-17	P.159	Energy-saving control function	0: Off.	0	145
			1: Energy-saving mode.		
10-18	P.229	Dwell function selection	0: Off.	0	146
			1: Backlash compensation function.		
			2: Acceleration and deceleration interrupt waiting function.		
10-19	P.230	Dwell frequency at acceleration	0 ~ 599.00Hz	1.00Hz	146
10-20	P.231	Dwell time at acceleration	0 ~ 360.0s	0.5s	146
10-21	P.232	Dwell frequency at deceleration	0 ~ 599.00Hz	1.00Hz	146
10-22	P.233	Dwell time at deceleration	0 ~ 360.0s	0.5s	146
10-23	P.234	Triangular wave function selection	0: Off.	0	147
			1: If terminal function TRI is triggered, triangular wave function will on.		
			2: Triangular wave function is on at all time.		
10-24	P.235	Maximum amplitude	0 ~ 25.0%	10.0%	147
10-25	P.236	Amplitude compensation at deceleration	0 ~ 50.0%	10.0%	147
10-26	P.237	Amplitude compensation at acceleration	0 ~ 50.0%	10.0%	147
10-27	P.238	Amplitude acceleration time	0 ~ 360.00s/0 ~ 3600.0s	10.00s	147
10-28	P.239	Amplitude deceleration time	0 ~ 360.00s/0 ~ 3600.0s	10.00s	147
10-46	P.268	Voltage stall level	220V : 155 ~ 400V	380V	148
			440V : 310 ~ 800V	760V	
10-55	P.226	Reciprocating machine function selection	0 : Off	0	148
			1 : Turn on reciprocating machine function		
10-56	P.227	Reciprocating forward limit time	0~3600.0s	0.0s	148
10-57	P.228	Reciprocating reverse limit time	0~3600.0s	0.0s	148


### 5.10.1 DC injection brake

- When stopping the motor, apply DC voltage on motor to stop motor shaft from rotating, users can adjust the motor stop time and braking torque.

Parameter	Name	Default	Setting Range	Content
10-00 P.10	DC brake operating frequency	3.00Hz	0 ~ 120.00Hz	---
10-01 P.11	DC brake operating time	0.5s	0 ~ 60.0s	---
10-02 P.12	DC brake operating voltage	4.0%	0 ~ 30.0%	

**Setting** DC brake

- ◆ After sending stop signal (please refer to chapter 4 for basic operation of starting and stopping the motor), output frequency of inverter will gradually decrease. When the output frequency decreases to “DC brake operation frequency (10-00(P.10))”, DC brake will start to operate.
- ◆ During DC braking, inverter will inject DC voltage into the motor coil to lock the motor rotor. This voltage is called “DC brake operating voltage (10-02(P.12))”. The larger the 10-02(P.12) value, the greater the DC braking voltage, and the better the braking ability. However, the braking current will not exceed inverter rated current.
- ◆ Operation of DC braking will maintain a period of time ( 10-01(P.11) value) to overcome the inertia from motor rotation.
- ◆ See figure below:



Note: 1. User must set appropriate values to get the best control characteristic.  
 2. If any one of 10-00(P.10), 10-01(P.11), 10-02(P.12) is set to “0”, DC brake will not operate, when send stop signal, motor may still rotate due to inertia.

## 5.10.2 Zero-speed control

### ➤ Zero-speed function selection

Parameter	Name	Default	Setting Range	Content
10-03 P.151	Zero-speed control function selection	0	0	Off.
			1	DC voltage braking
10-04 P.152	Voltage at zero-speed control	5.0%	0 ~ 30.0%	

### Setting Zero-speed control

- ◆ Make sure to set 01-11(P.13) (start frequency) to zero when using this function.

Note: 1. If set 10-04(P. 152) to 6%, output voltage of zero speed is 6% of 01-04(P. 19) (base frequency voltage).

## 5.10.3 DC injection brake before start


- Before operation, motor may be in rotating state due to external force or inertia. If inverter suddenly start operation, the output current may be too large, causing motor damage or trigger driver protection.

Parameter	Name	Default	Setting Range	Content
10-05 P.242	DC brake before inverter start	0	0	Off
			1	Before starting operate DC brake first.
10-06 P.243	DC brake time before inverter start	0.5s	0 ~ 60.0s	---
10-07 P.244	DC brake voltage before inverter start	4.0%	0 ~ 30.0%	

### Setting DC injection brake before start

- ◆ If 10-05(P. 242)=0, DC brake function before start will be off. If 10-05(P. 242)=1, DC brake before start is on, when inverter start, it will inject DC voltage (with 10-07(P. 244) value) into the motor coil to lock the rotor. DC brake will maintain for a period of time (10-06(P. 243) value) before motor starts to run.

See figure below:




### 5.10.4 Restart mode selection

➤ Select suitable start mode according to different load conditions.


Parameter	Name	Default	Setting Range	Content
10-08 P.150	Restart mode selection	0	x0	No frequency search.
			x1	Reserved
			x2	Decrease voltage mode
			0x	Power on once.
			1x	Start each time.
			2x	Only instantaneous stop and restart
10-09 P.57	Restart idling time	99999	0 ~ 30.0s	---
			99999	Off.
10-10 P.58	Restart rising time	10.0s	0 ~ 60.0s	

#### Setting Restart mode selection

◆ 10-08(P.150) is set by 2 bits. The meaning of each bit is as follows:



- ◆ During motor operation, when instantaneous power interruption occur inverter will stop output immediately. If 10-09(P.57)=99999, inverter will not restart automatically after power is restored; If 10-09(P.57)=0.1~30, when power is restored, inverter will automatically restart the motor after idling for a period of time (10-09(P.57) value).
- ◆ When restarting the motor automatically, output frequency is target frequency, but output voltage is zero and then slowly rises to the proper voltage value. This voltage rise time is called “Restart rising time (10-10(P.58))”.



Note:1. 10-08(P.150) must also be set if need instant restart function.  
 2. If 10-08(P.150) is not 0, in default inverter do linear acceleration and deceleration.




### 5.10.5 Remote setting function selection

- If operation box is located away from control cabinet, without analog signal, variable speed can still be realized through digital input.

Parameter	Name	Default	Setting Range	Content
10-11 P.61	Remote control function	0	0	0: Off
			X1	Remote control function, frequency save in memory
			X2	Remote control function, frequency won't save
			X3	Remote control function, frequency won't save, clear frequency setting every time STF/STR "turn off".
			X4	Remote control function, frequency save in memory every 5s
			1X	Frequency command range 01-01(P.2)~01-00(P.1), frequency command value from RH,RM setting

#### Setting Remote setting function


- ◆ In external mode, combined mode 1, combined mode 5, use digital input to change output frequency.
- ◆



#### ◆ Remote function setting

1. 10-11(P.61) decides remote function and ways to save frequency.

Set 10-11(P.61) = X1~X4 ( remote control function on ), terminal RM, RH, RL will be accelerate (RH), decelerate (RM) and clear (RH).See following figure:



2. If 10-11 (P.61)=1~4, the target frequency of inverter = (frequency set during RH and RM operation + external

## Application parameter group 10

---

set frequency other than multi-speed/PU set frequency);

If 10-11 (P.61)=11~14, the target frequency of inverter = frequency set during RH and RM operation.

### ◆ Frequency save

The frequency save function is to store the remote function frequency (the frequency set by RH, RM operation) in the memory (EEPROM), once the power is turned off then restart, inverter will run to frequency save value (10-11 (P.61) = X1/X4).

< Frequency save memory condition >


10-11(P.61) = X1

1. The frequency when start signal (STF/STR) is "off";
2. When RH (acceleration) and RM (deceleration) are both "off", the remote control setting frequency is stored every 1 minute (If RL is triggered will not write);


10-11(P.61) = X4

1. The frequency when RH (acceleration) and RM (deceleration) signals are both "off";
2. Store the remote control setting frequency once every 5s (If RL is triggered will not write);

Note: 1. When 10-11(P.61) = 0X frequency can be controlled by RH (accelerate) and RM (decelerate) between 0 and (maximum frequency – frequency set by main speed). Output frequency is limited by 01-00(P.1).



2. When 10-11 (P.61) = 1X, the adjustable frequency range through RH (acceleration) and RM (deceleration) is 01-01(P.2)~01-00(P.1), and output frequency is limit by 01-00 (P.1).



3. When acceleration/deceleration signal "on", acceleration/deceleration time is set by 01-40 (P.219).

4. If start signal (STF/STR) is "off" but RH (accelerate) or RM (decelerate) is "on", target frequency will still change.

5. When the start signal (STF/STR) changes from "on" to "off", if the frequency changes from the RH and RM signals are frequently required, please turn off frequency save function (10-11 (P.61) )=X2/X3). If it's turn on (10-11(P.61)=X1/X4), the lifespan of the EEPROM will be shortened due to frequent writing.

6. RH, RM and RL mentioned in this paragraph are the function names of "multi-function digital input terminals". If the terminal assignment is changed, other functions may be affected. Please confirm the functions of each terminal before modifying. For details, please refer to 03-00(P.83), 03-01(P.84), 03-03(P.80), 03-04(P.81).

## 5.10.6 Auto reset function

➤ This function allows inverter to reset itself and restart when alarm occurs. Choose which alarm to reset.

Parameter	Name	Default	Setting Range	Content
10-12 P.65	Auto reset function	0	0	Off.
			1	When over-voltage, inverter will reset.
			2	When over-current, inverter will reset.
			3	When either over-voltage or over-current, inverter will reset.
			4	When any alarm occurs, inverter will reset.
10-13 P.67	Auto reset times	0	0	Off.
			1 ~ 10	If the alarm exceeds 10-13(P.67) times, inverter will not reset.
10-14 P.68	Auto reset waiting time	6.0s	0 ~ 360.0s	---
10-15 P.69	Auto reset times count	0	Read only	---

### Setting Auto reset function

- ◆ After alarm occur, inverter returns to the state before alarm, which is called “auto reset”.
- ◆ The auto reset of inverter is conditional. If alarm occurs and inverter auto reset, but the alarm occurs again within the time (10-14(P.68)\*5), then this type of alarm is called “continuous alarm”. If the continuous alarm exceeds a certain number of times, it means that there is a major fault, and this number is called “Auto reset times (10-13) (P.67)”. At this time, inverter will no longer perform auto reset, and need manual troubleshooting by user.
- ◆ If all alarms do not belong to “continuous alarm”, inverter can perform auto reset for an unlimited number of times.
- ◆ The time between the occurrence of alarm and auto reset is called “Auto reset waiting time”.
- ◆ For each auto reset, 10-15(P.69) value will automatically add 1. Therefore, 10-15(P.69) value read from memory represents the number of auto reset.
- ◆ If set parameter 10-15(P.69)=0, auto reset times can be cleared.

Note: The inverter will perform retry only after the retry waiting time of 10-14(P.68). Therefore when using this function, please be aware of the possible danger when operating the inverter.

### 5.10.7 Forward and reverse rotation dead time


- During the process of inverter output forward -reverse transition, set the transition time at 0Hz.

Parameter	Name	Default	Setting Range	Content
10-16 P.119	Forward and reverse rotation dead time	0.0s	0	Off.
			0.1~3000.0s	Waiting and holding time during forward -reverse switch, after inverter output frequency drops to zero.

#### Setting Dead time of forward-reverse rotation

- ◆ Dead time of forward -reverse rotation refers to the waiting and holding time of inverter. During this period of time, inverter will transit from the current direction to the reverse direction upon receiving a reverse run command, and its output frequency will drop to zero.

The diagram is as follows:



### 5.10.8 Energy-saving function V/F

- In energy-saving mode, in order to minimize inverter output power in constant speed operation, inverter will automatically control the output voltage.

Parameter	Name	Default	Setting Range	Content
10-17 P.159	Energy-saving control function	0	0	Off.
			1	Energy-saving mode.

#### Setting Energy-saving mode

- ◆ In energy-saving mode, in order to minimize inverter output power in constant speed operation, inverter will automatically control the output voltage.

Note: 1. If selecting energy-saving operation mode, deceleration time may be longer than the set value. In addition, compared with constant torque load, overvoltage will more likely to occur, please set the deceleration time relatively longer.  
2. For heavy-duty or frequent acceleration/ deceleration applications, energy saving effect may not be very good.

### 5.10.9 Dwell function V/F

➤ During acceleration /deceleration, this function can solve the backlash problem caused by stopping acceleration /deceleration, through frequency and time set by this parameters.

Parameter	Name	Default	Setting Range	Content
10-18 P.229	Dwell function selection	0	0	None.
			1	Backlash compensation function.
			2	Stop acceleration and deceleration waiting function.
10-19 P.230	Dwell frequency at acceleration	1.00Hz	0 ~ 599.00Hz	Set the stopping frequency and time of Dwell function.
10-20 P.231	Dwell time at acceleration	0.5s	0 ~ 360.0s	
10-21 P.232	Dwell frequency at deceleration	1.00Hz	0 ~ 599.00Hz	Set the stopping frequency and time of Dwell function.
10-22 P.233	Dwell time at deceleration	0.5s	0 ~ 360.0s	

#### Setting Dwell function


#### ◆ Backlash compensation ( 10-18(P.229)="1")

The gears of the reducer have biting backlash, and there is an empty section between forward and reverse rotation. This unloaded segment is called backlash, and even if the motor rotates, it will not produce a mechanical following state.

Specifically, when switching the direction of rotation and changing from constant speed operation to deceleration operation, the motor shaft generates excessive torque, and the motor current rapidly increases or becomes a regenerative state.

To avoid backlash, the acceleration and deceleration are temporarily interrupted during acceleration and deceleration. The frequency and time of interrupting acceleration and deceleration are set by 10-18 (P.229) ~ 10-22 (P.233).

As shown in the following diagram:




Note: After setting backlash compensation, only the interruption time in acceleration and deceleration time will become longer.

◆ Acceleration and deceleration interrupt waiting function ( 10-18(P.229)="2")

When 10-18 (P.229) = "2", enable acceleration and deceleration interrupt waiting function. When accelerating to the frequency set in 10-19 (P.230), wait for the time set in 10-20 (P.231) before accelerating to the target; when decelerating to the frequency set in 10-21 (P.232), wait for the time set in 10-22 (P.233) before decelerating to the target.

As shown in the following diagram:



Note: After setting backlash compensation, only the interruption time in acceleration and deceleration time will become longer.

### 5.10.10 Triangular wave function V/F


➤ According to a certain period, through triangular wave makes output frequency oscillate.

Parameter	Name	Default	Setting Range	Content
10-23 P.234	Triangular wave function selection	0	0	Off
			1	If terminal function TRI is triggered, triangular wave function will on.
			2	Triangular wave function is on at all time.
10-24 P.235	Maximum amplitude	10.0%	0 ~ 25.0%	---
10-25 P.236	Amplitude compensation for deceleration	10.0%	0 ~ 50.0%	---
10-26 P.237	Amplitude compensation for acceleration	10.0%	0 ~ 50.0%	---
10-27 P.238	Amplitude acceleration time	10.00s	0 ~ 360.00s/ 0 ~ 3600.0s	When 01-08(P.21)=0, the unit of 10-27(P.238) and 10-28(P.239) is 0.01s.
10-28 P.239	Amplitude deceleration time	10.00s	0 ~ 360.00s/ 0 ~ 3600.0s	When 01-08(P.21)=1, the unit of 10-27(P.238) and 10-28(P.239) is 0.1s.

**Setting**

Triangular wave function

- ◆ If 10-23(P.234) set to 1, triangular wave function will be on when terminal function TRI is triggered. Please set one of 03-00(P.83)、03-01(P.84)、03-03(P.80)、03-04(P.81) as “36”, and then give TRI signals to the digital input terminal.
- ◆ If 10-23(P.234) set to 2, triangular wave function will be on all the time.



Note: 1. Output frequency is limited by the upper and lower frequency limits in triangular wave operation.  
 2. If the values of amplitude compensation 10-25(P.236) and 10-26(P.237), are too large, overvoltage trip and stall prevention protection will trigger.

5.10.11 Voltage stall action level

- This parameter is used to set the voltage stall action discrimination level

Parameter	Name	Default	Setting Range	Content
10-46 P.268	Voltage stall level	380V	155 ~ 400V	220V model
		760V	310 ~ 800V	440V model

**Setting**

Voltage stall action level

- ◆ When the inverter's DC bus voltage is higher than the setting of 10-46 (P.268), the inverter is in voltage stall state.

5.10.12 Reciprocating machine function


- Special functions for reciprocating machine according to customer needs.

Parameter	Name	Default	Setting Range	Content
10-55 P.226	Reciprocating machine function selection	0	0	Off
			1	Turn on reciprocating machine function
10-56 P.227	Reciprocating forward limit time	0.0s	0 ~ 3600.0s	Run forward for more than 10-56 (P.227) time, inverter will decelerate to stop. When set to 0, this function is invalid.
10-57 P.228	Reciprocating reverse limit time	0.0s	0 ~ 3600.0s	Run reverse for more than 10-57(P.228) time, inverter will decelerate to stop. When set to 0, this function is invalid.

**Setting**


Reciprocating machine function





System wiring diagram

- ◆ Please wire according to the above diagram, connect a limit switch between M0 and SD, M1 and SD, and connect a pulse switch between STF and SD, STR and SD.
- ◆ Power on the inverter, execute parameter 00-02=3 (P.998=1), set parameter 10-55 (P.226) to 1, turn on reciprocating machine function. The multi-function terminal settings are all factory settings no need to change value. If target frequency is given by external terminal, the M0 and M1 terminals will affect the target frequency, so please set the value of 04-01 (P.5) and 04-02 (P.6) to the same as target frequency .
- ◆ When K3 and K4 are both in off state, press K1 and inverter forward turn to trigger K3 once, then inverter reverse turn to trigger K4 once and then turn forward, reciprocating. If press K2 the system stops running.
- ◆ When K3 (or K4) is in off state, press K1 and it will reverse (or forward) until trigger K4 (or K3) once and then forward (or reverse). If press K2 the system stops running.
- ◆ To prevent dangerous situations caused by the failure of the limit switch, additional one-way running time: reciprocating forward/reverse limit time is added. Two limit switches are not allowed to be closed at the same time. If they are closed at the same time, the system will stop running.



Operation diagram

## 5.11 Special Adjustment Parameter Group 13

Group	Parameter Number	Name	Setting Range	Default	Page
13-00	P.89	Slip compensation coefficient	0 ~ 10	0	150
13-01	P.246	Modulation coefficient	0.00 ~ 1.20	0.50	150
13-03	P.286	High frequency vibration Suppression factor	0 ~ 15	0	151
13-04	P.283	Current detection method	0 ~ 2	2	151

## 5.11.1 Slip Compensation V/F

- This parameter can set the compensation frequency so that the motor running speed at the rated current can be closer to the set speed, thereby improving the accuracy of speed control.

Parameter	Name	Default	Setting Range	Content
13-00 P.89	Slip compensation coefficient	0	0 ~ 10	Execute slip compensation with target frequency as standard. The quantity of compensation set to 10 is 3% of target frequency.

Note : 1. At the process of slip compensation, the output frequency may be larger than the set frequency.

## 5.11.2 Modulation coefficient

- It is used to determine the ratio of the maximum output voltage to the input voltage

Parameter	Name	Default	Setting Range	Content
13-01 P.246	Modulation coefficient	0.50	0.00 ~ 1.20	---

 Modulation coefficient


- ◆ This parameter can be used to obtain the maximum output voltage higher than the input voltage. However, if the set value is higher, the waveform of the output voltage will be distorted and contain harmonic waves, thus increasing the torque harmonics and noise of the motor.

Note:It's typically fine to use the default value.

### 5.11.3 Vibration inhibition

- It is used to suppress the large fluctuation of inverter output current, large fluctuation of motor speed and motor vibration.

Parameter	Name	Default	Setting Range	Content
13-03 P.286	High frequency vibration inhibition factor	0	0 ~ 15	If the motor vibrates at a higher frequency, adjust the set value of 13-03 (P.286). It is recommended to gradually increase the set value based on the increment of 1.

 Setting Vibration inhibition factor

- ◆ In practical applications, the frequency range where the vibration occurs is usually lower than or higher than half of the rated frequency of the motor to distinguish as "low frequency vibration " or "high frequency vibration ", that is:

If the rated frequency of the motor nameplate is 50Hz,

If the frequency of oscillation is lower than 25Hz, it is considered as "low frequency vibration:".


If the frequency of oscillation is higher than 25Hz, it is considered to be "high frequency vibration ".

Note: The motor current will fluctuate in a certain operating frequency band under light load conditions, which may cause slight vibration of the motor. If it does not cause application impact, it can be ignored.

### 5.11.4 Current detection option

- Current detection option

Parameter	Name	Default	Setting Range	Content
13-04 P.283	Current detection option	2	0~2	

 Setting Current detection option

Note:It's typically fine to use the default value.

## 5.12 User registered parameter 15

Group	Parameter Number	Name	Setting Range	Default	Page
15-00	P.900	User registered parameter 1	P parameter mode: 0~399 Parameter group mode: 00-00~13-99	99999	153
15-01	P.901	User registered parameter 2		99999	153
15-02	P.902	User registered parameter 3		99999	153
15-03	P.903	User registered parameter 4		99999	153
15-04	P.904	User registered parameter 5		99999	153
15-05	P.905	User registered parameter 6		99999	153
15-06	P.906	User registered parameter 7		99999	153
15-07	P.907	User registered parameter 8		99999	153
15-08	P.908	User registered parameter 9		99999	153
15-09	P.909	User registered parameter 10		99999	153
15-10	P.910	User registered parameter 11		99999	153
15-11	P.911	User registered parameter 12		99999	153
15-12	P.912	User registered parameter 13		99999	153
15-13	P.913	User registered parameter 14		99999	153
15-14	P.914	User registered parameter 15		99999	153
15-15	P.915	User registered parameter 16		99999	153
15-16	P.916	User registered parameter 17		99999	153
15-17	P.917	User registered parameter 18		99999	153
15-18	P.918	User registered parameter 19		99999	153
15-19	P.919	User registered parameter 20		99999	153

## 5.12.1 User registered parameter

- The user parameter group is used to register the number of the parameter that does not require the user to restore the factory default value.

Parameter	Name	Default	Setting Range	Content
15-00 P.900	User registered parameter 1	99999	P mode: 0 ~ 399 Parameter group mode: 00-00~13-99	---
15-01 P.901	User registered parameter 2	99999		---
15-02 P.902	User registered parameter 3	99999		---
15-03 P.903	User registered parameter 4	99999		---
15-04 P.904	User registered parameter 5	99999		---
15-05 P.905	User registered parameter 6	99999		---
15-06 P.906	User registered parameter 7	99999		---
15-07 P.907	User registered parameter 8	99999		---
15-08 P.908	User registered parameter 9	99999		---
15-09 P.909	User registered parameter 10	99999		---
15-10 P.910	User registered parameter 11	99999		---
15-11 P.911	User registered parameter 12	99999		---
15-12 P.912	User registered parameter 13	99999		---
15-13 P.913	User registered parameter 14	99999		---
15-14 P.914	User registered parameter 15	99999		---
15-15 P.915	User registered parameter 16	99999		---
15-16 P.916	User registered parameter 17	99999		---
15-17 P.917	User registered parameter 18	99999		---
15-18 P.918	User registered parameter 19	99999		---
15-19 P.919	User registered parameter 20	99999		---



### User registered parameter

- ◆ The parameter values set in this parameter group will not be restored to the factory default value when performing 00-02=5/6 ( P.999=2/3 )
- ◆ The parameter value set in this parameter group is the parameter number required to be registered by the user. The parameter values of the registered parameter number will not be restored to the factory default value when performing 00-02=5/6 ( P.999=2/3 )
- ◆ Please refer to 5.1.2 parameter management section for the setting of restoring the factory default value.

## 6. INSPECTION AND MAINTENANCE

### 6.1 Inspection item

#### 6.1.1 Daily inspection item

- Inverter is mainly composed of semiconductor components. In order to prevent faults caused by influence of environment such as temperature, humidity, dust and vibration, or aging and service life of used parts, users must do daily inspections
  1. Whether the surrounding environment for installation is normal (temperature, humidity, dust density around inverter).
  2. Whether the power supply voltage is normal (whether the three-phase voltage between terminals R/L1, S/L2 and T/L3 is normal).
  3. Whether the wirings are firm (whether the external wirings of the main circuit terminal and the control board terminal are firm).
  4. Whether the cooling system is normal (whether there is abnormal sound at the fan operation and whether the connecting wire is firm).
  5. Whether the indicator light is normal (such as LED indicator on control board, LED indicator on keypad and LED on keypad screen).
  6. Whether the motor is running as expected.
  7. Whether there is abnormal vibration, sound or smell at the motor operation.
  - 8 Whether there is liquid leakage in the filter capacitor on the capacitor board.

#### Caution

Pay attention to safety during inspection!

#### 6.1.2 Replacement parts

- Inverter is composed of many electronic components such as semiconductor components.
- Due to the composition or physical characteristics, the following components will age within a certain period of time, thus reducing the inverter performance and even causing faults. Therefore, it is necessary to replace them on a regular basis.
- Use lifetime detection function as a guidance of parts replacement.

Part name	Estimated lifespan	Description
Cooling fan	2 years	For the axle of a fan, the standard lifetime is about 10 – 35 thousand hours. If fan operates 24 hours per day, should be replaced every 2 years.
Capacitor	5 years	Capacitor is an electrolytic capacitor that deteriorates with time. The deterioration level depends on ambient conditions. Generally, it should be replaced every 5 years.
Relay	---	If bad contact occurs, please replace it immediately.

Note: 1. Please send the inverters to the factory for replacement.

2. For the replacement of cooling fan, please refer to section 3.8.

## 6.2 Ways to measure voltage, current, power on main circuit

### 6.2.1 Selecting measurement instruments

- Since inverter voltage and current on input side and output side includes harmonics, measurement data result may vary. Choose the instruments below (with commercial power supply) for measurement.

	Voltage ( V )	Current ( A )	Power ( Kw )
Input side ( R/L1、 S/L2、 T/L3 )	Moving-iron type	Moving-iron type	Electrodynamic type
Output side( U/T1、 V/T2、 W/T3 )	Rectifier type	Moving-iron type	Electrodynamic type

Note: 1. Please pay attention to the instrument range and polarity;  
2. Please pay attention to personal and property safety.

### 6.2.2 Measurement of voltage

- Inverter input side  
Input side voltage has a sine wave and with extremely small distortion, accurate measurement can be made with an ordinary AC meter.
- Inverter output side  
Since the output side voltage has a PWM-controlled rectangular wave, always use a rectifier type voltmeter. A pointer type meter cannot be used to measure the output side voltage as it indicates a value much greater than the actual value.  
A moving-iron type meter indicates an effective value which includes harmonics and therefore the value is larger than that of the fundamental wave.  
The value monitored on keypad is the inverter-controlled voltage itself. Hence, that value is accurate and it is recommended to monitor values (analog output) using keypad.

### 6.2.3 Measurement of current

- Use moving-iron type meters on both the input and output sides of inverter. However, if the carrier frequency exceeds 5kHz, do not use this type of meter since an overcurrent losses produced in the internal metal parts of the meter will increase and may burn. In this case, use an approximate-effective value type.
- Since current on the inverter input side tends to be imbalanced, measure three phases together is recommended. Correct value cannot be obtained by measuring only one or two phases. On the other hand, the unbalanced ratio of each phase of the output side current should be within 10%.
- When a clamp ammeter is used, always use an effective value detection type. A mean value detection type produces a large error and may indicate an extremely smaller value than the actual value. The value monitored on keypad is accurate if the output frequency varies, and it is recommended to monitor values (provide analog output) using the keypad.

### 6.2.4 Measurement of power




- Use digital power meters at the input and output terminals of inverter simultaneously, or use electrodynamic meters at the input and output terminals of inverter simultaneously. Then, measure the power by the 2-power measurement method or the 3-power measurement method. However, the input terminal current tends to be imbalanced, so it is recommended to use 3-power measurement method for measurement.

### 6.2.5 Measurement of insulation resistance

➤ Inverter insulation resistance


1. Before measuring the inverter insulation resistance, first dismount the wiring of all the main-circuit terminals and control board. Then do the wiring as shown in the right picture
2. The measurement is only suitable for the main circuit. It is prohibited to use a high-resistance meter for measuring terminals on the control board.
3. The value of the insulation resistance shall be greater than 5MΩ.



Note: Please use a 500 VDC megger.

➤ Motor insulation resistance

1. Before the measurement, please dismount the motor, and execute the wiring as shown in the diagram on the right.
2. The value of the insulation resistance shall be greater than 5MΩ



Note: Please use a suitable megger.

### 6.2.6 Hi-pot test

- Do not conduct a hi-pot test. Deterioration may occur on the internal semiconductor components of the inverter

## 7. Appendix

### 7.1 Appendix 1 Parameter table

#### 7.1.1 Parameter in p sequence

Parameter Number	Group	Name	Setting Range	Default	Page
P.0	01-10	Torque boost	0 ~ 30.0% : 0.75K and under	6.0%	66
			0 ~ 30.0% : 1.5K ~ 2.2K	4.0%	
P.1	01-00	Maximum frequency	0.00 ~ 01-02 ( P.18 ) Hz	120.00Hz	61
P.2	01-01	Minimum frequency	0 ~ 120.00Hz	0.00Hz	61
P.3	01-03	Base frequency	50Hz system setting: 0 ~ 599.00Hz	50.00Hz	62
			60Hz system setting: 0 ~ 599.00Hz	60.00Hz	
P.4	04-00	Speed 1 (high speed)	0 ~ 599.00Hz	60.00Hz	99
P.5	04-01	Speed 2 (medium speed)	0 ~ 599.00Hz	30.00Hz	99
P.6	04-02	Speed 3 (low speed)	0 ~ 599.00Hz	10.00Hz	99
P.7	01-06	Acceleration time	0 ~ 360.00s/0 ~ 3600.0s	5.00s	63
P.8	01-07	Deceleration time	0 ~ 360.00s/0 ~ 3600.0s	5.00s	63
P.9	06-00	Electronic thermal relay capacity	0~500.00A	0.00	107
P.10	10-00	DC brake operating frequency	0 ~ 120.00Hz	3.00Hz	138
P.11	10-01	DC brake operating time	0 ~ 60.0s	0.5s	138
P.12	10-02	DC brake operating voltage	0 ~ 30.0%	4.0%	138
P.13	01-11	Starting frequency	0 ~ 60.00Hz	0.50Hz	66
P.14	01-12	Load pattern selection	0: For constant torque loads (conveyor belt, etc.)	0	66
			1: For variable torque loads (fans and pumps, etc.)		
			2, 3: For Lifting loads		
			4: Multipoint V/F curve		
			5~13: Special two-point V/F curve		
P.15	01-13	JOG frequency	0 ~ 599.00Hz	5.00Hz	69
P.16	01-14	JOG Acc/ Dec time	0 ~ 360.00s/0 ~ 3600.0s	0.50s	69
P.17	02-20	Terminal 3-5 signal range selection	0: Signal sampling range from 4~20mA.	1	79
			1: Signal sampling range from 0 ~ 10V.		
			2: Signal sampling range from 0 ~ 5V.		
P.18	01-02	High-speed maximum frequency	01-00 ( P.1 ) ~ 599.00Hz	120.00Hz	62
P.19	01-04	Base voltage	0 ~ 1000.0V	99999	63
			99999: Change according to the input voltage		
P.20	01-09	Acceleration/deceleration reference frequency	50Hz system setting: 1.00 ~ 599.00Hz	50.00Hz	63
			60Hz system setting: 1.00 ~ 599.00Hz	60.00Hz	
P.21	01-08	Acceleration/deceleration time increments	0: Time increment is 0.01s	0	63
			1: Time increment is 0.1s		
P.22	06-01	Stall prevention operation level	0 ~ 200%	150.0%	108

Appendix 1 Parameter table

Parameter Number	Group	Name	Setting Range	Default	Page
P.23	06-02	Stall prevention operation level correction factor	0 ~ 200%	99999	108
			99999: Stall prevention operation level is the setting value of 06-01(P.22).		
P.24	04-03	Speed 4	0 ~ 599.00Hz	99999	99
			99999: Off		
P.25	04-04	Speed 5	Same as 04-03	99999	99
P.26	04-05	Speed 6	Same as 04-03	99999	99
P.27	04-06	Speed 7	Same as 04-03	99999	99
P.28	01-15	Output frequency filter time	0 ~ 31	0	70
P.29	01-05	Acceleration/deceleration curve selection	0: Linear acceleration /deceleration curve	0	63
			1: S shape acceleration /deceleration curve 1		
			2: S shape acceleration /deceleration curve 2		
			3: S shape acceleration /deceleration curve 3		
P.31	00-12	Soft-PWM carrier function selection	0: Off	0	54
			1: When 00-11(P.72)<5, Soft-PWM is on(only apply to V/F control)		
			2 : When 00-11(P.72) > 9, if the IGBT temperature is high, carrier frequency will decrease automatically, when temperature go back to normal, carrier frequency go back to 00-11(P.72) value		
P.32	07-02	Serial communication baud rate	0 : baud rate :4800bps	1	114
			1 : baud rate :9600bps		
			2 : baud rate :19200bps		
			3 : baud rate :38400bps		
P.33	07-00	Communication protocol selection	0 : Modbus protocol	1	114
			1 : Shihlin protocol		
P.34	07-11	Communication EEPROM write-in selection	0 : When writing parameters in communication mode, write in RAM and EEPROM	0	129
			1 : When writing parameters through communication, only write into RAM		
P.35	00-19	Communication mode selection	0: In communication mode, run signal and frequency is given by communication.	0	56
			1: In communication mode, run signal and frequency is given by external signal.		
P.36	07-01	Inverter communication station number	0 ~ 254	0	114
P.37	00-08	Speed display	0 : Display output frequency(not mechanical speed)	0.0	51
			0.1~5000.0		
			1~50000		
P.39	02-21	Maximum operation frequency ( Terminal 3-5 input / built-in keypad knob )	50 Hz system:1.00 ~ 599.00Hz	50.00Hz	79
			60 Hz system:1.00 ~ 599.00Hz	60.00Hz	

Appendix 1 Parameter table

Parameter Number	Group	Name	Setting Range	Default	Page
P.41	03-20	Output frequency detection sensitivity	0 ~ 100.0%	10.0%	95
P.42	03-21	Output frequency detection for forward rotation	0 ~ 599.00Hz	6.00Hz	95
P.43	03-22	Output frequency detection for reverse rotation	0 ~ 599.00Hz	99999	95
			99999: Same as the setting of 03-21(P.42)		
P.44	01-22	Second acceleration time	0 ~ 360.00s/0 ~ 3600.0s	99999	72
			99999: Off		
P.45	01-23	Second deceleration time	0 ~ 360.00s/0 ~ 3600.0s	99999	72
			99999: Off		
P.46	01-24	Second torque boost	0 ~ 30.0%	99999	72
			99999: Off		
P.47	01-25	Second base frequency	0 ~ 599.00Hz	99999	72
			99999: Off		
P.48	07-03	Data length	0 : 8bit	0	114
			1 : 7bit		
P.49	07-04	Stop bit length	0 : 1bit	0	114
			1 : 2bit		
P.50	07-05	Parity check selection	0 : No parity check	0	114
			1 : Odd		
			2 : Even		
P.51	07-06	CR/LF selection	1 : CR only	1	114
			2 : Both CR and LF		
P.52	07-08	Number of communication retries	0 ~ 10	1	114
P.53	07-09	Communication interval allowed time	0 ~ 999.8s : Check communication timeout with the set value	99999	114
			99999 : No timeout check		
P.56	02-52	Inverter rated current display level	0~500.00A	According to kW	84
P.57	10-09	Restart idling time	0 ~ 30.0s	99999	140
			99999: Off.		
P.58	10-10	Restart rising time	0 ~ 60.0s	10.0s	140
P.59	00-10	Built-in keypad set target frequency selection	XXX0: Use up down button on built-in or external keypad to set frequency	0	52
			XXX1: Use keypad knob on external keypad to set frequency		
			XXX2 : Use keypad knob on built-in keypad to set frequency		
			X0XX: Every frequency change will save after 30s		
			X1XX: Every frequency change will save after 10s		

Appendix 1 Parameter table

Parameter Number	Group	Name	Setting Range	Default	Page
P.59	00-10	Built-in keypad set target frequency selection	X2XX: Every frequency change will not save	0	52
			0XXX: Set frequency will work immediately when use up down button on built-in keypad		
			1XXX: Set frequency will work after pressing SET when use up down button on built-in keypad		
P.60	02-10	Terminal 3-5 filter time	0 ~ 2000ms	31ms	78
P.61	10-11	Remote control function	0: Off	0	142
			X1 : Remote control function, frequency save in memory		
			X2 : Remote control function, frequency won't save		
			X3 :Remote control function, frequency won't save, clear frequency setting every time STF/STR "turn off".		
			X4: Remote control function, frequency save in memory every 5s		
			1X:Frequency command range 01-01(P.2)~01-00(P.1), frequency command value from RH,RM setting		
P.62	03-23	Zero current detection level	0 ~ 200.0%	5.0%	96
			99999: Off		
P.63	03-24	Zero current detection time	0.05 ~ 100.00s	0.50s	96
			99999: Off		
P.65	10-12	Auto reset function	0: Off.	0	144
			1: When over-voltage, inverter will reset.		
			2: When over-current, inverter will reset.		
			3: When either over-voltage or over-current, inverter will reset.		
			4: When any alarm occurs, inverter will reset.		
P.66	06-03	Stall prevention operation reduction starting frequency	50Hz system: 0 ~ 599.00Hz	50.00Hz	108
			60Hz system: 0 ~ 599.00Hz	60.00Hz	
P.67	10-13	Auto reset times	0: Off.	0	144
			1 ~ 10: If the alarm exceeds 10-13(P.67) times, inverter will not reset.		
P.68	10-14	Auto reset waiting time	0 ~ 360.0s	6.0s	144
P.69	10-15	Auto reset times count	Read only	0	144
P.71	00-13	Idling brake / DC brake	0: Idling brake	1	55
			1: DC brake		
P.72	00-11	Carrier frequency	1~15 kHz	5 kHz	53
P.75	00-14	Stop function selection	0: Press STOP button and inverter stop running in PU and H2 mode	1	55
			1: Press STOP button and inverter stop running in all mode.		
P.76	02-62	Keypad knob on inverter minimum value	0.00~599.00 Hz	0.00Hz	79

Parameter Number	Group	Name	Setting Range	Default	Page
P.77	00-03	Selection of parameters write protection	0: Parameters can be written only when the motor stops.	0	48
			1: Parameters cannot be written.		
			2: Parameters can also be written when the motor is running.		
			3: Parameters cannot be read when in password protection.		
P.78	00-15	Prevent forward/reverse rotation selection	0: Forward/reverse rotation are both permitted.	0	56
			1: Prevent reverse rotation (Giving reverse signal decelerates and stops the motor).		
			2: Prevent forward rotation (Giving forward signal decelerates and stops the motor).		
P.79	00-16	Operation mode selection	0: "PU mode", "external mode" and "Jog mode" are interchangeable.	0	56
			1: "PU mode" and "JOG mode" are interchangeable.		
			2: "External mode" only		
			3: "Communication mode" only		
			4: "Combined mode 1"		
			5: "Combined mode 2"		
			6: "Combined mode 3"		
			7: "Combined mode 4"		
8: "Combined mode 5"					
P.80	03-03	Terminal M0 input function	Same as 03-00	2	89
P.81	03-04	Terminal M1 input function	Same as 03-00	3	89
P.83	03-00	Terminal STF input function	0: STF(Inverter runs forward)	0	89
			1: STR(Inverter runs reverse)		
			2: RL(Multi-speed low speed)		
			3: RM(Multi-speed medium speed)		
			4: RH(Multi-speed high speed)		
			5: Reserved		
			6: External thermal relay actuate		
			7: MRS(Stops inverter output immediately)		
			8: RT(Inverter second function)		
			9: EXT(External JOG)		
			10 : STF+EXJ		
			11 : STR+EXJ		
			12 : STF+RT		
			13 : STR+RT		
			14 : STF+RL		
15 : STR+RL					

Appendix 1 Parameter table

Parameter Number	Group	Name	Setting Range	Default	Page
P.83	03-00	Terminal STF input function	16 : STF+RM	0	89
			17 : STR+RM		
			18 : STF+RH		
			19 : STR+RH		
			20 : STF+RL+RM		
			21 : STR+RL+RM		
			22 : STF+RT+RL		
			23 : STR+RT+RL		
			24 : STF+RT+RM		
			25 : STR+RT+RM		
			26 : STF+RT+RL+RM		
			27 : STR+RT+RL+RM		
			28: RUN(Inverter runs forward)		
			29: STF/STR(use with RUN signal, when ON, motor runs reverse ; when OFF, motor runs forward)		
			30: RES(External reset function)		
			31: STOP(Use as three line control with RUN signal and STF-STR signal)		
			32: REX(Extend multi-speed to 16 levels)		
			33: PO(In "external mode", run programmed operation)		
			34: RES_E (External reset, valid only when alarm.)		
			35: MPO (In "external mode" run manual cycle operation.)		
			36: TRI(Triangle wave function)		
			37 : Reserved		
			38 : Reserved		
39: STF/STR +STOP (Use with RUN signal, when ON, motor runs reverse, when OFF, motor stops then runs forward.)					
40: P_MRS (Stops inverter output immediately by pulse signal input)					
41: PWM set frequency (Only valid with terminal STF and parameter 03-00(P.83))					
42 : Reserved					
43: RUN_EN (Enable digital input terminal operation)					
44: PID_OFF (Enable digital input terminal turning off PID)					
45: Second frequency command source mode					
P.84	03-01	Terminal STR input function	Same as 03-00	1	89
P.85	03-11	Terminal A-C output function	0: RUN(Output when inverter running)	5	93
			1: SU(Output when reach target frequency)		
			2: FU(Output when reach 03-21 03-22 value )		
			3: OL(Output when overload)		



Parameter Number	Group	Name	Setting Range	Default	Page
P.85	03-11	Terminal A-C output function	4: OMD(Output when output current is zero)	5	93
			5: ALARM(Output when alarm)		
			6: PO1(Output when in program operation step)		
			7: PO2(Output when in program operation cycle)		
			8: PO3(Output when in program operation pause)		
			9 : Reserved		
			10 : Reserved		
			11 : OMD1(Output when output current is zero 1)		
			12 : OL2(Output when over torque)		
			13 ~ 16 : Reserved		
			17: RY(Output when inverter is powered on and no alarm)		
			18: Output when it's time for maintenance		
			41: Output when PID feedback signal disconnect		
P.87	03-14	Digital input logic	0 ~ 15	0	93
P.88	03-15	Digital output logic	0 : Terminal A-C output positive logic	0	93
			2 : Terminal A-C output negative logic		
P.89	13-00	Slip compensation coefficient	0 ~ 10	0	153
P.90	00-00	Inverter model	Read only	Read only	44
P.91	01-16	Frequency jump 1A	0 ~ 599.00Hz	99999	70
			99999: Off		
P.92	01-17	Frequency jump 1B	0 ~ 599.00Hz	99999	70
			99999: Off		
P.93	01-18	Frequency jump 2A	0 ~ 599.00Hz	99999	70
			99999: Off		
P.94	01-19	Frequency jump 2B	0 ~ 599.00Hz	99999	70
			99999: Off		
P.95	01-20	Frequency jump 3A	0 ~ 599.00Hz	99999	70
			99999: Off		
P.96	01-21	Frequency jump 3B	0 ~ 599.00Hz	99999	70
			99999: Off		
P.97	00-17	Second target frequency selection	0: Frequency set by built-in keypad	0	56
			1: Frequency set by RS485 communication		
			2: Frequency set by analog input		
P.98	01-26	Middle frequency 1	0 ~ 599.00Hz	3.00Hz	72
P.99	01-27	Output voltage 1 of middle frequency	0 ~ 100.0%	10.0%	72
P.100	04-15	Programmed operation minute / second selection	0: Select minute as the time increment.	1	101
			1: Select second as the time increment.		

Appendix 1 Parameter table

Parameter Number	Group	Name	Setting Range	Default	Page
P.101	04-27	Programmed operation mode speed 1 operating time	0 ~ 6000.0s	0.0s	101
P.102	04-28	Programmed operation mode speed 2 operating time	0 ~ 6000.0s	0.0s	101
P.103	04-29	Programmed operation mode speed 3 operating time	0 ~ 6000.0s	0.0s	101
P.104	04-30	Programmed operation mode speed 4 operating time	0 ~ 6000.0s	0.0s	101
P.105	04-31	Programmed operation mode speed 5 operating time	0 ~ 6000.0s	0.0s	101
P.106	04-32	Programmed operation mode speed 6 operating time	0 ~ 6000.0s	0.0s	101
P.107	04-33	Programmed operation mode speed 7 operating time	0 ~ 6000.0s	0.0s	101
P.108	04-34	Programmed operation mode speed 8 operating time	0 ~ 6000.0s	0.0s	102
P.110	00-06	Built-in keypad monitor selection	0 : When inverter starts, built-in keypad enters monitor mode automatically, screen displays output frequency (with slip compensation ).	2	50
			1 : When inverter starts, built-in keypad displays target frequency.		
			2 : When inverter starts, built-in keypad enters monitor mode automatically, screen displays steady state output frequency		
			3 : When inverter starts, built-in keypad enters monitor mode automatically, screen displays current pressure and feedback pressure of the constant pressure system in percentage		
			4 : When inverter starts, built-in keypad doesn't enter monitor mode but enter the previous mode before power off		
			5 : When inverter starts, built-in keypad enters monitor mode automatically, screen displays current pressure and feedback pressure of the constant pressure system		
P.111	04-35	Programmed operation mode speed 1 Acc/Dec time	0 ~ 600.00s/0 ~ 6000.0s	0.00s	102
P.112	04-36	Programmed operation mode speed 2 Acc/Dec time	0 ~ 600.00s/0 ~ 6000.0s	0.00s	102
P.113	04-37	Programmed operation mode speed 3 Acc/Dec time	0 ~ 600.00s/0 ~ 6000.0s	0.00s	102
P.114	04-38	Programmed operation mode speed 4 Acc/Dec time	0 ~ 600.00s/0 ~ 6000.0s	0.00s	102

Appendix 1 Parameter table

Parameter Number	Group	Name	Setting Range	Default	Page
P.115	04-39	Programmed operation mode speed 5 Acc/Dec time	0 ~ 600.00s/0 ~ 6000.0s	0.00s	102
P.116	04-40	Programmed operation mode speed 6 Acc/Dec time	0 ~ 600.00s/0 ~ 6000.0s	0.00s	102
P.117	04-41	Programmed operation mode speed 7 Acc/Dec time	0 ~ 600.00s/0 ~ 6000.0s	0.00s	102
P.118	04-42	Programmed operation mode speed 8 Acc/Dec time	0 ~ 600.00s/0 ~ 6000.0s	0.00s	102
P.119	10-16	Forward and reverse rotation dead time	0 ~ 3000.0s	0.0s	145
P.120	03-16	Output signal delay time	0 ~ 3600.0s	0.0s	94
P.121	04-16	Run direction in each section	0 ~ 255	0	101
P.122	04-17	Programmed operation cycle selection	0:Off	0	101
			1 ~ 8: Start cycle from the set section.		
P.123	04-18	Programmed operation acceleration / deceleration time setting selection	0: Acceleration time is 01-06(P.7), deceleration time is 01-07(P.8).	0	101
			1: Acceleration and deceleration time is set by 04-35(P.111) ~ 04-42(P.118).		
P.131	04-19	Programmed operation mode speed 1	0 ~ 599.00Hz	0.00Hz	101
P.132	04-20	Programmed operation mode speed 2	0 ~ 599.00Hz	0.00Hz	101
P.133	04-21	Programmed operation mode speed 3	0 ~ 599.00Hz	0.00Hz	101
P.134	04-22	Programmed operation mode speed 4	0 ~ 599.00Hz	0.00Hz	101
P.135	04-23	Programmed operation mode speed 5	0 ~ 599.00Hz	0.00Hz	101
P.136	04-24	Programmed operation mode speed 6	0 ~ 599.00Hz	0.00Hz	101
P.137	04-25	Programmed operation mode speed 7	0 ~ 599.00Hz	0.00Hz	101
P.138	04-26	Programmed operation mode speed 8	0 ~ 599.00Hz	0.00Hz	101
P.141	02-61	Polarity of percentage corresponds to terminal 3-5 current/ voltage signal	0~11	0	79
P.142	04-07	Speed 8	0 ~ 599.00Hz	0.00Hz	99
P.143	04-08	Speed 9	Same as 04-03	99999	99
P.144	04-09	Speed 10	Same as 04-03	99999	99
P.145	04-10	Speed 11	Same as 04-03	99999	99
P.146	04-11	Speed 12	Same as 04-03	99999	99
P.147	04-12	Speed 13	Same as 04-03	99999	99
P.148	04-13	Speed 14	Same as 04-03	99999	99

Appendix 1 Parameter table

Parameter Number	Group	Name	Setting Range	Default	Page
P.149	04-14	Speed 15	Same as 04-03	99999	99
P.150	10-08	Restart mode selection	X0 : No frequency search.	0	140
			X1 : Reserved		
			X2 : Decrease voltage mode		
			0X : Power on once.		
			1X : Start each time.		
			2X : Only instantaneous stop and restart		
P.151	10-03	Zero-speed control function selection	0: Off.	0	139
			1: DC voltage braking		
P.152	10-04	Voltage at zero-speed control	0 ~ 30.0%	5.0%	139
P.153	07-10	Communication alarm action	0 : Alarm and stop freely	1	114
			1 : No alarm and continuing to operation		
P.154	07-07	Modbus communication format	0 : 1、7、N、2 (Modbus, ASCII)	4	114
			1 : 1、7、E、1 (Modbus, ASCII)		
			2 : 1、7、O、1 (Modbus, ASCII)		
			3 : 1、8、N、2 (Modbus, RTU)		
			4 : 1、8、E、1 (Modbus, RTU)		
			5 : 1、8、O、1 (Modbus, RTU)		
			6 : 1、8、N、1 (Modbus, RTU)		
P.155	06-08	Over torque detection level	0 ~ 200.0%	0.0%	110
P.156	06-09	Over torque detection time	0 ~ 60.0s	1.0s	110
P.157	03-17	Digital input terminal filter time	0 ~ 2000	4	94
P.158	03-18	Digital input terminal enable when power on	0: When power on digital terminals work directly	0	95
			1: When power on digital terminals work after switch off then on		
P.159	10-17	Energy-saving control function	0: Off.	0	145
			1: Energy-saving mode.		
P.161	00-07	Multi-function display	0: Output AC voltage (V)	0	50
			1: DC bus voltage. (V)		
			2: Inverter temperature rising accumulation rate (%)		
			3: Target pressure of the constant pressure system (%)		
			4: Feedback pressure of the constant pressure system (%)		
			5: Running frequency (Hz)		
			6: Electronic thermal accumulation rate (%)		
			8: Signal value (mA) of 3-5 input terminals (mA/V).		
			9: Output power (kW).		

Parameter Number	Group	Name	Setting Range	Default	Page
P.161	00-07	Multi-function display	11: Forward reverse rotation signal. 1: forward rotation 2: reverse rotation 0: stop.	0	50
			12: NTC temperature (°C)		
			13 : Motor electronic thermal accumulation rate (%)		
			14~18 : Reserved		
			19: Digital terminal input state		
			20: Digital terminal output state		
			21: Actual working carrier frequency		
P.162	01-28	Middle frequency 2	0 ~ 599.00Hz	99999	72
			99999: Off		
P.163	01-29	Output voltage 2 of middle frequency	0 ~ 100.0%	0.0%	72
P.164	01-30	Middle frequency 3	0 ~ 599.00Hz	99999	72
			99999: Off		
P.165	01-31	Output voltage 3 of middle frequency	0 ~ 100.0%	0.0%	72
P.166	01-32	Middle frequency 4	0 ~ 599.00Hz	99999	72
			99999: Off		
P.167	01-33	Output voltage 4 of middle frequency	0 ~ 100.0%	0.0%	72
P.168	01-34	Middle frequency 5	0 ~ 599.00Hz	99999	72
			99999: Off		
P.169	01-35	Output voltage 5 of middle frequency	0 ~ 100.0%	0.0%	72
P.170	08-00	PID function selection	0: Off	0	131
			2 : Parameter 08-03(P.225) as target value, terminal 3-5 current/voltage input as feedback source		
P.171	08-01	PID feedback control method	0: Negative feedback control.	0	131
			1: Positive feedback control.		
P.172	08-04	Proportional gain	1~100	20	131
P.173	08-05	Integral time	0 ~ 100.0s	1.0s	131
P.174	08-06	Differential time	0 ~ 10000ms	0ms	131
P.175	08-07	Abnormal deviation	0 ~ 100.0%	0.0%	131
P.176	08-08	Abnormal duration time	0 ~ 600.0s	30.0s	131
P.177	08-09	Abnormal processing mode	0: Stop freely	0	131
			1: Slow down to stop		
			2: Alarm and continue operation		
P.178	08-10	Sleep detection deviation	0 ~ 100.0%	0.0%	131
P.179	08-11	Sleep detection duration time	0 ~ 255.0s	1.0s	132
P.180	08-12	Wake-up level	0 ~ 100.0%	90.0%	132
P.181	08-13	Stop level	0 ~ 120.00Hz	40.00Hz	132

Appendix 1 Parameter table

Parameter Number	Group	Name	Setting Range	Default	Page
P.182	08-14	Upper integral limit	50Hz system:0 ~ 120.00Hz	50.00Hz	132
			60Hz system:0 ~ 120.00Hz	60.00Hz	
P.183	08-15	Deceleration step length when stable	0 ~ 10.00Hz	0.50Hz	132
P.184	02-24	Terminal 3-5 disconnect selection	0: Off 1: Inverter decelerates to 0Hz, multi-function digital output terminal set off alarm 2: Inverter stops immediately, and keypad displays "AErr" alarm 3: Inverter runs continuously according to the frequency command before disconnection. Digital output terminal will set off alarm.	0	78
P.185	02-06	Proportional linkage gain	0 ~ 100%	0%	76
P.188	00-01	Firmware version	Read only	---	45
P.189	00-24	50Hz/60Hz switch selection	0: Frequency related parameter default value is 60Hz. 1: Frequency related parameter default value is 50Hz.	0 1	68
P.196	02-27	Percentage corresponds to terminal 3-5 minimum input current/ voltage	0% ~ 100.0%	0.0%	78
P.197	02-28	Percentage corresponds to terminal 3-5 maximum input current/ voltage	0% ~ 100.0%	100.0%	78
P.198	02-25	Terminal 3-5 minimum input current/ voltage	0 ~ 20.00 mA /V	0.00V	78
P.199	02-26	Terminal 3-5 maximum input current/ voltage	0 ~ 20.00 mA/V	10.00V	78
P.204	02-63	PWM signal duty cycle	0: automatically detects the period of input PWM pulse 1~1000ms: set the PWM duty cycle value input into terminal STF	0	84
P.219	01-40	Remote function acc/dec time selection	0 : Use default acc/dec time ( same as regular mode ) 1 : Use second acc/dec time	0	73
P.223	08-18	Analog feedback signal bias	0 ~ 100.0%	0.0%	132
P.224	08-19	Analog feedback signal gain	0 ~ 100.0%	100.0%	132
P.225	08-03	PID target value from keypad	0 ~ 08-43 ( P.251 )	20.0%	131
P.226	10-55	Reciprocating machine function selection	0 : Off 1 : Turn on reciprocating machine function	0	148
P.227	10-56	Reciprocating forward limit time	0~3600.0s	0.0s	148
P.228	10-57	Reciprocating reverse limit time	0~3600.0s	0.0s	148

Appendix 1 Parameter table

Parameter Number	Group	Name	Setting Range	Default	Page
P.229	10-18	Dwell function selection	0: Off.	0	146
			1: Backlash compensation function.		
			2: Acceleration and deceleration interrupt waiting function.		
P.230	10-19	Dwell frequency at acceleration	0 ~ 599.00Hz	1.00Hz	146
P.231	10-20	Dwell time at acceleration	0 ~ 360.0s	0.5s	146
P.232	10-21	Dwell frequency at deceleration	0 ~ 599.00Hz	1.00Hz	146
P.233	10-22	Dwell time at deceleration	0 ~ 360.0s	0.5s	146
P.234	10-23	Triangular wave function selection	0: Off.	0	147
			1: If terminal function TRI is triggered, triangular wave function will on.		
			2: Triangular wave function is on at all time.		
P.235	10-24	Maximum amplitude	0 ~ 25.0%	10.0%	147
P.236	10-25	Amplitude compensation at deceleration	0 ~ 50.0%	10.0%	147
P.237	10-26	Amplitude compensation at acceleration	0 ~ 50.0%	10.0%	147
P.238	10-27	Amplitude acceleration time	0 ~ 360.00s/0 ~ 3600.0s	10.00s	147
P.239	10-28	Amplitude deceleration time	0 ~ 360.00s/0 ~ 3600.0s	10.00s	147
P.240	02-07	Auxiliary frequency	0: Off	0	77
			2: Output frequency = basic frequency + auxiliary frequency (given by terminal 3-5)		
			4: Output frequency = basic frequency - auxiliary frequency (given by terminal 3-5)		
			6: Output frequency = proportional linkage signal (given by terminal 3-5)		
P.242	10-05	DC brake before inverter start	0: Off	0	139
			1: Before starting operate DC brake first.		
P.243	10-06	DC brake time before inverter start	0 ~ 60.0s	0.5s	139
P.244	10-07	DC brake voltage before inverter start	0 ~ 30.0%	4.0%	139
P.246	13-01	Modulation coefficient	0.00 ~ 1.20	0.50	150
P.251	08-43	PID pressure range (Bar) setting	1.0~100.0	100.0	135
P.253	08-45	Analog signal feedback loss detection time	0 ~ 600.0	0.0 s	135
P.254	08-46	Analog signal feedback loss action selection	0 : Alarm AErr and inverter stop freely	0	135
			1 : Slow down to stop then alarm AErr		
			2 : Alarm AErr and continue operation		
P.255	01-36	S curve time at the beginning of acceleration	0 ~ 25.00s/0 ~ 250.0s	0.20s	73
P.256	01-37	S curve time at the end of acceleration	0 ~ 25.00s/0 ~ 250.0s	99999	73
			99999: Off		

Appendix 1 Parameter table

Parameter Number	Group	Name	Setting Range	Default	Page
P.257	01-38	S curve time at the beginning of deceleration	0 ~ 25.00s/0 ~ 250.0s	99999	73
			99999: Off		
P.258	01-39	S curve time at the end of deceleration	0 ~ 25.00s/0 ~ 250.0s	99999	73
			99999: Off		
P.259	00-09	Speed display unit selection	0: Speed display unit is 1	1	51
			1: Speed display unit is 0.1		
P.260	06-10	Action when detect over torque	0: OL2 alarm will not be reported after over torque detection, and inverter keeps running.	1	110
			1: OL2 alarm will be reported after over torque detection, and inverter stops.		
P.261	06-17	Maintenance alarm function	0: Off	0	111
			1 ~ 9998day: Used to set the time for maintenance alarm output signal		
P.268	10-46	Voltage stall level	220V : 155 ~ 400V	380V	148
			440V : 310 ~ 800V	760V	
P.280	06-18	Short circuit protection function	X0: Turn off short circuit to ground detect when inverter start	10	111
			X1: Short circuit to ground detect when inverter start		
			0X: Turn off output short circuit,		
			1X: When output short circuit, built-in keypad shows SCP alarm and inverter stops		
P.281	06-13	Input phase loss protection	0: Off	0	111
			1: When input phase loss, built-in keypad shows IPF alarm and inverter stops		
P.283	13-04	Current detection method	0 ~ 2	2	151
P.286	13-03	High frequency vibration Suppression factor	0 ~ 15	0	151
P.288	06-40	Alarm record code query	Choose 0 ~ 12 recorded alarm	0	112
P.289	06-41	Alarm record code display	Read only	Read only	112
P.290	06-42	Alarm record message query	Choose 0 ~ 10 recorded alarm	0	112
P.291	06-43	Alarm record message display	Read only	Read only	112
P.292	06-27	Total inverter operation time (minutes)	0 ~ 1439 min	0 min	111
P.293	06-28	Total inverter operation time (days)	0 ~ 9999 day	0 day	111
P.294	00-04	Password parameter	0~65535	0	48
P.295	00-05	Password setup	2~65535	0	48
P.296	06-29	Total inverter power on time (minutes)	0 ~ 1439 min	0 min	111
P.297	06-30	Total inverter power on time (days)	0 ~ 9999 day	0 day	111



Parameter Number	Group	Name	Setting Range	Default	Page
P.300	00-21	Motor control mode selection	0: Induction motor V/F control	0	57
			1: Reserved		
			2: Reserved		
P.302	05-01	Motor rated power	0 ~ 160.00kW	0.00kW	105
P.303	05-02	Motor poles	0 ~ 48	4	105
P.304	05-03	Motor rated voltage	0 ~ 510V	According to voltage	105
P.305	05-04	Motor rated frequency	50Hz system : 0 ~ 599.00Hz	50.00Hz	105
			60Hz system : 0 ~ 599.00Hz	60.00Hz	
P.306	05-05	Motor rated current	0~500.00A	According to kw	105
P.307	05-06	Motor rated rotation speed	50Hz system:0 ~ 9998r/min	1410r/min	105
			60Hz system: 0 ~ 9998r/min	1710r/min	
P.308	05-07	Motor excitation current	0~500.00A	According to kw	105
P.309	05-08	IM motor stator resistance	0 ~ 99.98Ω	According to kw	105
P.900	15-00	User registered parameter 1	P mode: 0 ~ 399 Parameter group mode: 00-00~13-99	99999	153
P.901	15-01	User registered parameter 2		99999	153
P.902	15-02	User registered parameter 3		99999	153
P.903	15-03	User registered parameter 4		99999	153
P.904	15-04	User registered parameter 5		99999	153
P.905	15-05	User registered parameter 6		99999	153
P.906	15-06	User registered parameter 7		99999	153
P.907	15-07	User registered parameter 8		99999	153
P.908	15-08	User registered parameter 9		99999	153
P.909	15-09	User registered parameter 10		99999	153
P.910	15-10	User registered parameter 11		99999	153
P.911	15-11	User registered parameter 12		99999	153
P.912	15-12	User registered parameter 13		99999	153
P.913	15-13	User registered parameter 14		99999	153
P.914	15-14	User registered parameter 15		99999	153
P.915	15-15	User registered parameter 16		99999	153
P.916	15-16	User registered parameter 17		99999	153
P.917	15-17	User registered parameter 18		99999	153
P.918	15-18	User registered parameter 19		99999	153
P.919	15-19	User registered parameter 20		99999	153

Appendix 1 Parameter table

Parameter Number	Group	Name	Setting Range	Default	Page
P.990	00-25	Parameter display mode setting	0: Parameter is displayed in "group mode"	0	58
			1: Parameter is displayed in "sequence P mode"		
P.996 ~ P.999	00-02	Parameter restoration	0: Off	0	46
			1: Clear alarm history (P.996=1)		
			2: Reset inverter (P.997=1)		
			3: Restore all parameters to default (P.998=1)		
			4: Restore some parameters to default 1 (P.999=1)		
			5: Restore some parameters to default 2 (P.999=2)		
6: Restore some parameters to default 3 (P.999=3)					

## 7.1.2 Parameter in group

Group	Parameter Number	Name	Setting Range	Default	Page
00-00	P.90	Inverter model	Read only	---	45
00-01	P.188	Firmware version	Read only	---	45
00-02	P.996 ~ P.999	Parameter restoration	0: Off	0	46
			1: Clear alarm history (P.996=1)		
			2: Reset inverter (P.997=1)		
			3: Restore all parameters to default (P.998=1)		
			4: Restore some parameters to default 1 (P.999=1)		
			5: Restore some parameters to default 2 (P.999=2)		
00-03	P.77	Selection of parameters write protection	0: Parameters can be written only when the motor stops.	0	48
			1: Parameters cannot be written.		
			2: Parameters can also be written when the motor is running.		
			3: Parameters cannot be read when in password protection.		
00-04	P.294	Password parameter	0~65535	0	48
00-05	P.295	Password setup	2~65535	0	48
00-06	P.110	Built-in keypad monitor selection	0 : When inverter starts, built-in keypad enters monitor mode automatically, screen displays output frequency (with slip compensation ).	2	50
			1 : When inverter starts, built-in keypad displays target frequency.		
			2 : When inverter starts, built-in keypad enters monitor mode automatically, screen displays steady state output frequency		
			3 : When inverter starts, built-in keypad enters monitor mode automatically, screen displays current pressure and feedback pressure of the constant pressure system in percentage		
			4 : When inverter starts, built-in keypad doesn't enter monitor mode but enter the previous mode before power off		
			5 : When inverter starts, built-in keypad enters monitor mode automatically, screen displays current pressure and feedback pressure of the constant pressure system		
00-07	P.161	Multi-function display	0: Output AC voltage (V)	0	50
			1: DC bus voltage. (V)		
			2: Inverter temperature rising accumulation rate (%)		
			3: Target pressure of the constant pressure system (%)		
			4: Feedback pressure of the constant pressure system (%)		
			5: Running frequency (Hz)		
			6: Electronic thermal accumulation rate (%)		

Appendix 1 Parameter table

Group	Parameter Number	Name	Setting Range	Default	Page
00-07	P.161	Multi-function display	7 : Reserved	0	50
			8: Signal value (mA) of 3-5 input terminals (mA/V).		
			9: Output power (kW).		
			10 : Reserved		
			11: Forward reverse rotation signal. 1: forward rotation 2: reverse rotation 0: stop.		
			12: NTC temperature (°C)		
			13 : Motor electronic thermal accumulation rate (%)		
			14~18 : Reserved		
			19: Digital terminal input state		
			20: Digital terminal output state		
			21: Actual working carrier frequency		
00-08	P.37	Speed display	0 : Display output frequency(not mechanical speed)	0.0	51
			0.1~5000.0		
			1~50000		
00-09	P.259	Speed display unit selection	0: Speed display unit is 1	1	51
			1: Speed display unit is 0.1		
00-10	P.59	Built-in keypad set target frequency selection	XXX0: Use up down button on built-in or external keypad to set frequency	0	52
			XXX1: Use keypad knob on external keypad to set frequency		
			XXX2 : Use keypad knob on built-in keypad to set frequency		
			X0XX: Every frequency change will save after 30s		
			X1XX: Every frequency change will save after 10s		
			X2XX: Every frequency change will not save		
			0XXX: Set frequency will work immediately when use up down button on built-in keypad		
1XXX: Set frequency will work after pressing SET when use up down button on built-in keypad					
00-11	P.72	Carrier frequency	1~15 kHz	5 kHz	53
00-12	P.31	Soft-PWM carrier function selection	0: Off	0	53
			1: When 00-11(P.72)<5,Soft-PWM is on(only apply to V/F control)		
			2 : When 00-11(P.72) > 9, if the IGBT temperature is high, carrier frequency will decrease automatically, when temperature go back to normal, carrier frequency go back to 00-11(P.72) value		
00-13	P.71	Idling brake / DC brake	0: Idling brake	1	55
			1: DC brake		
00-14	P.75	Stop function selection	0: Press STOP button and inverter stop running in PU and H2 mode	1	55
			1: Press STOP button and inverter stop running in all mode.		

Group	Parameter Number	Name	Setting Range	Default	Page
00-15	P.78	Prevent forward/reverse rotation selection	0: Forward/reverse rotation are both permitted.	0	56
			1: Prevent reverse rotation (Giving reverse signal decelerates and stops the motor).		
			2: Prevent forward rotation (Giving forward signal decelerates and stops the motor).		
00-16	P.79	Operation mode selection	0: "PU mode", "external mode" and "Jog mode" are interchangeable.	0	56
			1: "PU mode" and "JOG mode" are interchangeable.		
			2: "External mode" only		
			3: "Communication mode" only		
			4: "Combined mode 1"		
			5: "Combined mode 2"		
			6: "Combined mode 3"		
			7: "Combined mode 4"		
8: "Combined mode 5"					
00-17	P.97	Second target frequency selection	0: Frequency set by built-in keypad	0	56
			1: Frequency set by RS485 communication		
			2: Frequency set by analog input		
00-19	P.35	Communication mode selection	0: In communication mode, run signal and frequency is given by communication.	0	56
			1: In communication mode, run signal and frequency is given by external signal.		
00-21	P.300	Motor control mode selection	0: Induction motor V/F control	0	57
			1: Reserved		
			2: Reserved		
00-24	P.189	50Hz/60Hz switch selection	0: Frequency related parameter default value is 60Hz.	0	58
			1: Frequency related parameter default value is 50Hz.	1	
00-25	P.990	Parameter display mode setting	0: Parameter is displayed in "group mode"	0	58
			1: Parameter is displayed in "sequence P mode"		
01-00	P.1	Maximum frequency	0.00 ~ 01-02 ( P.18 ) Hz	120.00 Hz	61
01-01	P.2	Minimum frequency	0 ~ 120.00Hz	0.00Hz	61
01-02	P.18	High-speed maximum frequency	01-00 ( P.1 ) ~ 599.00Hz	120.00 Hz	61
01-03	P.3	Base frequency	50Hz system setting: 0 ~ 599.00Hz	50.00Hz	62
			60Hz system setting: 0 ~ 599.00Hz	60.00Hz	
01-04	P.19	Base voltage	0 ~ 1000.0V	99999	62
			99999: Change according to the input voltage		
01-05	P.29	Acceleration/deceleration curve selection	0: Linear acceleration /deceleration curve	0	63
			1: S shape acceleration /deceleration curve 1		
			2: S shape acceleration /deceleration curve 2		
			3: S shape acceleration /deceleration curve 3		
01-06	P.7	Acceleration time	0 ~ 360.00s/0 ~ 3600.0s	5.00s	63

Appendix 1 Parameter table

Group	Parameter Number	Name	Setting Range	Default	Page
01-07	P.8	Deceleration time	0 ~ 360.00s/0 ~ 3600.0s	5.00s	63
01-08	P.21	Acceleration/deceleration time increments	0: Time increment is 0.01s	0	63
			1: Time increment is 0.1s		
01-09	P.20	Acceleration/deceleration reference frequency	50Hz system setting: 1.00 ~ 599.00Hz	50.00Hz	63
			60Hz system setting: 1.00 ~ 599.00Hz	60.00Hz	
01-10	P.0	Torque boost	0 ~ 30.0% : 0.75K and under	6.0%	66
			0 ~ 30.0% : 1.5K ~ 2.2K	4.0%	
01-11	P.13	Starting frequency	0 ~ 60.00Hz	0.50Hz	66
01-12	P.14	Load pattern selection	0: For constant torque loads (conveyor belt, etc.)	0	67
			1: For variable torque loads (fans and pumps, etc.)		
			2, 3: For Lifting loads		
			4: Multipoint V/F curve		
			5~13: Special two-point V/F curve		
01-13	P.15	JOG frequency	0 ~ 599.00Hz	5.00Hz	69
01-14	P.16	JOG Acc/ Dec time	0 ~ 360.00s/0 ~ 3600.0s	0.50s	69
01-15	P.28	Output frequency filter time	0 ~ 31	0	69
01-16	P.91	Frequency jump 1A	0 ~ 599.00Hz	99999	70
			99999: Off		
01-17	P.92	Frequency jump 1B	0 ~ 599.00Hz	99999	70
			99999: Off		
01-18	P.93	Frequency jump 2A	0 ~ 599.00Hz	99999	70
			99999: Off		
01-19	P.94	Frequency jump 2B	0 ~ 599.00Hz	99999	70
			99999: Off		
01-20	P.95	Frequency jump 3A	0 ~ 599.00Hz	99999	70
			99999: Off		
01-21	P.96	Frequency jump 3B	0 ~ 599.00Hz	99999	70
			99999: Off		
01-22	P.44	Second acceleration time	0 ~ 360.00s/0 ~ 3600.0s	99999	71
			99999: Off		
01-23	P.45	Second deceleration time	0 ~ 360.00s/0 ~ 3600.0s	99999	71
			99999: Off		
01-24	P.46	Second torque boost	0 ~ 30.0%	99999	71
			99999: Off		
01-25	P.47	Second base frequency	0 ~ 599.00Hz	99999	71
			99999: Off		
01-26	P.98	Middle frequency 1	0 ~ 599.00Hz	3.00Hz	72
01-27	P.99	Output voltage 1 of middle frequency	0 ~ 100.0%	10.0%	72
01-28	P.162	Middle frequency 2	0 ~ 599.00Hz	99999	72
			99999: Off		
01-29	P.163	Output voltage 2 of middle frequency	0 ~ 100.0%	0.0%	72

Group	Parameter Number	Name	Setting Range	Default	Page
01-30	P.164	Middle frequency 3	0 ~ 599.00Hz	99999	72
			99999: Off		
01-31	P.165	Output voltage 3 of middle frequency	0 ~ 100.0%	0.0%	72
01-32	P.166	Middle frequency 4	0 ~ 599.00Hz	99999	72
			99999: Off		
01-33	P.167	Output voltage 4 of middle frequency	0 ~ 100.0%	0.0%	72
01-34	P.168	Middle frequency 5	0 ~ 599.00Hz	99999	72
			99999: Off		
01-35	P.169	Output voltage 5 of middle frequency	0 ~ 100.0%	0.0%	72
01-36	P.255	S curve time at the beginning of acceleration	0 ~ 25.00s/0 ~ 250.0s	0.20s	73
01-37	P.256	S curve time at the end of acceleration	0 ~ 25.00s/0 ~ 250.0s	99999	73
			99999: Off		
01-38	P.257	S curve time at the beginning of deceleration	0 ~ 25.00s/0 ~ 250.0s	99999	73
			99999: Off		
01-39	P.258	S curve time at the end of deceleration	0 ~ 25.00s/0 ~ 250.0s	99999	73
			99999: Off		
01-40	P.219	Remote function acc/dec time selection	0 : Use default acc/dec time ( same as regular mode )	0	75
			1 : Use second acc/dec time		
02-06	P.185	Proportional linkage gain	0 ~ 100%	0%	77
02-07	P.240	Auxiliary frequency	0: Off	0	78
			2: Output frequency = basic frequency + auxiliary frequency ( given by terminal 3-5)		
			4: Output frequency = basic frequency - auxiliary frequency ( given by terminal 3-5)		
			6: Output frequency = proportional linkage signal ( given by terminal 3-5)		
02-10	P.60	Terminal 3-5 filter time	0 ~ 2000ms	31ms	79
02-20	P.17	Terminal 3-5 signal range selection	0: Signal sampling range from 4~20mA.	1	79
			1: Signal sampling range from 0 ~ 10V.		
			2: Signal sampling range from 0 ~ 5V.		
02-21	P.39	Maximum operation frequency ( Terminal 3-5 input / built-in keypad knob )	50 Hz system:1.00 ~ 599.00Hz	50.00Hz	79
			60 Hz system:1.00 ~ 599.00Hz	60.00Hz	
02-24	P.184	Terminal 3-5 disconnect selection	0: Off	0	79
			1: Inverter decelerates to 0Hz, multi-function digital output terminal set off alarm		
			2: Inverter stops immediately, and keypad displays "AErr" alarm		
			3: Inverter runs continuously according to the frequency command before disconnection. Digital output terminal will set off alarm.		

Appendix 1 Parameter table

Group	Parameter Number	Name	Setting Range	Default	Page
02-25	P.198	Terminal 3-5 minimum input current/ voltage	0 ~ 20.00 mA /V	0.00V	79
02-26	P.199	Terminal 3-5 maximum input current/ voltage	0 ~ 20.00 mA/V	10.00V	79
02-27	P.196	Percentage corresponds to terminal 3-5 minimum input current/ voltage	0% ~ 100.0%	0.0%	79
02-28	P.197	Percentage corresponds to terminal 3-5 maximum input current/ voltage	0% ~ 100.0%	100.0%	79
02-52	P.56	Inverter rated current display level	0~500.00A	According to kW	84
02-61	P.141	Polarity of percentage corresponds to terminal 3-5 current/ voltage signal	0~11	0	79
02-62	P.76	Keypad knob on inverter minimum value	0.00~599.00 Hz	0.00Hz	79
02-63	P.204	PWM signal duty cycle	0: automatically detects the period of input PWM pulse 1~1000ms: set the PWM duty cycle value input into terminal STF	0	84
03-00	P.83	Terminal STF input function	0: STF(Inverter runs forward) 1: STR(Inverter runs reverse) 2: RL(Multi-speed low speed) 3: RM(Multi-speed medium speed) 4: RH(Multi-speed high speed) 5: Reserved 6: External thermal relay actuate 7: MRS(Stops inverter output immediately) 8: RT(Inverter second function) 9: EXT(External JOG) 10 : STF+EXJ 11 : STR+EXJ 12 : STF+RT 13 : STR+RT 14 : STF+RL 15 : STR+RL 16 : STF+RM 17 : STR+RM 18 : STF+RH 19 : STR+RH 20 : STF+RL+RM 21 : STR+RL+RM 22 : STF+RT+RL 23 : STR+RT+RL	0	89



Group	Parameter Number	Name	Setting Range	Default	Page
03-00	P.83	Terminal STF input function	24 : STF+RT+RM	0	89
			25 : STR+RT+RM		
			26 : STF+RT+RL+RM		
			27 : STR+RT+RL+RM		
			28: RUN(Inverter runs forward)		
			29: STF/STR(use with RUN signal, when ON, motor runs reverse ; when OFF, motor runs forward)		
			30: RES(External reset function)		
			31: STOP(Use as three line control with RUN signal and STF-STR signal)		
			32: REX(Extend multi-speed to 16 levels)		
			33: PO(In "external mode", run programmed operation)		
			34: RES_E (External reset, valid only when alarm.)		
			35: MPO (In "external mode" run manual cycle operation.)		
			36: TRI(Triangle wave function)		
			37~38 : Reserved		
			39: STF/STR +STOP (Use with RUN signal, when ON, motor runs reverse, when OFF, motor stops then runs forward.)		
			40: P_MRS (Stops inverter output immediately by pulse signal input)		
			41: PWM set frequency (Only valid with terminal STF and parameter 03-00(P.83))		
42 : Reserved					
43: RUN_EN (Enable digital input terminal operation)					
44: PID_OFF (Enable digital input terminal turning off PID)					
45: Second frequency command source mode					
03-01	P.84	Terminal STR input function	Same as 03-00	1	89
03-03	P.80	Terminal M0 input function	Same as 03-00	2	89
03-04	P.81	Terminal M1 input function	Same as 03-00	3	89
03-11	P.85	Terminal A-C output function	0: RUN(Output when inverter running)	5	92
			1: SU(Output when reach target frequency)		
			2: FU(Output when reach 03-21 03-22 value )		
			3: OL(Output when overload)		
			4: OMD(Output when output current is zero)		
			5: ALARM(Output when alarm)		
			6: PO1(Output when in program operation step)		
			7: PO2(Output when in program operation cycle)		
			8: PO3(Output when in program operation pause)		
			9~10 : Reserved		
			11 : OMD1(Output when output current is zero 1)		
			12 : OL2(Output when over torque)		

Appendix 1 Parameter table

Group	Parameter Number	Name	Setting Range	Default	Page
03-11	P.85	Terminal A-C output function	13 ~ 16 : Reserved	5	92
			17: RY(Output when inverter is powered on and no alarm)		
			18: Output when it's time for maintenance		
			41: Output when PID feedback signal disconnect		
03-14	P.87	Digital input logic	0 ~ 15	0	93
03-15	P.88	Digital output logic	0 : Terminal A-C output positive logic	0	93
			2 : Terminal A-C output negative logic		
03-16	P.120	Output signal delay time	0 ~ 3600.0s	0.0s	94
03-17	P.157	Digital input terminal filter time	0 ~ 2000	4	94
03-18	P.158	Digital input terminal enable when power on	0: When power on digital terminals work directly	0	95
			1: When power on digital terminals work after switch off then on		
03-20	P.41	Output frequency detection sensitivity	0 ~ 100.0%	10.0%	95
03-21	P.42	Output frequency detection for forward rotation	0 ~ 599.00Hz	6.00Hz	95
03-22	P.43	Output frequency detection for reverse rotation	0 ~ 599.00Hz	99999	95
			99999: Same as the setting of 03-21(P.42)		
03-23	P.62	Zero current detection level	0 ~ 200.0%	5.0%	96
			99999: Off		
03-24	P.63	Zero current detection time	0.05 ~ 100.00s	0.50s	96
			99999: Off		
04-00	P.4	Speed 1 (high speed)	0 ~ 599.00Hz	60.00Hz	99
04-01	P.5	Speed 2 (medium speed)	0 ~ 599.00Hz	30.00Hz	99
04-02	P.6	Speed 3 (low speed)	0 ~ 599.00Hz	10.00Hz	99
04-03	P.24	Speed 4	0 ~ 599.00Hz	99999	99
			99999: Off		
04-04	P.25	Speed 5	Same as 04-03	99999	99
04-05	P.26	Speed 6	Same as 04-03	99999	99
04-06	P.27	Speed 7	Same as 04-03	99999	99
04-07	P.142	Speed 8	0 ~ 599.00Hz	0.00Hz	99
04-08	P.143	Speed 9	Same as 04-03	99999	99
04-09	P.144	Speed 10	Same as 04-03	99999	99
04-10	P.145	Speed 11	Same as 04-03	99999	99
04-11	P.146	Speed 12	Same as 04-03	99999	99
04-12	P.147	Speed 13	Same as 04-03	99999	99
04-13	P.148	Speed 14	Same as 04-03	99999	99
04-14	P.149	Speed 15	Same as 04-03	99999	99

## Appendix 1 Parameter table

Group	Parameter Number	Name	Setting Range	Default	Page
04-15	P.100	Programmed operation minute / second selection	0: Select minute as the time increment.	1	101
			1: Select second as the time increment.		
04-16	P.121	Run direction in each section	0 ~ 255	0	101
04-17	P.122	Programmed operation cycle selection	0:Off	0	101
			1 ~ 8: Start cycle from the set section.		
04-18	P.123	Programmed operation acceleration / deceleration time setting selection	0: Acceleration time is 01-06(P.7), deceleration time is 01-07(P.8).	0	101
			1: Acceleration and deceleration time is set by 04-35(P.111) ~ 04-42(P.118).		
04-19	P.131	Programmed operation mode speed 1	0 ~ 599.00Hz	0.00 Hz	101
04-20	P.132	Programmed operation mode speed 2	0 ~ 599.00Hz	0.00 Hz	101
04-21	P.133	Programmed operation mode speed 3	0 ~ 599.00Hz	0.00 Hz	101
04-22	P.134	Programmed operation mode speed 4	0 ~ 599.00Hz	0.00 Hz	101
04-23	P.135	Programmed operation mode speed 5	0 ~ 599.00Hz	0.00 Hz	101
04-24	P.136	Programmed operation mode speed 6	0 ~ 599.00Hz	0.00 Hz	101
04-25	P.137	Programmed operation mode speed 7	0 ~ 599.00Hz	0.00 Hz	101
04-26	P.138	Programmed operation mode speed 8	0 ~ 599.00Hz	0.00 Hz	101
04-27	P.101	Programmed operation mode speed 1 operating time	0 ~ 6000.0s	0.0s	101
04-28	P.102	Programmed operation mode speed 2 operating time	0 ~ 6000.0s	0.0s	101
04-29	P.103	Programmed operation mode speed 3 operating time	0 ~ 6000.0s	0.0s	101
04-30	P.104	Programmed operation mode speed 4 operating time	0 ~ 6000.0s	0.0s	101
04-31	P.105	Programmed operation mode speed 5 operating time	0 ~ 6000.0s	0.0s	101
04-32	P.106	Programmed operation mode speed 6 operating time	0 ~ 6000.0s	0.0s	101
04-33	P.107	Programmed operation mode speed 7 operating time	0 ~ 6000.0s	0.0s	101
04-34	P.108	Programmed operation mode speed 8 operating time	0 ~ 6000.0s	0.0s	102
04-35	P.111	Programmed operation mode speed 1 Acc/Dec time	0 ~ 600.00s/0 ~ 6000.0s	0.00s	102

Appendix 1 Parameter table

Group	Parameter Number	Name	Setting Range	Default	Page
04-36	P.112	Programmed operation mode speed 2 Acc/Dec time	0 ~ 600.00s/0 ~ 6000.0s	0.00s	102
04-37	P.113	Programmed operation mode speed 3 Acc/Dec time	0 ~ 600.00s/0 ~ 6000.0s	0.00s	102
04-38	P.114	Programmed operation mode speed 4 Acc/Dec time	0 ~ 600.00s/0 ~ 6000.0s	0.00s	102
04-39	P.115	Programmed operation mode speed 5 Acc/Dec time	0 ~ 600.00s/0 ~ 6000.0s	0.00s	102
04-40	P.116	Programmed operation mode speed 6 Acc/Dec time	0 ~ 600.00s/0 ~ 6000.0s	0.00s	102
04-41	P.117	Programmed operation mode speed 7 Acc/Dec time	0 ~ 600.00s/0 ~ 6000.0s	0.00s	102
04-42	P.118	Programmed operation mode speed 8 Acc/Dec time	0 ~ 600.00s/0 ~ 6000.0s	0.00s	102
05-01	P.302	Motor rated power	0 ~ 160.00kW	0.00kW	105
05-02	P.303	Motor poles	0 ~ 48	4	105
05-03	P.304	Motor rated voltage	0 ~ 510V	According to voltage	105
05-04	P.305	Motor rated frequency	50Hz system : 0 ~ 599.00Hz	50.00Hz	105
			60Hz system : 0 ~ 599.00Hz	60.00Hz	
05-05	P.306	Motor rated current	0~500.00A	According to kw	105
05-06	P.307	Motor rated rotation speed	50Hz system:0 ~ 9998r/min	1410r/min	105
			60Hz system: 0 ~ 9998r/min	1710r/min	
05-07	P.308	Motor excitation current	0~500.00A	According to kw	105
05-08	P.309	IM motor stator resistance	0 ~ 99.98Ω	According to kw	105
06-00	P.9	Electronic thermal relay capacity	0~500.00A	0.00	107
06-01	P.22	Stall prevention operation level	0 ~ 200%	150%	108
06-02	P.23	Stall prevention operation level correction factor	0 ~ 200%	99999	108
			99999: Stall prevention operation level is the setting value of 06-01(P.22).		
06-03	P.66	Stall prevention operation reduction starting frequency	50Hz system: 0 ~ 599.00Hz	50.00Hz	108
			60Hz system: 0 ~ 599.00Hz	60.00Hz	
06-08	P.155	Over torque detection level	0 ~ 200.0%	0.0%	110
06-09	P.156	Over torque detection time	0 ~ 60.0s	1.0s	110
06-10	P.260	Action when detect over torque	0: OL2 alarm will not be reported after over torque detection, and inverter keeps running.	1	110
			1: OL2 alarm will be reported after over torque detection, and inverter stops.		
06-13	P.281	Input phase loss protection	0: Off	0	111
			1: When input phase loss, built-in keypad shows IPF alarm and inverter stops		

Group	Parameter Number	Name	Setting Range	Default	Page
06-17	P.261	Maintenance alarm function	0: Off	0	110
			1 ~ 9998day: Used to set the time for maintenance alarm output signal		
06-18	P.280	Short circuit protection function	X0: Turn off short circuit to ground detect when inverter start	10	110
			X1: Short circuit to ground detect when inverter start		
			0X: Turn off output short circuit,		
			1X: When output short circuit, built-in keypad shows SCP alarm and inverter stops		
06-27	P.292	Total inverter operation time (minutes)	0 ~ 1439 min	0min	111
06-28	P.293	Total inverter operation time (days)	0 ~ 9999 day	0day	111
06-29	P.296	Total inverter power on time (minutes)	0 ~ 1439min	0min	111
06-30	P.297	Total inverter power on time (days)	0 ~ 9999day	0day	111
06-40	P.288	Alarm record code query	Choose 0 ~ 12 recorded alarm	0	112
06-41	P.289	Alarm record code display	Read only	Read only	112
06-42	P.290	Alarm record message query	Choose 0 ~ 10 recorded alarm	0	112
06-43	P.291	Alarm record message display	Read only	Read only	112
07-00	P.33	Communication protocol selection	0 : Modbus protocol	1	114
			1 : Shihlin protocol		
07-01	P.36	Inverter communication station number	0 ~ 254	0	114
07-02	P.32	Serial communication baud rate	0 : baud rate :4800bps	1	114
			1 : baud rate :9600bps		
			2 : baud rate :19200bps		
			3 : baud rate :38400bps		
07-03	P.48	Data length	0 : 8bit	0	114
			1 : 7bit		
07-04	P.49	Stop bit length	0 : 1bit	0	114
			1 : 2bit		
07-05	P.50	Parity check selection	0 : No parity check	0	114
			1 : Odd		
			2 : Even		
07-06	P.51	CR/LF selection	1:CR only	1	114
			2 : Both CR and LF		

Appendix 1 Parameter table

Group	Parameter Number	Name	Setting Range	Default	Page
07-07	P.154	Modbus communication format	0 : 1、7、N、2 (Modbus, ASCII)	4	114
			1 : 1、7、E、1 (Modbus, ASCII)		
			2 : 1、7、O、1 (Modbus, ASCII)		
			3 : 1、8、N、2 (Modbus, RTU)		
			4 : 1、8、E、1 (Modbus, RTU)		
			5 : 1、8、O、1 (Modbus, RTU)		
07-08	P.52	Number of communication retries	0 ~ 10	1	114
07-09	P.53	Communication interval allowed time	0 ~ 999.8s : Check communication timeout with the set value	99999	114
			99999 : No timeout check		
07-10	P.153	Communication alarm action	0 : Alarm and stop freely	1	114
			1 : No alarm and continuing to operation		
07-11	P.34	Communication EEPROM write-in selection	0 : When writing parameters in communication mode, write in RAM and EEPROM	0	129
			1 : When writing parameters through communication, only write into RAM		
08-00	P.170	PID function selection	0: Off	0	131
			2 : Parameter 08-03(P.225) as target value, terminal 3-5 current/voltage input as feedback source		
08-01	P.171	PID feedback control method	0: Negative feedback control.	0	131
			1: Positive feedback control.		
08-03	P.225	PID target value from keypad	0 ~ 08-43 ( P.251 )	20.0%	131
08-04	P.172	Proportional gain	1~100	20	131
08-05	P.173	Integral time	0 ~ 100.0s	1.0s	131
08-06	P.174	Differential time	0 ~ 10000ms	0ms	131
08-07	P.175	Abnormal deviation	0 ~ 100.0%	0.0%	131
08-08	P.176	Abnormal duration time	0 ~ 600.0s	30.0s	131
08-09	P.177	Abnormal processing mode	0: Stop freely	0	131
			1: Slow down to stop		
			2: Alarm and continue operation		
08-10	P.178	Sleep detection deviation	0 ~ 100.0%	0.0%	131
08-11	P.179	Sleep detection duration time	0 ~ 255.0s	1.0s	132
08-12	P.180	Wake-up level	0 ~ 100.0%	90.0%	132
08-13	P.181	Stop level	0 ~ 120.00Hz	40.00Hz	132
08-14	P.182	Upper integral limit	50Hz system:0 ~ 120.00Hz	50.00Hz	132
			60Hz system:0 ~ 120.00Hz	60.00Hz	
08-15	P.183	Deceleration step length when stable	0 ~ 10.00Hz	0.50Hz	132
08-18	P.223	Analog feedback signal bias	0 ~ 100.0%	0.0%	132

Group	Parameter Number	Name	Setting Range	Default	Page
08-19	P.224	Analog feedback signal gain	0 ~ 100.0%	100.0%	132
08-43	P.251	PID pressure range (Bar) setting	1.0~100.0	100.0	135
08-45	P.253	Analog signal feedback loss detection time	0 ~ 600.0	0.0 s	135
08-46	P.254	Analog signal feedback loss action selection	0 : Alarm AErr and inverter stop freely	0	135
			1 : Slow down to stop then alarm AErr		
			2 : Alarm AErr and continue operation		
10-00	P.10	DC brake operating frequency	0 ~ 120.00Hz	3.00Hz	138
10-01	P.11	DC brake operating time	0 ~ 60.0s	0.5s	138
10-02	P.12	DC brake operating voltage	0 ~ 30.0%	4.0%	138
10-03	P.151	Zero-speed control function selection	0: Off.	0	139
			1: DC voltage braking		
10-04	P.152	Voltage at zero-speed control	0 ~ 30.0%	5.0%	139
10-05	P.242	DC brake before inverter start	0: Off	0	139
			1: Before starting operate DC brake first.		
10-06	P.243	DC brake time before inverter start	0 ~ 60.0s	0.5s	139
10-07	P.244	DC brake voltage before inverter start	0 ~ 30.0%	4.0%	139
10-08	P.150	Restart mode selection	X0 : No frequency search.	0	140
			X1 : Reserved		
			X2 : Decrease voltage mode		
			0X : Power on once.		
			1X : Start each time.		
2X : Only instantaneous stop and restart					
10-09	P.57	Restart idling time	0 ~ 30.0s	99999	140
			99999: Off.		
10-10	P.58	Restart rising time	0 ~ 60.0s	10.0s	140
10-11	P.61	Remote control function	0: Off	0	141
			X1 : Remote control function, frequency save in memory		
			X2 : Remote control function, frequency won't save		
			X3 :Remote control function, frequency won't save, clear frequency setting every time STF/STR "turn off".		
			X4 : Remote control function, frequency save in memory every 5s		
1X : Frequency command range 01-01(P.2)~01-00(P.1), frequency command value from RH,RM setting					

Appendix 1 Parameter table

Group	Parameter Number	Name	Setting Range	Default	Page
10-11	P.61	Remote control function	1: When over-voltage, inverter will reset.	0	141
			2: When over-current, inverter will reset.		
			3: When either over-voltage or over-current, inverter will reset.		
			4: When any alarm occurs, inverter will reset.		
10-13	P.67	Auto reset times	0: Off.	0	144
			1 ~ 10: If the alarm exceeds 10-13(P.67) times, inverter will not reset.		
10-14	P.68	Auto reset waiting time	0 ~ 360.0s	6.0s	144
10-15	P.69	Auto reset times count	Read only	0	144
10-16	P.119	Forward and reverse rotation dead time	0 ~ 3000.0s	0.0s	145
10-17	P.159	Energy-saving control function	0: Off.	0	145
			1: Energy-saving mode.		
10-18	P.229	Dwell function selection	0: Off.	0	146
			1: Backlash compensation function.		
			2: Acceleration and deceleration interrupt waiting function.		
10-19	P.230	Dwell frequency at acceleration	0 ~ 599.00Hz	1.00Hz	146
10-20	P.231	Dwell time at acceleration	0 ~ 360.0s	0.5s	146
10-21	P.232	Dwell frequency at deceleration	0 ~ 599.00Hz	1.00Hz	146
10-22	P.233	Dwell time at deceleration	0 ~ 360.0s	0.5s	146
10-23	P.234	Triangular wave function selection	0: Off.	0	147
			1: If terminal function TRI is triggered, triangular wave function will on.		
			2: Triangular wave function is on at all time.		
10-24	P.235	Maximum amplitude	0 ~ 25.0%	10.0%	147
10-25	P.236	Amplitude compensation at deceleration	0 ~ 50.0%	10.0%	147
10-26	P.237	Amplitude compensation at acceleration	0 ~ 50.0%	10.0%	147
10-27	P.238	Amplitude acceleration time	0 ~ 360.00s/0 ~ 3600.0s	10.00s	147
10-28	P.239	Amplitude deceleration time	0 ~ 360.00s/0 ~ 3600.0s	10.00s	147
10-46	P.268	Voltage stall level	220V : 155 ~ 400V	380V	148
			440V : 310 ~ 800V	760V	
10-55	P.226	Reciprocating machine function selection	0 : Off	0	148
			1 : Turn on reciprocating machine function		
10-56	P.227	Reciprocating forward limit time	0~3600.0s	0.0s	148



## Appendix 1 Parameter table

Group	Parameter Number	Name	Setting Range	Default	Page
10-57	P.228	Reciprocating reverse limit time	0~3600.0s	0.0s	148
13-00	P.89	Slip compensation coefficient	0 ~ 10	0	150
13-01	P.246	Modulation coefficient	0.00 ~ 1.20	0.50	150
13-03	P.286	High frequency vibration Suppression factor	0 ~ 15	0	151
13-04	P.283	Current detection method	0 ~ 2	2	151
15-00	P.900	User registered parameter 1	P parameter mode: 0~399 Parameter group mode: 00-00~13-99	99999	153
15-01	P.901	User registered parameter 2		99999	153
15-02	P.902	User registered parameter 3		99999	153
15-03	P.903	User registered parameter 4		99999	153
15-04	P.904	User registered parameter 5		99999	153
15-05	P.905	User registered parameter 6		99999	153
15-06	P.906	User registered parameter 7		99999	153
15-07	P.907	User registered parameter 8		99999	153
15-08	P.908	User registered parameter 9		99999	153
15-09	P.909	User registered parameter 10		99999	153
15-10	P.910	User registered parameter 11		99999	153
15-11	P.911	User registered parameter 12		99999	153
15-12	P.912	User registered parameter 13		99999	153
15-13	P.913	User registered parameter 14		99999	153
15-14	P.914	User registered parameter 15		99999	153
15-15	P.915	User registered parameter 16		99999	153
15-16	P.916	User registered parameter 17		99999	153
15-17	P.917	User registered parameter 18		99999	153
15-18	P.918	User registered parameter 19		99999	153
15-19	P.919	User registered parameter 20		99999	153





## 7.2 Appendix 2 Alarm code list

Code	Screen display	Cause	Troubleshooting
<b>ERROR</b>	<i>Error</i>	<ol style="list-style-type: none"> <li>1.Low input voltage.</li> <li>2.The reset function "RES" is on.</li> <li>3.Bad connection between the control panel and main body.</li> <li>4.Internal circuit malfunction.</li> <li>5. CPU error.</li> <li>6. Abnormal insulation of load to ground.</li> </ol>	<ol style="list-style-type: none"> <li>1.Use a better power supply.</li> <li>2.Shut off "RES".</li> <li>3.Ensure the keypad is connected firmly.</li> <li>4.Replace the inverter.</li> <li>5.Restart the inverter.</li> <li>6. Check the insulation of the motor cable and the three-phase winding of the motor.</li> </ol>
<b>OC0</b> Over-current when stop	<i>OC0</i>	The output current is two times larger than the rated current of the inverter or the motor is short.	Inverter may be interfered by external electromagnetic noise, please improve the wiring and restart the inverter. If the alarm repeated, send the unit back to the dealer or the manufacturer to repair.(Note1)
<b>OC1</b> Over-current during acceleration	<i>OC1</i>		<ol style="list-style-type: none"> <li>1.When there is a sudden speed change, extend the acceleration or deceleration time.</li> <li>2.Avoid sudden increase of load.</li> <li>3.Check Terminals U/T1, V/T2 and W/T3 for short circuit.</li> </ol> (Note1)
<b>OC2</b> Over-current at constant speed	<i>OC2</i>		
<b>OC3</b> Over-current during deceleration	<i>OC3</i>		
<b>OV0</b> Over-voltage when stop	<i>OV0</i>	<ol style="list-style-type: none"> <li>1. The voltage between terminals (+ / P)-(- / N) is too high.</li> <li>2. The external power supply line has large power equipment start and stop affecting the power grid surge.</li> </ol>	Check if the power supply is functioning properly. (Note1)
<b>OV1</b> Over-voltage during acceleration	<i>OV1</i>		<ol style="list-style-type: none"> <li>1. When there is a sudden speed change, extend the acceleration or deceleration time.</li> <li>2. Check the insulation of the motor to ground.</li> <li>3. Improve the power supply quality.(It is recommended to install an input reactor)</li> </ol> (Note1)
<b>OV2</b> Over-voltage at constant speed	<i>OV2</i>		
<b>OV3</b> Over-voltage during deceleration	<i>OV3</i>		
<b>THT</b> IGBT module Overheat	<i>THT</i>	<ol style="list-style-type: none"> <li>1. IGBT module thermal relay actuate. (overload warning)</li> <li>2. 01-03 (P.3) setting does not match the rated frequency of the motor.</li> <li>3. Insufficient input power voltage causes inverter output capacity reduced.</li> <li>4.The three phase input connection of the motor is incorrect.</li> </ol>	<ol style="list-style-type: none"> <li>1. Avoid overloading the inverter in long term.</li> <li>2. Recheck 01-03 (P.3) and motor rated frequency setting.</li> <li>3. Check the grid voltage.</li> <li>4. Check whether the motor connection (Y / Δ) is consistent with the motor nameplate.</li> <li>5. Confirm whether the carrier frequency 00-11 (P.72) is set too large.(Note 1)</li> </ol>
<b>THN</b> Motor Overheated	<i>THN</i>	Thermal relay actuate.	<ol style="list-style-type: none"> <li>1.Check if the 06-00 (P. 9) value matches the motor (check rated current on motor nameplate)</li> <li>2.Reduce the load</li> </ol>
<b>OHT</b> External Overheat	<i>OHT</i>	External thermal relay actuate.	<ol style="list-style-type: none"> <li>1.Check if the thermal relay used matches the motor</li> <li>2.Reduce the load</li> <li>3. Check if the external IO signal is not connected or dropped</li> </ol>

Code	Screen display	Cause	Troubleshooting
OPT RS-485 connector error	OPT	1.Communication error , exceeding the retry limit. 2. External noise interference 3. The logic of the communication control program is unreasonable 4.Disconnect time exceeding the limit.	1.It is recommended to use twisted-pair shielded communication lines and the shielding layer is properly grounded 2.Check the communication program 3.Set the communication parameters correctly
EEP Memory error	EEP	ROM malfunction	If the alarm repeated, send the unit back to the dealer or the manufacturer to repair. Avoid frequent parameters modification and saving target frequency to EEPROM, please refer to 07-11 (P.34) and target frequency address H1002 to prevent damage.
PIDE PID error	PIDE	1.The capacity of the inverter or motor is not enough 2.PID target value or feedback value doesn't make sense 3.Peripheral devices malfunction 4. During PID control, the feedback signal is not connected or dropped	1.Use an inverter or a motor with bigger capacity. 2.Check PID parameters 3.Check all peripheral feedback devices of the system (sensors, potentiometer) and wirings.
CPU CPU error	CPU	Strong electromagnetic interference	Reduce peripheral interference.
OLS Stall prevention and protection	OLS	Over-loaded motor	1.Reduce the load 2.Increase 06-01(P.22) value.
SCP Short circuit over-current	SCP	1.Short circuit at output-end 2. Inverter false alarm SCP	1.Check if the output circuit is short and check the wiring 2. Inverter may be interfered by external electromagnetic noise, please improve the wiring (Note 1)
NTC Module overheat	NTC	The inverting part of IGBT module overheated	1.Lower the surrounding temperature and increase venting 2. Check if the cooling fan is functioning properly 3. Confirm whether the carrier frequency 00-11 (P.72) is set too large
IPF Input power error	IPF	Input power error(phase loss)	Check if the power supply is normal.
OL2 Torque overload	OL2	1. Motor overload 2. The value in 06-08 (P.155) and 06-09(P.156) doesn't make sense.	1.Reduce the load 2.Set 06-08 (P.155) and 06-09(P.156) properly
CPR CPU error	CPR	CPU error	1.Check the wiring 2.Check the parameter setup 3.Reduce noise interference
AErr Terminal 3-5 error	AErr	The terminal 3-5 analog input disconnect	Check parameter 02-24(P.184)
GF Output short to ground	GF	Shortage between output and ground	Please check whether the motor short circuit to ground
HDC Hardware self-detect circuit error	HDC	Hardware self-detect circuit error	Send the unit back to the dealer or the manufacturer to repair

Note 1: Do not turn on the power repeatedly before removing the cause of the alarm.

### 7.3 Appendix 3 : Warning code list

Code	Built-in keypad status	Reason	Action
Current stall		When the output current is greater than the stall level, the three small lights at the top right of the built-in keypad will flash, indicating that the inverter is currently in a current stall state, and the motor will not run smoothly.	<ol style="list-style-type: none"> <li>1. Check whether the setting of 06-01 (P.22), 06-02 (P.23), 06-03 (P.66) is reasonable;</li> <li>2. Check whether the set value of 01-06 (P.7), 01-07 (P.8) is too small;</li> </ol>
Voltage stall		If the DC bus voltage is too high, inverter will be in a voltage stall state, and the three small lights at the bottom right of the built-in keypad will flash, and the motor will not run smoothly.	Check whether the set value of 01-06 (P.7), 01-07 (P.8) is too small
LV Undervoltage		Input voltage is too low	Supply normal voltage.
LT action		When the inverter output current is higher than twice the rated current, but does not reach the overcurrent level, the six small lights on the right side of the built-in keypad will flash, indicating that the inverter is now in LT state, and the motor will not run smoothly.	<ol style="list-style-type: none"> <li>1. If there is rapid acceleration or rapid deceleration, please extend the acceleration and deceleration time</li> <li>2. Avoid sudden increase in load</li> <li>3. Check whether there is a short circuit at the motor terminal U/T1-V/T2-W/T3</li> </ol>

Note: The function of the above warning is to inform the customer of the current working condition of the inverter. The inverter will not stop. Please adjust the parameter value appropriately or confirm the power supply and load status.


## 7.4 Appendix 4:Troubles and solutions

Troubles	Check points	
The motor does not run	Main circuit	<ul style="list-style-type: none"> <li>•Is the voltage between terminals R/L1-S/L2-T/L3 normal?</li> <li>•Is the wiring between the inverter and the motor correct?</li> </ul>
	Load	<ul style="list-style-type: none"> <li>•Is the load too heavy?</li> <li>•Is the motor rotor locked?</li> </ul>
	Parameters Setting	<ul style="list-style-type: none"> <li>•Is the startup frequency (01-11(P.13)) set too high?</li> <li>•Is the operation mode (00-16(P.79)) correct?</li> <li>•Is the upper limit frequency (01-00(P.1)) set to zero?</li> <li>•Is forward reverse rotation prevention (00-15(P.78)) limited?</li> <li>•Is the signal input and percentage setting ( 02-25 ( P.198 ) ~02-28 ( P.197 ) ) correct?</li> <li>•Is the frequency jump ( 01-16(P.91)~01-21(P.96) ) correct?</li> </ul>
	Control circuit	<ul style="list-style-type: none"> <li>•Is MRS function “on”? (relevant parameters 03-00(P.83), 03-01(P.84), 03-03(P.80) , 03-04(P.81) )</li> <li>•Is RES function “on”? (relevant parameters 03-00(P.83) 、 03-01(P.84) 、 03-03(P.80)、 03-04(P.81) )</li> <li>•Is the external thermal relay tripping?</li> <li>•Is there an alarm that has not been reset?</li> <li>• Are STF and STR functions correct? (relevant parameters 03-00(P.83), 03-01(P.84), 03-03(P.80), 03-04(P.81) )</li> <li>•Does the wiring of the control circuit fall off or have poor contact?</li> </ul>
Opposite motor rotation direction	<ul style="list-style-type: none"> <li>•Is the phase sequence of the wiring of the motor terminal (U/T1)/(V/T2)/(W/T3) correct?</li> <li>•Is the wiring of the start terminals STF and STR correct?</li> </ul>	
The motor cannot accelerate	<ul style="list-style-type: none"> <li>•Is the load too heavy?</li> <li>•Is stall prevention level (06-01(P.22)) correct?</li> <li>•Is torque compensation (01-10(P.0)) too high?</li> <li>•Is it limited by the upper limit frequency (01-00(P.1))?</li> </ul>	
Unsmooth acceleration and deceleration	<ul style="list-style-type: none"> <li>•Is the acceleration and deceleration time (01-06(P.7) and 01-07(P.8)) set correctly?</li> <li>•Is the acceleration/deceleration curve selection (01-05(P.29)) correct?</li> <li>•Does the voltage/current signal fluctuate due to noise?</li> </ul>	
Excessive motor current	<ul style="list-style-type: none"> <li>•Is the load too heavy?</li> <li>•Does the inverter capacity match the motor capacity?</li> <li>•Is torque compensation (01-10(P.0)) too high?</li> </ul>	
Speed fluctuation in operation	<ul style="list-style-type: none"> <li>•Does the voltage/current signal fluctuate due to noise?</li> <li>•Has the motor load changed?</li> <li>•Is the main circuit wiring too long?</li> </ul>	

## 7.5 Appendix 5 Optional equipment

### 7.5.1 PU301 Keypad

➤ PU301 appearance




Order number


NO.	Model	Name	Order code
1	PU301	LED Keypad	SNKPU301

➤ Outline

<Outline drawing>




➤ Panel mounting hole size



➤ Snap-in installation hole size

<Card buckle installation: panel cutting dimension drawing>



Panel thickness	1.2mm	1.6mm	2.0mm
W	66.4		
H	110.2	111.3	112.5

\* Allowable error: ±0.15mm


\* If the customer's drilling accuracy cannot meet the above allowable error, please purchase the accessory SMK301 (spring installation kit) for installation.





### 7.5.2 DU06 Keypad

➤ DU06 appearance




Order number:

NO.	Model	Name	Order code
1	DU06	DU06 keypad	SNKDU06


➤ DU06 outline:

<Outline drawing>




➤ DU06 Recommended screw installation size :

<Screw installation:panel cutting dimension drawing>




➤ DU06 Snap-in installation hole size:

<Snap-fit installation: panel cutting dimension drawing>



7.5.3 DU08 Keypad

DU08 appearance



DU08


DU08S

Order number:


NO.	Model	Name	Order code
1	DU08	DU08 keypad	SNKDU08
2	DU08S	DU08S keypad	SNKDU08S

➤ DU08 outline:


<Outline dimensional drawing>



Panel mounting hole size




Flange mounting hole size



7.5.4 DU10 Keypad

DU10 appearance




Order number:



NO.	Model	Name	Order code
1	DU10	DU10 keypad	SNKDU10

➤ DU10 outline:

<Outline drawing>




### 7.5.5 PU302 Keypad




◆ Order number:

NO.	Model	Name	Order code
1	PU302	LED keypad	SNKPU302

◆ Outline




◆ Recommended screw installation size




◆ Recommended installation size

## Appendix 4 Optional equipment

---



### ◆ Spring installation




\*Allowable error:  $\pm 0.15\text{mm}$

\* If the customer's drilling accuracy cannot meet the above tolerance, please purchase the accessory SMK301 (spring installation kit) for installation.

## 7.5.6 CBL : Data transmission line (for use with the above keypads)

Model: SNKCBLxxGTN2 (xx means 1R5,3,5,10)



Item NO.	Part No.	L(mm)
1	SNKCBL1R5GTN2	1500
2	SNKCBL3GTN2	3000
3	SNKCBL5GTN2	5000
4	SNKCBL10GTN2	10000

## 7.6 Appendix 6 European Specification Compatibility Description

**This inverter qualifies the CE label. Specifications:**

**Low Voltage Directive 2014/35/EU & Electromagnetic Compatibility Directive 2014/30/EU**

1. Electromagnetic compatibility command (EMC):

(1). EMC compatibility description:

For system integration, inverter is not a functionally independent device unit. It is usually a unit in the control box. It is combined with other devices to control a machine or equipment. Therefore, our company does not consider that all the EMC commands should be directly applied on the inverter. As a result, the CE label of this inverter is not extensible.

(2). Compatibility:

The inverter does not need to cover all the EMC commands. Yet, for certain machine equipment that needs to use EMC commands and the inverter, the machine has to be equipped with CE label. In addition, the company can provide the electromagnetic inspection data and operation manual that covers the required electromagnetic compatibility specifications for a quick and easy installation of the machine equipment of this inverter.

(3). Installation outline:

Please follow the following notes for installing the inverter:

\*Use a noise filter qualifying the EU standard to coordinate with the inverter.

\*The wire between the motor and the inverter has to be stored in shielded cable or metal tube. In addition, ground the motor terminal and the inverter terminal together. Please shorten the wire as much as possible.

\*Please put this inverter in a metal cabinet that is already grounded. It can prevent radiation interference.

\*The line-to-line noise filter at the power source terminal and the online magnetic iron core at the control row are used for suppressing noises.

All the signals and the EU-qualified filter specifications are described in details in the operation manual. Please contact your agent.

2. Low-voltage command (LVD):

(1). Low-voltage command compatibility description:

This inverter is compatible with low-voltage commands.

(2). Compatibility:

Our company qualifies the low-voltage command specification.

(3). Description:

\*Do not rely on leakage protection only for preventing electric shocks. Grounding is required for the protection.

\*Ground each inverter individually (do not connect more than two (including two) ground cables).

\*Please use non-fuse switch and electromagnetic contactor that qualify EN or IEC specifications.

\*Please use the inverter under an environment of over-voltage level-3 condition with contamination level 2 or better.

\*For the style and dimensions of the input- and output-end of the inverter cable, please refer to the specifications listed in the operation manual.



## 3. CE Self Declaration

**EU-Declaration of Conformity**

<i>Herewith we(manufacture):</i>	
<i>Name:</i>	<i>Suzhou Shihlin Electric &amp; Engineering Corporation</i>
<i>Address:</i>	<i>NO.88, Guangdong St., Suzhou New District, Jiangsu, China.</i>

*Declare that the following Appliance complies with the appropriate basic safety and health requirements of the EU Directives(see item 4) and the relevant Union harmonisation legislation based on its design and type, as brought into circulation by us.*

*The object of the declaration is identification of electrical equipment allowing traceability.*

*The declaration relates exclusively to Shihlin products in the state in which it was placed on the market, and excludes components which are added and/or operations carried out subsequently by the final user.*

*This declaration of conformity is issued under the sole responsibility of the manufacture.*

1	<i>Product name:</i>	<i>Inverter</i>
2	<i>Model/Type:</i>	<i>SL3 Series (Reference the attached list of catalogue numbers)</i>
3	<i>Batch or Serial number:</i>	<i>Reference the attached list of catalogue numbers</i>
4	<i>Application EU Directives:</i>	<i>Low voltage Directive 2014/35/EU EMC directive 2014/30/EU</i>
5	<i>Used harmonized Standards:</i>	<i>LVD: EN61800-5-1:2007 EMC: EN61800-3:2004+A1:2012</i>
6	<i>Signed for and on behalf of:</i>	<i>Suzhou Shihlin Electric &amp; Engineering Corporation</i>
7	<i>Print Name, Function(Title of Signature )</i>	<i>Anne Yang, Director</i>
8	<i>Signature</i>	<i>Anne Yang</i>
9	<i>Place and date of issue</i>	<i>Suzhou of China, 2020. 10. 15</i>
<p><i>Manufacturer Statement:</i></p> <p><i>✓ We shall give the manufacturer full name and address, registered trade name or registered trade mark, and true Batch/series no., "xxxx-xxxx" in the EU declaration and on the product(marking plate), or where that is not possible, on its packaging or in a document accompanying the product.</i></p> <p><i>✓ We shall keep the technical documentation referred to in Annex III and the EU declaration of conformity for 10 years after the electrical equipment has been placed on the market.</i></p>		

**Catalogue numbers:**

Series name	Model name	Serial number <sup>1</sup>
SL3 Series	SL3-021-0.4K-xy, SL3-021-0.75K-xy, SL3-021-1.5K-xy, SL3-021-2.2K-xy, SL3-043-0.4K-xy, SL3-043-0.75K-xy, SL3-043-1.5K-xy, SL3-043-2.2K-xy	/

- 1) If no series number is given, then all series are covered
- 2) xy: denote any alphanumeric suffix

Signature: *Anne Yang*

Rev.01 2020/10/15

## 8. REVISION RECORD

Published Date	Edition of the Manual	Revision Content
2020.8	V1.00	First Edition
2020.9	V1.01	<p>modify: Improve and optimize the description of some parameters.</p> <p>add: 5.2.13 Remote control frequency acceleration and deceleration time selection</p>
2020.10	V1.02	<p>modify: Modify part of the drawing to ensure consistency with the actual product</p> <p>add: 3.7.5 New remarks for control loop wave switch AVI/ACI</p>
2021.1	V1.03	<p>modify: Modify part of the drawing to ensure consistency with the actual product</p> <p>add: 7.3 Appendix 3 : Warning code list 7.5.4 DU10 Keypad 7.5.5 PU302 Keypad</p>

Version : V1.03