

High price-performance ratio
SC3-021-0.2K ~ 2.2K
SC3-023-0.2K ~ 3.7K
SC3-043-0.4K ~ 5.5K

Thank you for choosing Shihlin inverters SC3 series.

This instruction will explain the use and precautions of the product. Please read this instruction carefully before installation and use the inverter correctly and safely.

1) Safety Instructions**Safety Instructions**


- ✓ The qualified specialized person should be invited to install, operate, maintain and inspect the product.
- ✓ In the instruction, the levels of the safety caution include "Warning" and "Caution".
- ⚠ Warning: the incorrect operation may cause hazardous situation, and accordingly lead to death or serious injury.
- ⚠ Caution: the incorrect operation may cause hazardous situation, and accordingly lead to general or minor injury or damage of the object.

Warning

- ✓ The front cover plate and the wiring board should not be opened when the inverter is powered on. In addition, the inverter should not be operated when the front cover plate and the wiring board are demounted. Otherwise, the electric shock may be caused due to contacting with the high-voltage terminal and the charging part.
- ✓ If the wiring needs to be changed or inspection is required, the power supply of the inverter should be turned off first. There is still high voltage inside the inverter before the LED display of the inverter is turned off. Therefore, please don't touch the internal circuit and parts.
- ✓ The inverter must be earthed correctly.
- ✓ Please don't operate with wet hands, don't touch the heat sink, and don't plug and unplug the cable; or electric shock may be caused.
- ✓ Do not replace the cooling fan when the inverter is powered on, otherwise the risk may occur. It is dangerous to replace the cooling fan when the inverter is powered on.

Caution

- ✓ Voltage applied to each terminal must be the one specified in the user manual; otherwise, failure or damage may be caused.
- ✓ Do not operate a voltage-resistant test for the parts inside the inverter because semiconductors in inverter may be easily damaged due to high-voltage breakdown.
- ✓ Do not touch the inverter because the temperature of the inverter is very high when it is powered on or right after disconnecting the power supply, only built-in keypad is touchable, otherwise, burn may occur.
- ✓ Failure or damage may be caused due to wrong wiring.
- ✓ Do not reverse the polarities (+, -) by mistake, failure or damage may be caused.
- ✓ Please install the inverter on nonflammable walls without holes (to avoid contacts with the cooling fin of the inverter from the back). If the inverter is installed on or close to flammable objects it may cause a fire.
- ✓ Please disconnect the inverter from power supply in case of failure. Overload current passes through the inverter continuously may cause a fire.

2) Product Model

Series category	Voltage level	Capacity	Others
SC3 series	-043 : three phase 440V -023 : three phase 220V -021 : single phase 220V	0.75kW	None : General model -xy : Customize or specialize or region difference

3) Installation Environment

Ambient temperature	-10 ~ +50°C (non-freezing), parallel install -10~ +40°C (non-freezing).
Ambient humidity	Under 90%Rh (non-condensing).
Storage temperature	-20 ~ +65°C.
Surrounding environment	Indoor, no corrosive gas, no flammable gas, no flammable powder.
Altitude	Altitude below 2000 meters, when altitude is above 1,000 m, derate the rated current 2% per 100 m
Vibration	Below 5.9m/s ² (0.6G)
Grade of protection	IP20
The degree of pollution	2

4) Installation and Wiring


- Please install the inverter vertically in order not to reduce the heat dissipation effect:




(a) Vertical arrangement (b) Horizontal arrangement (c) Level arrangement

- Please follow the installation restrictions shown below to ensure enough ventilation space for inverter cooling and wiring space:

- Single or side by side installation :





- Arrangement of multiple inverters :



(a) Horizontal arrangement (b) Vertical arrangement

- Note 1: When installing different sizes inverters in parallel, please align the upper positions of the inverters before installing, for easier replacement of the cooling fan.
Note 2: When it is inevitable to arrange inverters vertically to minimize space, install guides since heat from the bottom inverters can increase the temperature on the top inverters, causing inverter failures.
Note 3: Side-by-side installation, that is, when the D dimension is 0, ensure that the ambient temperature in the cabinet is not higher than 40°C. It is not possible to use keypad or communicate through the RS485 interface.


Din rail installation :**5) Terminal Connection Diagrams**

Note 1: SC3-043-0.4K~1.5K, SC3-023-0.2~1.5K, SC3-021-0.2~0.75K without +P and PR terminals.

Note 2: All SC3 have built-in RFI filters to suppress electromagnetic interference, but to comply with CE regulations, please refer to the relevant instructions in the instruction manual for installation.

6) Main Circuit Wiring and Terminal Specification

Inverter model	Terminal screw specifications	Tightening torque(Kgf.cm)	Recommended wiring specification(mm ²)				Recommended wiring specification (AWG)			
			R, S, T	U, V, W	+P, PR	Grounding Cable	R, S, T	U, V, W	+P, PR	Grounding Cable
SC3-021-0.2K	M3	4-6	2.5	1.5	---	1.5	14	16	---	16
SC3-023-0.2K			1.5	1.5	---	1.5	16	16	---	16
SC3-043-0.4K			1.5	1.5	---	1.5	16	16	---	16
SC3-021-0.4K			2.5	2.5	---	2.5	14	14	---	14
SC3-023-0.4K			2.5	2.5	---	2.5	14	14	---	14
SC3-043-0.75K			2.5	2.5	---	2.5	14	14	---	14
SC3-021-0.75K			2.5	2.5	---	2.5	14	14	---	14
SC3-023-0.75K			2.5	2.5	---	2.5	14	14	---	14
SC3-043-1.5K			2.5	2.5	---	2.5	14	14	---	14
SC3-023-1.5K			2.5	2.5	---	2.5	14	14	---	14
SC3-021-1.5K			2.5	2.5	2.5	2.5	14	14	14	14
SC3-043-2.2K			2.5	2.5	2.5	2.5	14	14	14	14
SC3-021-2.2K			4	4	4	4	12	12	12	12
SC3-023-2.2K			4	4	4	4	12	12	12	12
SC3-043-3.7K			2.5	2.5	2.5	2.5	10	14	14	14
SC3-043-5.5K			2.5	2.5	2.5	2.5	14	14	14	14
SC3-023-3.7K			4	4	4	4	12	12	12	12

7) Control Terminal**Arrangement of control terminal****Control terminal description**

Terminal type	Terminal	Function instructions	Terminal specifications
---------------	----------	-----------------------	-------------------------

	name		
Switch signal input	STF	These four terminals are multifunction digital input, can switch between SINK/SOURCE.	Input impedance:4.7 kΩ
	STR		Action current:5mA (when 24VDC)
	M0		Voltage range:10~28VDC
	M1		Maximum frequency:1kHz
Analog signal input	10	+10.5±0.5V	Maximum current:10mA
	3	0~10V/4~20mA	Input impedance:10kΩ
Relay output	A	Multi-function relay output terminals. A-C is normally open contact, C is common terminal.	Maximum voltage:30VDC or 250VAC
	C		Maximum current: Resistor load 5A NO/3A NC Inductance load 2A NO/1.2A (cosΦ=0.4)
Communication terminal	RJ45	RS485, optical coupling isolation	Distance: up to 500m
	DA+	RJ45 and "DA+/DB-" can't work at the same time	Bit rate: up to 115200bps
	DB-		
Common terminal	5/SD	Common terminal for terminal STF,STR,M0, M1,3 (SINK)	---
	PC	Common terminal for terminal STF,STR,M0, M1 (SOURCE)	---

Note1: When connecting control terminal to external devices, please pay attention to the voltage and current specifications of terminals to avoid damaging the inverter.

Note2 : The function of the control terminal is decided by inverter parameters, please refer to Instruction Manual for setting.


Note3 : Please pay attention to polarity when connect to external power and devices.

► Wiring method**• Wire connection**

For the control circuit wiring, strip off the sheath of a cable, and use it with a blade terminal. For a single wire, strip off the sheath of the wire and apply directly.

Insert the blade terminal or the single wire into a socket of the terminal.

- (1) Strip off the sheath for the below length. If the length of the sheath peeled is too long, a short circuit may occur with neighboring wires. If the length is too short, wires might come off.

**(2) Crimp the blade terminal**

Insert wires to a blade terminal, and check that the wires come out for about 0 to 0.5 mm from a sleeve.

Check the condition of the blade terminal after crimping. Do not use a blade terminal of which the crimping is inappropriate, or the face is damaged.





- Please do use blade terminals with insulation sleeve. Blade terminals commercially available:

Cable gauge (mm²)	Blade terminals model	L (mm)	d1 (mm)	d2 (mm)	Manufacturer	Tool type

<tbl

SC3-021-0.75K						torque 20~25kgf.cm)
SC3-023-0.2K						
SC3-023-0.4K						
SC3-023-0.75K						
SC3-023-1.5K						
SC3-043-0.4K						
SC3-043-0.75K						
SC3-043-1.5K						

► Frame B



unit : mm

Model	W	W1	H	H1	H2	D	S1
SC3-021-1.5K							
SC3-021-2.2K							
SC3-023-2.2K							
SC3-023-3.7K							
SC3-043-2.2K							
SC3-043-3.7K							
SC3-043-5.5K							

9) Optional Equipment

Category	Name	Description	Order code
Keypad	PU301	LED display	SNKPU301
	DU06	LED display	SNKDU06
	DU08	LED display	SNKDU08
	PU302	LED display	SNKPU302
	DU10	LED display	SNKDU10

10) Parameter group

► System Parameter Group 00

Group	No.	Name	Setting Range	Default	User Setting
00-00	P.90	Inverter model	Read only	---	
00-01	P.188	Firmware version	Read only	---	
00-02	P.996 ~ P.999	Parameter restoration	0: Off	0	
			1: Clear alarm history (P.996=1)		
			2: Reset inverter (P.997=1)		
			3: Restore all parameters to default (P.998=1)		
			4: Restore some parameters to default 1 (P.999=1)		
			5: Restore some parameters to default 2 (P.999=2)		
			6: Restore some parameters to default 3 (P.999=3)		
00-03	P.77	Selection of parameters write protection	0: Parameters can be written only when the motor stops.	0	
			1: Parameters cannot be written.		
			2: Parameters can also be written when the motor is running.		
			3: Parameters cannot be read when in password protection.		
00-04	P.294	Password parameter	0~65535	0	
00-05	P.295	Password setup	2~65535	0	
00-06	P.110	Built-in keypad monitor selection	0: When inverter starts, built-in keypad enters monitor mode automatically, screen displays output frequency (with slip compensation).	2	
			1: When inverter starts, built-in keypad displays target frequency.		
			2: When inverter starts, built-in keypad enters monitor mode automatically, screen displays steady state output frequency.		
			3: When inverter starts, built-in keypad enters monitor mode automatically, screen displays current pressure and feedback pressure of the constant pressure system in percentage.		
			4: When inverter starts, built-in keypad doesn't enter monitor mode but enter the previous mode before power off		
			5: When inverter starts, built-in keypad enters monitor mode automatically, screen displays current pressure and feedback pressure of the constant pressure system.		
			0: Output AC voltage (V)		
			1: DC bus voltage. (V)		
			2: Inverter temperature rising accumulation rate (%)		
			3: Target pressure of the constant pressure system (%)		
00-07	P.161	Multi-function display	4: Feedback pressure of the constant pressure system (%)	0	
			5: Running frequency (Hz)		
			6: Electronic thermal accumulation rate (%)		
			7: Reserved		
			8: Signal value (mA) of 3-5 input terminals (mA/V).		
			9: Output power (kW).		
			10: Reserved		
			11: Forward reverse rotation signal. Built-in keypad: Fwd is forward, Rev is reverse, STOP is not operating status. External keypad: 1 is forward, 2 is reverse, 0 is not operating status..		

			12: NTC temperature (°C) 13: Motor electronic thermal accumulation rate (%) 14~18 : Reserved 19: Digital terminal input state 20: Digital terminal output state 21: Actual working carrier frequency 0 : Display output frequency(not mechanical speed) 0.1~5000.0 1~50000	
00-08	P.37	Speed display	0.0	
00-09	P.259	Speed display unit selection	1	
00-10	P.59	Built-in keypad set target frequency selection	---	
00-11	P.72	Carrier frequency	5 kHz	
00-12	P.31	Soft-PWM carrier function selection	0	
00-13	P.71	Idling brake / DC brake	1	
00-14	P.75	Stop function selection	1	
00-15	P.78	Prevent forward/reverse rotation selection	0	
00-16	P.79	Operation mode selection	0	
00-17	P.97	Second target frequency selection	0	
00-19	P.35	Communication mode selection	0	
00-21	P.300	Motor control mode selection	0	
00-24	P.189	50Hz/60Hz switch selection	0	
00-25	P.990	Parameter display mode setting	0	
► Basic Parameter Group 01				
01-00	P.1	Maximum frequency	0.00 ~ 01-02 (P.18) Hz	120.00Hz
01-01	P.2	Minimum frequency	0 ~ 120.00Hz	0.00Hz
01-02	P.18	High-speed maximum frequency	01-00 (P.1) ~ 650.00Hz	120.00Hz
01-03	P.3	Base frequency	50Hz system setting: 0 ~ 650.00Hz 60Hz system setting: 0 ~ 650.00Hz	50.00Hz 60.00Hz
01-04	P.19	Base voltage	0 ~ 1000.0V 99999: Change according to the input voltage	99999
01-05	P.29	Acceleration/deceleration curve selection	0: Linear acceleration /deceleration curve 1: S shape acceleration /deceleration curve 1 2: S shape acceleration /deceleration curve 2 3: S shape acceleration /deceleration curve 3	0
01-06	P.7	Acceleration time	0 ~ 360.00s/0 ~ 3600.0s : 3.7Kw and below 0 ~ 360.00s/0 ~ 3600.0s : 5.5Kw model	5.00s 10.00s
01-07	P.8	Deceleration time	0 ~ 360.00s/0 ~ 3600.0s : 3.7Kw and below 0 ~ 360.00s/0 ~ 3600.0s : 5.5Kw model	5.00s 10.00s
01-08	P.21	Acceleration/deceleration time increments	0: Time increment is 0.01s 1: Time increment is 0.1s	0 50.00Hz
01-09	P.20	Acceleration/deceleration reference frequency	50Hz system setting: 1.00 ~ 599.00Hz 60Hz system setting: 1.00 ~ 599.00Hz	50.00Hz 60.00Hz
01-10	P.0	Torque boost	0 ~ 30.0% : 0.75K and under 0 ~ 30.0% : 1.5K - 3.7K	6.0% 4.0%
01-11	P.13	Starting frequency	0 ~ 60.00Hz	0.50Hz
01-12	P.14	Load pattern selection	0: For constant torque loads (conveyor belt, etc.) 1: For variable torque loads (fans and pumps, etc.) 2, 3: For Lifting loads 4: Multipoint V/F curve 5-13: Special two-point V/F curve	0
01-13	P.15	JOG frequency	0 ~ 650.00Hz	5.00Hz
01-14	P.16	JOG Acc / Dec time	0 ~ 360.00s/0 ~ 3600.0s	0.50s
01-15	P.28	Output frequency filter time	0 ~ 31	0
01-16	P.91	Frequency jump 1A	0 ~ 650.00Hz 99999: Off	99999

01-17	P.92	Frequency jump 1B	0 ~ 650.00Hz 99999: Off	9999	
01-18	P.93	Frequency jump 2A	0 ~ 650.00Hz 99999: Off	9999	
01-19	P.94	Frequency jump 2B	0 ~ 650.00Hz 99999: Off	9999	
01-20	P.95	Frequency jump 3A	0 ~ 650.00Hz 99999: Off	9999	
01-21	P.96	Frequency jump 3B	0 ~ 650.00Hz 99999: Off	9999	
01-22	P.44	Second acceleration time	0 ~ 360.00s/0 ~ 3600.0s	3.00Hz	
01-23	P.45	Second deceleration time	0 ~ 360.00s/0 ~ 3600.0s	10.0%	
01-24	P.46	Second torque boost	0 ~ 30.0%	99999	
01-25	P.47	Second base frequency	0 ~ 650.00Hz	0.0%	
01-26	P.98	Middle frequency 1	0 ~ 650.00Hz	0.0%	
01-27</td					

			10 : STF+EXJ 11 : STR+EXJ 12 : STF+RT 13 : STR+RT 14 : STF+RL 15 : STR+RL 16 : STF+RM 17 : STR+RM 18 : STF+RH 19 : STR+RH 20 : STF+RL+RM 21 : STR+RL+RM 22 : STF+RT+RL 23 : STR+RT+RL 24 : STF+RT+RM 25 : STR+RT+RM 26 : STF+RT+RL+RM 27 : STR+RT+RL+RM 28: RUN(Inverter runs forward) 29: STF/STR(use with RUN signal, when ON, motor runs reverse ; when OFF, motor runs forward) 30: RES(External reset function) 31: STOP(Use as three line control with RUN signal and STF-STR signal) 32: REX(Extend multi-speed to 16 levels) 33: PO(In "external mode", run programmed operation) 34: RES_E (External reset, valid only when alarm.) 35: MPO (In "external mode" run manual cycle operation.) 36: TRI(Triangle wave function) 37 : Reserved 38 : Reserved 39: STF/STR +STOP (Use with RUN signal, when ON, motor runs reverse, when OFF, motor stops then runs forward.) 40: P_MRS (Stops inverter output immediately by pulse signal input) 41~42 : Reserved 43: RUN_EN (Enable digital input terminal operation) 44: PID_OFF (Enable digital input terminal turning off PID) 45: Second frequency command source mode	
03-01	P.84	Terminal STR input function	Same as 03-00	1
03-03	P.80	Terminal M0 input function	Same as 03-00	2
03-04	P.81	Terminal M1 input function	Same as 03-00	3
03-11	P.85	Terminal A-C output function	0: RUN(Output when inverter running) 1: SU(Output when reach target frequency) 2: FU(Output when reach 03-21 03-22 value) 3: OL(Output when overload) 4: OMD(Output when output current is zero) 5: ALARM(Output when alarm) 6: P01(Output when in program operation step) 7: P02(Output when in program operation cycle) 8: P03(Output when in program operation pause) 9 : Reserved 10 : Reserved 11 : OMD1(Output when output current is zero 1) 12 : OL2(Output when over torque) 13 ~ 16 : Reserved 17: RY(Output when inverter is powered on and no alarm) 18: Output when it's time for maintenance 41: Output when PID feedback signal disconnect	5
03-14	P.87	Digital input logic	0 ~ 15	0
03-15	P.88	Digital output logic	0 : Terminal A-C output positive logic 2 : Terminal A-C output negative logic	0
03-16	P.120	Output signal delay time	0 ~ 3600.0s	0.0s
03-17	P.157	Digital input terminal filter time	0 ~ 2000	4
03-18	P.158	Digital input terminal enable when power on	0: When power on digital terminals work directly 1: When power on digital terminals work after switch off then on	0
03-20	P.41	Output frequency detection sensitivity	0 ~ 100.0%	10.0%
03-21	P.42	Output frequency detection for forward rotation	0 ~ 650.00Hz	6.00Hz
03-22	P.43	Output frequency detection for reverse rotation	0 ~ 650.00Hz 99999: Same as the setting of 03-21(P.42)	99999
03-23	P.62	Zero current detection level	0 ~ 200.0% 99999: Off	5.0%
03-24	P.63	Zero current detection time	0.05 ~ 100.00s 99999: Off	0.50s

➤ Multi-speed Parameter Group 04

Group	No.	Name	Setting Range	Default	User Setting
04-00	P.4	Speed 1 (high speed)	0 ~ 650.00Hz	60.00Hz	
04-01	P.5	Speed 2 (medium speed)	0 ~ 650.00Hz	30.00Hz	
04-02	P.6	Speed 3 (low speed)	0 ~ 650.00Hz	10.00Hz	
04-03	P.24	Speed 4	0 ~ 650.00Hz 99999: Off	99999	
04-04	P.25	Speed 5	Same as 04-03(P.24)	99999	
04-05	P.26	Speed 6	Same as 04-03(P.24)	99999	
04-06	P.27	Speed 7	Same as 04-03(P.24)	99999	
04-07	P.142	Speed 8	0 ~ 650.00Hz	0.00Hz	
04-08	P.143	Speed 9	Same as 04-03(P.24)	99999	
04-09	P.144	Speed 10	Same as 04-03(P.24)	99999	
04-10	P.145	Speed 11	Same as 04-03(P.24)	99999	
04-11	P.146	Speed 12	Same as 04-03(P.24)	99999	
04-12	P.147	Speed 13	Same as 04-03(P.24)	99999	
04-13	P.148	Speed 14	Same as 04-03(P.24)	99999	
04-14	P.149	Speed 15	Same as 04-03(P.24)	99999	
04-15	P.100	Programmed operation minute / second selection	0: Select minute as the time increment. 1: Select second as the time increment.	1	
04-16	P.121	Run direction in each section	0 ~ 255	0	

04-17	P.122	Programmed operation cycle selection	0:Off 1~8: Start cycle from the set section.	0	
04-18	P.123	Programmed operation acceleration / deceleration time setting selection	0:Acceleration time is 01-06(P.7), deceleration time is 01-07(P.8). 1:Acceleration and deceleration time is set by 04-35(P.11) ~ 04-42(P.118).	0	
04-19	P.131	Programmed operation mode speed 1	0 ~ 650.00Hz	0.00Hz	
04-20	P.132	Programmed operation mode speed 2	0 ~ 650.00Hz	0.00Hz	
04-21	P.133	Programmed operation mode speed 3	0 ~ 650.00Hz	0.00Hz	
04-22	P.134	Programmed operation mode speed 4	0 ~ 650.00Hz	0.00Hz	
04-23	P.135	Programmed operation mode speed 5	0 ~ 650.00Hz	0.00Hz	
04-24	P.136	Programmed operation mode speed 6	0 ~ 650.00Hz	0.00Hz	
04-25	P.137	Programmed operation mode speed 7	0 ~ 650.00Hz	0.00Hz	
04-26	P.138	Programmed operation mode speed 8	0 ~ 650.00Hz	0.00Hz	
04-27	P.101	Programmed operation mode speed 1 operating time	0 ~ 6000.0s	0.0s	
04-28	P.102	Programmed operation mode speed 2 operating time	0 ~ 6000.0s	0.0s	
04-29	P.103	Programmed operation mode speed 3 operating time	0 ~ 6000.0s	0.0s	
04-30	P.104	Programmed operation mode speed 4 operating time	0 ~ 6000.0s	0.0s	
04-31	P.105	Programmed operation mode speed 5 operating time	0 ~ 6000.0s	0.0s	
04-32	P.106	Programmed operation mode speed 6 operating time	0 ~ 6000.0s	0.0s	
04-33	P.107	Programmed operation mode speed 7 operating time	0 ~ 6000.0s	0.0s	
04-34	P.108	Programmed operation mode speed 8 operating time	0 ~ 6000.0s	0.0s	
04-35	P.111	Programmed operation mode speed 1 Acc/Dec time	0 ~ 600.00s/0 ~ 6000.0s	0.00s	
04-36	P.112	Programmed operation mode speed 2 Acc/Dec time	0 ~ 600.00s/0 ~ 6000.0s	0.00s	
04-37	P.113	Programmed operation mode speed 3 Acc/Dec time	0 ~ 600.00s/0 ~ 6000.0s	0.00s	
04-38	P.114	Programmed operation mode speed 4 Acc/Dec time	0 ~ 600.00s/0 ~ 6000.0s	0.00s	
04-39	P.115	Programmed operation mode speed 5 Acc/Dec time	0 ~ 600.00s/0 ~ 6000.0s	0.00s	
04-40	P.116	Programmed operation mode speed 6 Acc/Dec time	0 ~ 600.00s/0 ~ 6000.0s	0.00s	
04-41	P.117	Programmed operation mode speed 7 Acc/Dec time	0 ~ 600.00s/0 ~ 6000.0s	0.00s	
04-42	P.118	Programmed operation mode speed 8 Acc/Dec time	0 ~ 600.00s/0 ~ 6000.0s	0.00s	
Motor Parameter Group 05					
Group	No.	Name	Setting Range	Default	User Setting
05-00	P.301	Motor specifications automatic measurement	0: Off	0	
			1: Induction motor specifications automatic measurement (Run motor to measure)		
			2: Induction motor specifications automatic measurement (Don't run motor to measure)		
			3: Induction motor specifications automatic measurement (Measure when operating)		
05-01	P.302	Motor rated power	0 ~ 160.00kW	0.00kW	
05-02	P.303	Motor poles	0 ~ 48	4	
05-03	P.304	Motor rated voltage	0 ~ 510V	380V/440V 220V	
05-04	P.305	Motor rated frequency	50Hz system : 0 ~ 650.00Hz 60Hz system : 0 ~ 650.00Hz		
05-05	P.306	Motor rated current	0~500.0A	According to kw	
05-06	P.307	Motor rated rotation speed	50Hz system : 0 ~ 9998r/min 60Hz system : 0 ~ 9998r/min		
05-07	P.308	Motor excitation current	0~500.0A		
05-08	P.309	IM motor stator resistance	0 ~ 99.98Ω	According to kw	
Protection Parameter Group 06					
Group	No.	Name	Setting Range	Default	User Setting
06-00	P.9	Electronic thermal relay capacity	0~500.00A	0.00A	
06-01	P.22	Stall prevention operation level	0 ~ 250.0%	150.0%	
06-02	P.23	Stall prevention operation level correction factor	0~200.0%	99999: Stall prevention operation level is the setting value of 06-01(P.22).	
			99999: Stall prevention operation level is the setting value of 06-01(P.22).		
06-03	P.66	Stall prevention operation reduction starting frequency	50Hz system: 0 ~ 650.00Hz 60Hz system: 0 ~ 650.00Hz	50.00Hz 60.00Hz	
06-04	P.67	Stall prevention operation reduction starting frequency	50Hz system: 0 ~ 650.00Hz 60Hz system: 0 ~ 650.00Hz		
06-05	P.30	Regenerative brake selection	0: Brake duty is fixed at 3%, parameter 06-06(P.70) will be off. 1: Brake duty is 06-06(P.70) value.	0	
06-06	P.70	Special regenerative brake duty	0 ~ 100.0%		
06-08	P.155	Over torque detection level	0 ~ 200.0%	0.0%	
06-09	P.156	Over torque detection time	0 ~ 60.0s	1.0s	
06-10	P.260	Action when detect over torque	0: OL2 alarm will not be reported after over torque detection, and inverter keeps running. 1: OL2 alarm will be reported after over torque detection, and inverter stops.	1	
			2 : When running and the heat sink temperature exceeds 60°C turn on the fan, under 40°C turn off the fan. 3 : When the heat sink temperature exceeds 60°C turn on the fan, under 40°C turn off the fan.		
06-12	P.245	Cooling fan working mode	0 : When running turn on the fan, after stop for 30 seconds turn off the fan. 1 : When power on turn on the fan, after power off turn off the fan.	1	
			2 : When running and the heat sink temperature exceeds 60°C turn on the fan, under 40°C turn off the fan. 3 : When the heat sink temperature exceeds 60°C turn on the fan, under 40°C turn off the fan.		
06-13	P.281	Input phase loss protection	0: Off 1: When input phase loss, built-in keypad shows IPF alarm and inverter stops	0	

			1 ~ 9998day: Used to set the time for maintenance alarm output signal		
18	P.280	Short circuit to ground protection function when start	0 : Off	0	
			1 : Detect short circuit to ground when inverter start		
19	P.282	GF detection level when operating	0 ~ 100%	50%	
27	P.292	Total inverter operation time (minutes)	0 ~ 1439 min	0 min	
28	P.293	Total inverter operation time (days)	0 ~ 9999 day	0 day	
29	P.296	Total inverter power on time (minutes)	0 ~ 1439 min	0 min	
30	P.297	Total inverter power on time (days)	0 ~ 9999 day	0 day	
40	P.288	Alarm record code query	Choose 0 ~ 12 recorded alarm	0	
41	P.289	Alarm record code display	Read only	Read only	
42	P.290	Alarm record message query	Choose 0 ~ 10 recorded alarm	0	
43	P.291	Alarm record message display	Read only	Read only	

communication Parameter Group 07

Group	No.	Name	Setting Range	Default	User Setting
00	P.33	Communication protocol selection	0: Modbus protocol 1: Shihlin protocol	1	
01	P.36	Inverter communication station number	0 ~ 254	0	
02	P.32	Serial communication baud rate	0 : Baud rate:4800bps 1 : Baud rate:9600bps 2 : Baud rate:19200bps 3 : Baud rate:38400bps 4 : Baud rate:57600bps 5 : Baud rate:115200bps	1	
03	P.48	Data length	0 : 8bit 1 : 7bit	0	
04	P.49	Stop bit length	0 : 1bit 1 : 2bit	0	
05	P.50	Parity check selection	0: No parity check 1: Odd 2: Even	0	
06	P.51	CR/LF selection	1: CR only 2: Both CR and LF	1	
07	P.154	Modbus communication format	0 : 1, 7, N, 2 (Modbus, ASCII) 1 : 1, 7, E, 1 (Modbus, ASCII) 2 : 1, 7, O, 1 (Modbus, ASCII) 3 : 1, 8, N, 2 (Modbus, RTU) 4 : 1, 8, E, 1 (Modbus, RTU) 5 : 1, 8, O, 1 (Modbus, RTU) 6 : 1, 8, N, 1 (Modbus, RTU)	4	
08	P.52	Number of communication retries	0 ~ 10	1	
09	P.53	Communication interval allowed time	0~999.8s: Checking communication timeout with the set value 99999: No timeout check	99999	
10	P.153	Communication alarm action	0: Alarm and stop freely 1: No alarm and continuing to operation	0	
11	P.34	EEPROM write-in selection	0: When writing parameters in communication mode, write in RAM and EEPROM 1: When writing parameters through communication, only write into RAM	0	

D Parameter Group 08

Group	No.	Name	Setting Range	Default	User Setting
00	P.170	PID function selection	0: Off 2 : Parameter 08-03(P.225) as target value, terminal 3-5 current/voltage input as feedback source	0	
01	P.171	PID feedback control method	0: Negative feedback control. 1: Positive feedback control.	0	
03	P.225	PID target value from keypad	0 ~ 08-43 (P.251)	20.0%	
04	P.172	Proportional gain	1~100	20	
05	P.173	Integral time	0 ~ 100.0s	1.0s	
06	P.174	Differential time	0 ~ 1000ms	0ms	
07	P.175	Abnormal deviation	0 ~ 100.0%	0.0%	
08	P.176	Abnormal duration time	0 ~ 600.0s	30.0s	
09	P.177	Abnormal processing mode	0: Stop freely 1: Slow down to stop 2: Alarm and continue operation	0	
10	P.178	Sleep detection deviation	0 ~ 100.0%	0.0%	
11	P.179	Sleep detection duration time	0 ~ 255.0s	1.0s	
12	P.180	Wake-up level	0 ~ 100.0%	90.0%	
13	P.181	Stop level	0 ~ 120.00Hz	40.00Hz	
14	P.182	Upper integral limit	50Hz system:0 ~ 120.00Hz 60Hz system:0 ~ 120.00Hz	50.00Hz 60.00Hz	
15	P.183	Deceleration step length when stable	0 ~ 10.00Hz	0.50Hz	
18	P.223	Analog feedback signal bias	0 ~ 100.0%	0.0%	
19	P.224	Analog feedback signal gain	0 ~ 100.0%	100.0%	
43	P.251	PID pressure unit (Bar) setting	1.0~100.0	100.0	
45	P.253	Analog signal feedback loss detection time	0.0~600.0s	0.0s	
46	P.254	Analog signal feedback loss action selection	0 : Alarm AErr and inverter stop freely 1 : Slow down to stop then alarm AErr 2 : Alarm AErr and continue operation	0	

selection

10-00	P.10	DC brake operating frequency	0 ~ 120.00Hz	3.00Hz
10-01	P.11	DC brake operating time	0 ~ 60.0s	0.5s
10-02	P.12	DC brake operating voltage	0 ~ 30.0%	4.0%
10-03	P.151	Zero-speed control function selection	0: Off.	0
			1: DC voltage braking	
10-04	P.152	Voltage at zero-speed control	0 ~ 30.0%	5.0%
10-05	P.242	DC brake before inverter start	0: Off	0
			1: Before starting operate DC brake first.	
10-06	P.243	DC brake time before inverter start	0 ~ 60.0s	0.5s
10-07	P.244	DC brake voltage before inverter start	0 ~ 30.0%	4.0%
10-08	P.150	Restart mode selection	X0 : No frequency search.	0
			X1 : Reserved	
10-09	P.57	Restart idling time	X2 : Decrease voltage mode	99999
			0X : Power on once.	
10-10	P.58	Restart rising time	1X : Start each time.	10.0s
			2X : Only instantaneous stop and restart	
10-11	P.61	Remote control function	0 ~ 30.0s 99999: Off.	0
10-12	P.65	Auto reset function	0: Off.	0
			1: When over-voltage, inverter will reset.	
10-13	P.67	Auto reset times	2: When over-current, inverter will reset.	0
			3: When either over-voltage or over-current, inverter will reset.	
10-14	P.68	Auto reset waiting time	4: When any alarm occurs, inverter will reset. 0 ~ 360.0s	6.0s
10-15	P.69	Auto reset times count	Read only	0
10-16	P.119	Forward and reverse rotation dead time	0 ~ 3000.0s	0.0s
10-17	P.159	Energy-saving control function	0: Off.	0
			1: Energy-saving mode.	
10-18	P.229	Dwell function selection	0: Off.	0
			1: Backlash compensation function.	
10-19	P.230	Dwell frequency at acceleration	2: Acceleration and deceleration interrupt waiting function.	1.00Hz
			0 ~ 650.00Hz	
10-20	P.231	Dwell time at acceleration	0 ~ 360.0s	0.5s
10-21	P.232	Dwell frequency at deceleration	0 ~ 650.00Hz	1.00Hz
10-22	P.233	Dwell time at deceleration	0 ~ 360.0s	0.5s
10-23	P.234	Triangular wave function selection	0: Off.	0
			1: If terminal function TRI is triggered, triangular wave function will on.	
10-24	P.235	Maximum amplitude	2: Triangular wave function is on at all time.	10.0%
			0 ~ 25.0%	
10-25	P.236	Amplitude compensation at deceleration	0 ~ 50.0%	10.0%
10-26	P.237	Amplitude compensation at acceleration	0 ~ 50.0%	10.0%
10-27	P.238	Amplitude acceleration time	0 ~ 360.00s/0 ~ 3600.0s	10.00s
10-28	P.239	Amplitude deceleration time	0 ~ 360.00s/0 ~ 3600.0s	10.00s
10-46	P.268	Voltage stall level	220V : 155 ~ 400V	380V
			440V : 310 ~ 800V	
10-55	P.226	Reciprocating machine function selection	0 : Off	0
			1 : Turn on reciprocating machine function	
10-56	P.227	Reciprocating forward limit time	0~3600.0s	0.0s
10-57	P.228	Reciprocating reverse limit time	0~3600.0s	0.0s

➤ Speed control parameter group 11

Speed control parameter group 11					
Group	No.	Name	Setting Range	Default	User Setting
11-00	P.320	Slip compensation gain	0~200%	85%	
11-01	P.321	Torque boost filter coefficient	0~2000	20	
11-02	P.322	Cutoff frequency point of current filter time 1	0~30.00Hz	4.00Hz	
11-03	P.323	Current filter time 1	0~400.00ms	20.00ms	
11-04	P.324	Low frequency current filter time 2	0~400.00ms	1.00ms	
11-05	P.325	High frequency current filter time 2	0~400.00ms	36.00ms	


➤ Special Adjustment Parameter Group 13

Special Adjustment Parameter Group 10					
Group	No.	Name	Setting Range	Default	User Setting
13-00	P.89	Slip compensation coefficient	0 ~ 10	0	
13-03	P.286	High frequency vibration suppression factor	0 ~ 15	0	

suppress

User Parameter Group 15					
Group	No.	Name	Setting Range	Default	User Setting
15-00	P.900	User registered parameter 1	P parameter mode:0 ~ 399 Parameter group mode : 00-00-13-99	99999	
15-01	P.901	User registered parameter 2		99999	
15-02	P.902	User registered parameter 3		99999	
15-03	P.903	User registered parameter 4		99999	
15-04	P.904	User registered parameter 5		99999	
15-05	P.905	User registered parameter 6		99999	
15-06	P.906	User registered parameter 7	P parameter mode:0 ~ 399 Parameter group mode : 00-00-13-99	99999	
15-07	P.907	User registered parameter 8		99999	
15-08	P.908	User registered parameter 9		99999	
15-09	P.909	User registered parameter 10		99999	

15-10	P.910	User registered parameter 11
15-11	P.911	User registered parameter 12
15-12	P.912	User registered parameter 13
15-13	P.913	User registered parameter 14
15-14	P.914	User registered parameter 15
15-15	P.915	User registered parameter 16
15-16	P.916	User registered parameter 17
15-17	P.917	User registered parameter 18
15-18	P.918	User registered parameter 19
15-19	P.919	User registered parameter 20




11) Switching Parameter Mode

► SC3 series classify parameters according to functions, and default displayed as "Group Mode".

➤ If users prefer to display as "P.xxx" mode, please set parameter 00-25 as "1", and parameters will be displayed as "Traditional P Mode".

12) Parameter Setting Flow chart

► Operation mode switching flow chart :




13) Others


► To improve our products, the parameters and contents may be modified, please contact the agent or refer to Shihlin websites (<http://automation.seec.com.tw/>) to download the latest version.



► Work mode switching flow chart :




➤ Monitor mode switching flow chart :



► Frequency setting flow chart :



► Parameter setting flow chart :



► HELP mode flow chart