



Shihlin Electric General Inverters SC3 Series Simple instruction

V1.09-01

SC3-021-0.2K~2.2K
SC3-023-0.2K~3.7K
SC3-043-0.4K~5.5K
SC3-043-7.5K/11KF~18.5K/22KF
SC3-043-22K

Thank you for choosing Shihlin inverters SC3 series.

These instructions will explain the use and precautions of the product. Please read the instructions carefully before installation and use the inverter correctly and safely.

*Actual maximum output frequency is 599Hz, Even if the parameter setting exceeds 599Hz, the maximum output frequency will still be 599Hz.

1) Safety Instructions

Safety Instructions

- ✓ Please contact the professionals to install, operate, maintain and inspect the product.
- ✓ The safety level could be classified as "Warning" and "Caution".
- ⚠ Warning: the incorrect operation may cause hazardous situation, and accordingly lead to death or serious injury.
- ⚠ Caution: the incorrect operation may cause hazardous situation, and accordingly lead to general or minor injury or damage of the object.

⚠ Warning

- ✓ The front cover plate and the wiring board should not be opened when the inverter is powered on. In addition, the inverter should not be operated when the front cover plate and the wiring board are demounted. Otherwise, the electric shock may be caused due to contacting with the high-voltage terminal and the charging part.
- ✓ If the wiring needs to be changed or inspection is required, the power supply of the inverter should be turned off first. There is still high voltage inside the inverter before the LED display of the inverter is turned off. Therefore, please don't touch the internal circuit and parts.
- ✓ The inverter must be earthed correctly.
- ✓ Please don't operate with wet hands, don't touch the heat sink, and don't plug and unplug the cable; or electric shock may be caused.
- ✓ Do not replace the cooling fan when the inverter is powered on, otherwise the risk may occur. It is dangerous to replace the cooling fan when the inverter is powered on.

⚠ Caution

- ✓ Voltage applied to each terminal must be the one specified in the user manual; otherwise, failure or damage may be caused.
- ✓ Do not operate a voltage-resistant test for the parts inside the inverter because semiconductors in inverter may be easily damaged due to high-voltage breakdown.
- ✓ Do not touch the inverter because the temperature of the inverter is very high when it is powered on or right after disconnecting the power supply, only built-in keypad is touchable, otherwise, scalds may occur.
- ✓ Failure or damage may be caused due to wrong wiring.
- ✓ Do not reverse the polarities (+, -) by mistake, otherwise failure or damage may be caused.
- ✓ Please install the inverter on nonflammable walls without holes (to avoid contacting with the cooling fin of the inverter from the back). If the inverter is installed on or close to flammable objects it may cause a fire.
- ✓ Please disconnect the inverter from power supply in case of failure. Overload current passes through the inverter continuously may cause a fire.

2) Product Model


	SC3-043	7.5K/11KF	X
Series category	Voltage level	Capacity	Others
SC3 series	-043 : three phase 440V -023 : three phase 220V -021 : single phase 220V	Heavy Duty : 7.5kW Normal Duty : 11kW	None : General model -xy : Customization or specialization or region difference

3) Installation Environment

Ambient temperature	-10 ~ +50°C (non-freezing), parallel install -10~ +40°C (non-freezing).
Ambient humidity	Under 90%Rh (non-condensing).
Storage temperature	-20 ~ +65°C.
Surrounding environment	Indoor, no corrosive gas, no flammable gas, no flammable dust.
Altitude	Altitude below 2000 meters. When altitude is above 1,000 m, derate the rated current 2% per 100 m
Vibration	Below 5.9m/ s ² (0.6G)
Protection level	IP20
Pollution degree	2

4) Installation and Wiring


- Please install the inverter vertically in order not to reduce the heat dissipation effect:




(a) Vertical arrangement (b) Horizontal arrangement (c) Level arrangement

- Please follow the installation restrictions shown below to ensure enough ventilation space for inverter cooling and wiring space:

- Single or side-by-side installation :



• Arrangement of multiple inverters :




Note 1: Before installing inverters with different sizes in parallel, please align the upper positions of the inverters for easier replacement of the cooling fan.

Note2: When it is inevitable to arrange inverters vertically to minimize space, please install guides since heat from the bottom inverters can increase the temperature on the top inverters and cause inverter failures.


Note 3: Side-by-side installation, that is, when the D dimension is 0, ensure that the ambient temperature in the cabinet is not higher than 40°C. It is not possible to use keypad or communicate through the RS485 interface.

(a) Horizontal arrangement (b) Vertical arrangement

• Din rail installation :



5) Terminal Connection Diagrams



Note 1: SC3-043-0.4K~1.5K, SC3-023-0.2K~1.5K, SC3-021-0.2K~0.75K without +/P, PR and N terminals; SC3-043-2.2K~5.5K, SC3-023-2.2K~3.7K, SC3-021-1.5K~2.2K without N terminals.


Note 2: All SC3 have built-in RF filters to suppress electromagnetic interference, but to comply with CE regulations, please refer to the relevant instructions in the user manual for installation.

6) Main Circuit Wiring and Terminal Specification

Inverter model	Terminal screw specifications	Tightening torque(Kgf.cm)	Recommended wiring specification(mm ²)				Recommended wiring specification (AWG)			
			R, S, T	U, V, W	+/P, PR	Grounding Cable	R, S, T	U, V, W	+/P, PR	Grounding Cable
SC3-021-0.2K	M3	4-6	2.5	1.5	---	1.5	14	16	---	16
SC3-023-0.2K			1.5	1.5	---	1.5	16	16	---	16
SC3-043-0.4K			1.5	1.5	---	1.5	16	16	---	16
SC3-021-0.4K			2.5	2.5	---	2.5	14	14	---	14
SC3-023-0.4K			2.5	2.5	---	2.5	14	14	---	14
SC3-043-0.75K			2.5	2.5	---	2.5	14	14	---	14
SC3-021-0.75K			2.5	2.5	---	2.5	14	14	---	14
SC3-023-0.75K			2.5	2.5	---	2.5	14	14	---	14
SC3-043-1.5K			2.5	2.5	---	2.5	14	14	---	14
SC3-021-1.5K			2.5	2.5	---	2.5	14	14	---	14
SC3-043-2.2K			2.5	2.5	2.5	2.5	14	14	14	14
SC3-021-2.2K			2.5	2.5	2.5	2.5	14	14	14	14
SC3-023-2.2K			4	4	4	4	12	12	12	12
SC3-043-3.7K			4	4	4	4	12	12	12	12
SC3-043-5.5K	M4	9.5~10.5	2.5	2.5	2.5	2.5	10	14	14	14
SC3-023-3.7K			2.5	2.5	2.5	2.5	14	14	14	14
SC3-043-7.5K/11KF	M5	19~20	6	6	6	6	10	10	10	10
SC3-043-11K/15KF			10	10	10	10	8	8	8	8
SC3-043-15K/18.5KF			10	10	10	10	8	8	8	8
SC3-043-18.5K/22KF			16	16	16	16	6	6	6	6
SC3-043-22K			25	25	25	25	4	4	4	4

7) Control Terminal

► Arrangement of control terminal



► Control terminal description

Terminal type	Terminal name	Function instructions	Terminal specifications
Digital signal input	STF	These four terminals are multifunction digital input, can switch between SINK/SOURCE.	Input impedance:4.7 kΩ
	STR		Action current:5mA(when 24VDC)
	M0		Voltage range:10~28VDC
	M1		Maximum frequency:1kHz
Analog signal input	10	+10.5±0.5V	Maximum current:10mA
	3	0~10V/4~20mA	Input impedance:10kΩ
Relay output	A	Multi-function relay output terminals. A-C is normally open contact, C is common terminal.	Maximum voltage:30VDC or 250VAC
	C		Maximum current: Resistor load 5A NO/3A NC Inductance load 2A NO/1.2A (cosΦ=0.4)
Communication terminal	RJ45	RS485, optical coupling isolation RJ45 and "DA+/DB-" can't work at the same time	Distance: up to 500m
	DA+		Bit rate: up to 115200bps
Common terminal	5/SD	Common terminal for terminal STF,STR,M0, M1,3 (SINK)	---
	PC	Common terminal for terminal STF,STR,M0, M1 (SOURCE)	---

Note1: When connecting control terminal to external devices, please pay attention to the voltage and current specifications of terminals to avoid damaging the inverter.

Note2 : The function of the control terminal is decided by inverter parameters, please refer to user manual for setting.

Note3 : Please pay attention to polarity when connect to external power and devices.

► Wiring method

• Wire connection



For the control circuit wiring, strip off the sheath of a cable, and use it with a blade terminal. For a single wire, strip off the sheath of the wire and apply it directly.

Insert the blade terminal or the single wire into a socket of the terminal.

(1) Strip off the sheath according to the lengths provided by the table below. If the length of the sheath peeled is too long, a short circuit may occur with neighboring wires. If the length is too short, wires might come off.

Model	W	W1	H	H1	H2	D	S1
SC3-021-0.2K							
SC3-021-0.4K							
SC3-021-0.75K							
SC3-023-0.2K							
SC3-023-0.4K							
SC3-023-0.75K							
SC3-023-1.5K							
SC3-043-0.4K							
SC3-043-0.75K							
SC3-043-1.5K							

► Frame B/C/D



unit : mm

Model	W	W1	H	H1	H2	D	S1
SC3-021-1.5K							
SC3-021-2.2K							
SC3-023-2.2K							
SC3-023-3.7K							
SC3-043-2.2K							
SC3-043-3.7K							
SC3-043-5.5K							
SC3-043-7.5K/11KF							
SC3-043-11K/15KF							
SC3-043-15K/18.5KF							
SC3-043-18.5K/22KF							
SC3-043-22K							

Note1: Frame C and frame D do not have this feature, that is, they do not support DIN rail installation

9) Optional Equipment

Category	Name	Description	Order code
Keypad	PU301	LED display	SNKPU301
	DU06	LED display	SNKDU06
	DU08	LED display	SNKDU08
	PU302	LED display	SNKPU302
	DU10	LED display	SNKDU10

10) Parameter group

► System Parameter Group 00

Group	No.	Name	Setting Range	Default	User Setting
00-00	P.90	Inverter model	Read only	---	
00-01	P.188	Firmware version	Read only	---	
00-02	P.996 ~ P.999	Parameter restoration	0: Off	0	
			1: Clear alarm history (P.996=1)		
			2: Reset inverter (P.997=1)		
			3: Restore all parameters to default (P.998=1)		
			4: Partly restore parameters to default 1 (P.999=1)		
			5: Partly restore parameters to default 2 (P.999=2)		
00-03	P.77	Selection of parameters writing protection	6: Partly restore parameters to default 3 (P.999=3)		
			0: Parameters can be written only when the motor stops.		
			1: Parameters cannot be written.		
			2: Parameters can also be written when the motor is running.		
			3: Parameters cannot be read when in password protection.		
			0-65535	0	
00-04	P.294	Password parameter	0-65535	0	
00-05	P.295	Password setup	2-65535	0	
00-06	P.110	Built-in keypad monitor selection	X0 : When inverter starts, built-in keypad enters monitor mode automatically, screen displays current output frequency (with slip compensation).	2	
			X1 : When inverter starts, built-in keypad displays current target frequency.		
			X2 : When inverter starts, built-in keypad enters monitor mode automatically, screen displays current steady state output frequency.		
			X3 : When inverter starts, built-in keypad enters monitor mode automatically, screen displays current pressure and feedback pressure of the constant pressure system in percentage		
			X4 : When inverter starts, built-in keypad doesn't enter monitor mode but enter the previous mode before power off.		
			X5 : When inverter starts, built-in keypad enters monitor mode automatically, screen displays current pressure and feedback pressure of the constant pressure system		
			4X: When the inverter is on standby, the keypad automatically enters target frequency mode and the value flashes		

Group	No.	Name	Setting Range	Default	User Setting
00-07	P.161	Multi-function display	0: Output AC voltage (V) 1: DC bus voltage (V) 2: Inverter temperature rising accumulation rate (%) 3: Target pressure of the constant pressure system (%) 4: Feedback pressure of the constant pressure system (%) 5: Running frequency (Hz) 6: Electronic thermal accumulation rate (%) 7: Reserved 8: Signal value (mA) of 3-5 input terminals (mA/V). 9: Output power (kW). 10: Reserved 11: Forward/reverse rotation signal. Built-in keypad: Frd is forward, Rev is reverse, STOP is not operating status. External keypad: 1 is forward, 2 is reverse, 0 is not operating status.. 12: NTC temperature (°C) 13 : Motor electronic thermal accumulation rate (%) 14~18 : Reserved 19: Digital terminal input state 20: Digital terminal output state 21: Actual working carrier frequency	0	
00-08	P.37	Speed display	0 : Display output frequency(not mechanical speed) 0.1~5000.0 1~50000	0.0	
00-09	P.259	Speed display unit selection	0: Speed display unit is 1 1: Speed display unit is 0.1	1	
00-10	P.59	Built-in keypad set target frequency selection	XXX0: Use jog wheel on built-in keypad or external keypad to set frequency XXX1: Use keypad knob on external keypad to set frequency X0XX: After changing the frequency, it will be automatically stored within 30s X1XX: After changing the frequency, it will be automatically saved within 10s X2XX: Every frequency change will not save 0XXX: Set frequency will work immediately when using jog wheel on built-in keypad 1XXX: Set frequency will work after pressing SET when using up and down buttons on built-in keypad 11K/15Kf and below model : 1~15kHz 15K/18.5Kf and above Heavy Duty : 1~15kHz 15K/18.5Kf and above Normal Duty : 1~10kHz	--	
00-11	P.72	Carrier frequency	0: Off 1: When 00-11(P.72)<9, if the IGBT temperature is higher than 60°C, carrier frequency will decrease automatically. When the temperature drops to under 40°C, carrier frequency go back to 00-11(P.72) value	5 kHz	
00-12	P.31	Soft-PWM carrier function selection	0: Off 1: When 00-11(P.72)<9, if the IGBT temperature is higher than 60°C, carrier frequency will decrease automatically. When the temperature drops to under 40°C, carrier frequency go back to 00-11(P.72) value	0	
00-13	P.71	Idling brake / DC brake	0: Idling brake 1: DC brake	1	
00-14	P.75	Stop function selection	0: Press STOP button and inverter stops running in PU and H2 mode 1: Press STOP button and inverter stops running in all modes.	1	
00-15	P.78	Prevent forward/reverse rotation selection	0: Forward/reverse rotation are both permitted. 1: Prevent reverse rotation (When giving reverse signal, the motor will decelerate and stop). 2: Prevent forward rotation (When giving forward signal, the motor will decelerate and stop).	0	
00-16	P.79	Operation mode selection	0: "PU mode", "external mode" and "Jog mode" are interchangeable. 1: "PU mode" and "JOG mode" are interchangeable. 2: "External mode" only 3: "Communication mode" only 4: "Combined mode 1" 5: "Combined mode 2" 6: "Combined mode 3" 7: "Combined mode 4" 8: "Combined mode 5"	0	
00-17	P.97	Second target frequency selection	0: Frequency set by built-in keypad 1: Frequency set by RS485 communication 2: Frequency set by analog input	0	
00-19	P.35	Communication mode selection	0: In communication mode, run command and frequency are given by communication. 1: In communication mode, run command and frequency are given by external signal.	0	
00-21	P.300	Motor control mode selection	0: Induction motor V/F control 1: Reserved	0	
00-23	P.186	Motor types selection	0: Normal Duty (ND), on fan and pump duty type. 1: Heavy Duty (HD), apply to other duties.	1	
00-24	P.189	50Hz/60Hz switch selection	0: Default value of frequency related parameter is 60Hz. 1: Default value of frequency related parameter is 50Hz.	0	
00-25	P.990	Parameter display mode setting	0: Parameter is displayed in "group mode" 1: Parameter is displayed in "sequence P mode"	0	
► Basic Parameter Group 01					
Group	No.	Name	Setting Range	Default	User Setting
01-00	P.1	Maximum frequency	0.00 ~ 01-02 (P.18) Hz	120.00Hz	
01-01	P.2	Minimum frequency	0 ~ 120.00Hz	0.00Hz	
01-02	P.18	High-speed maximum frequency	01-00 (P.1) ~ 650.00Hz	120.00Hz	
01-03	P.3	Base frequency	50Hz system setting: 0 ~ 650.00Hz 60Hz system setting: 0 ~ 650.00Hz	50.00Hz	
01-04	P.19	Base voltage	0 ~ 1000.0V 99999: Change according to the input voltage	99999	
01-05	P.29	Acceleration/deceleration curve selection	0: Linear acceleration/deceleration curve 1: S shape acceleration/deceleration curve 1 2: S shape acceleration/deceleration curve 2 3: S shape acceleration/deceleration curve 3	0	

Group	No.	Name	Setting Range	Default	User Setting
01-06	P.7	Acceleration time	3.7K and below model : 0 ~ 360.00s/0 ~ 3600.0s 5.5K model : 0 ~ 360.00s/0 ~ 3600.0s 7.5K/11KF and above model : 0 ~ 360.00s/0 ~ 3600.0s	5.00s	
01-07	P.8	Deceleration time	3.7K and below model : 0 ~ 360.00s/0 ~ 3600.0s 5.5K~7.5K/11KF model : 0 ~ 360.00s/0 ~ 3600.0s 11K/15KF and above model : 0 ~ 360.00s/0 ~ 3600.0s	10.00s	
01-08	P.21	Acceleration/deceleration time unit	0: Time unit is 0.01s 1: Time unit is 0.1s	0	
01-09	P.20	Acceleration/deceleration reference frequency	50Hz system setting: 1.00 ~ 599.00Hz 60Hz system setting: 1.00 ~ 599.00Hz	50.00Hz	</td

Group	No.	Name	Setting Range	Default	User Setting
02-25	P.198	Terminal 3-5 minimum input current/ voltage	0 ~ 20.00 mA /V	0.00V	
02-26	P.199	Terminal 3-5 maximum input current/ voltage	0 ~ 20.00 mA /V	10.00V	
02-27	P.196	Percentage corresponds to terminal 3-5 minimum input current/ voltage	0 ~ 100.0%	0.0%	
02-28	P.197	Percentage corresponds to terminal 3-5 maximum input current/ voltage	0 ~ 100.0%	100.0%	
02-52	P.56	Inverter rated current display level	0~500.00A	According to kW	
02-61	P.141	Polarity of percentage which corresponds to terminal 3-5 current/ voltage signal	0~11	0	

➤ Digital Input/ Output Parameter Group 03

Group	No.	Name	Setting Range	Default	User Setting
03-00	P.83	Terminal STF input function	0: STF(Inverter runs in forward direction) 1: STR(Inverter runs in reverse direction) 2: RL(Multi-speed low speed) 3: RM(Multi-speed medium speed) 4: RH(Multi-speed high speed) 5: Reserved 6: External thermal relay actuate 7: MRS/Stops inverter output immediately 8: RTI(Inverter second function) 9: EXJ(External JOG) 10 : STF+EXJ 11 : STR+EXJ 12 : STF+RT 13 : STR+RT 14 : STF+RL 15 : STR+RL 16 : STF+RM 17 : STR+RM 18 : STF+RH 19 : STR+RH 20 : STF+RL+RM 21 : STR+RL+RM 22 : STF+RT+RL 23 : STR+RT+RL 24 : STF+RT+RM 25 : STR+RT+RM 26 : STF+RT+RL+RM 27 : STR+RT+RL+RM 28: RUN(Inverter runs in forward direction) 29: STF/STR(use with RUN signal, when ON, motor runs in reverse direction; when OFF, motor runs in forward direction) 30: RES(External reset function) 31: STOP(Use as three line control with RUN signal and STF-STR signal) 32: REX(Extend multi-speed to 16 levels) 33: PO(In "external mode", run programmed operation) 34: RES_E (External reset, valid only when alarm.) 35: MPO (In "external mode" run manual cycle operation.) 36: TRI(Triangle wave function) 37 : Reserved 38 : Reserved 39: STF/STR +STOP (Use with RUN signal, when ON, motor runs in reverse direction, when OFF, motor stops and runs in forward direction.) 40: P_MRS (Stops inverter output immediately by pulse signal input) 41~42 : Reserved 43: RUN_EN (Enable digital input terminal operation) 44: PID_OFF (Enable digital input terminal turning off PID) 45: Second frequency command source mode 46~91:Reserved 92: Fire mode command 1 (with run command) 93: Fire mode command 2 (without run command)	0	
03-01	P.84	Terminal STR input function	Same as 03-00	1	
03-03	P.80	Terminal M0 input function	Same as 03-00	2	
03-04	P.81	Terminal M1 input function	Same as 03-00	3	
03-11	P.85	Terminal A-C output function	0: RUN(Output when inverter is running) 1: SU(Output when reach target frequency) 2: FU(Output when reach 03-21 03-22 value) 3: OL(Output when overload) 4: OMD(Output when output current is zero) 5: ALARM(Output when alarm) 6: PO1(Output when the program procedure completed) 7: PO2(Output when the program cycle completed) 8: PO3(Output when the program paused) 9 : Reserved 10 : Reserved 11 : OMD1(Output when output current is zero) 12 : OL2(Output when over torque) 13 ~ 16 : Reserved 17: RY(Output when inverter is powered on and no alarm) 18: Output when it's time for maintenance 41: PID feedback line break (AErr) alarm 42: Fire mode indication	5	
03-14	P.87	Multifunction Digital input logic	0 ~ 15	0	
03-15	P.88	Multifunction Digital output logic	0 : Terminal A-C output positive logic 2 : Terminal A-C output negative logic	0	
03-16	P.120	Output signal delay time	0 ~ 3600.0s	0.0s	
03-17	P.157	Digital input terminal filter time	0 ~ 2000	4	
03-18	P.158	Digital input terminal enabled when power on	0: When power on digital terminals work directly 1: When power on digital terminals work after switching off then on	0	

Group	No.	Name	Setting Range	Default	User Setting
03-20	P.41	Output frequency detection sensitivity	0 ~ 100.0%	10.0%	
03-21	P.42	Output frequency detection for forward rotation	0 ~ 650.00Hz	6.00Hz	
03-22	P.43	Output frequency detection for reverse rotation	0 ~ 650.00Hz 99999: Same as the setting of 03-21(P.42)	99999	
03-23	P.62	Zero current detection level	0 ~ 200.0% 9999: Off	5.0%	
03-24	P.63	Zero current detection time	0.05 ~ 100.00s 9999: Off	0.50s	

➤ Multi-speed Parameter Group 04

Group	No.	Name	Setting Range	Default	User Setting
04-00	P.4	Speed 1 (high speed)	0 ~ 650.00Hz	60.00Hz	
04-01	P.5	Speed 2 (medium speed)	0 ~ 650.00Hz	30.00Hz	
04-02	P.6	Speed 3 (low speed)	0 ~ 650.00Hz	10.00Hz	
04-03	P.24	Speed 4	0 ~ 650.00Hz 9999: Off	99999	
04-04	P.25	Speed 5	Same as 04-03(P.24)	99999	
04-05	P.26	Speed 6	Same as 04-03(P.24)	99999	
04-06	P.27	Speed 7	Same as 04-03(P.24)	99999	
04-07	P.142	Speed 8	Same as 04-03(P.24)	0.00Hz	
04-08	P.143	Speed 9	Same as 04-03(P.24)	99999	
04-09	P.144	Speed 10	Same as 04-03(P.24)	99999	
04-10	P.145	Speed 11	Same as 04-03(P.24)	99999	
04-11	P.146	Speed 12	Same as 04-03(P.24)	99999	
04-12	P.147	Speed 13	Same as 04-03(P.24)	99999	
04-13	P.148	Speed 14	Same as 04-03(P.24)	99999	
04-14	P.149	Speed 15	Same as 04-03(P.24)	99999	
04-15	P.100	Programmed operation minute / second selection	0: Select minute as the time unit 1: Select second as the time unit	1	
04-16	P.121	Run direction in each section	0~255	0	
04-17	P.122	Programmed operation cycle selection	0:Off 1~8: Start cycle from the set section.	0	
04-18	P.123	Programmed operation acceleration / deceleration time setting selection	0:Acceleration time is 01-06(P.7), deceleration time is 01-07(P.8). 1:Acceleration and deceleration time is set by 04-35(P.111)~04-42(P.118).	0	
04-19	P.131	Programmed operation mode speed 1	0 ~ 650.00Hz	0.00Hz	
04-20	P.132	Programmed operation mode speed 2	0 ~ 650.00Hz	0.00Hz	
04-21	P.133	Programmed operation mode speed 3	0 ~ 650.00Hz	0.00Hz	
04-22	P.134	Programmed operation mode speed 4	0 ~ 650.00Hz	0.00Hz	
04-23	P.135	Programmed operation mode speed 5	0 ~ 650.00Hz	0.00Hz	
04-24	P.136	Programmed operation mode speed 6	0 ~ 650.00Hz	0.00Hz	
04-25	P.137	Programmed operation mode speed 7	0 ~ 650.00Hz	0.00Hz	
04-26	P.138	Programmed operation mode speed 8	0 ~ 650.00Hz	0.00Hz	
04-27	P.101	Programmed operation mode speed 1 operating time	0 ~ 6000.0s	0.s	
04-28	P.102	Programmed operation mode speed 2 operating time	0 ~ 6000.0s	0.s	
04-29	P.103	Programmed operation mode speed 3 operating time	0 ~ 6000.0s	0.s	
04-30	P.104	Programmed operation mode speed 4 operating time	0 ~ 6000.0s	0.s	
04-31	P.105	Programmed operation mode speed 5 operating time	0 ~ 6000.0s	0.s	
04-32	P.106	Programmed operation mode speed 6 operating time	0 ~ 6000.0s	0.s	
04-33	P.107	Programmed operation mode speed 7 operating time	0 ~ 6000.0s	0.s	
04-34	P.108	Programmed operation mode speed 8 operating time	0 ~ 6000.0s	0.s	
04-35	P.111	Programmed operation mode speed 1 Acc/Dec time	0 ~ 600.00s/0 ~ 6000.0s	0.00s	
04-36	P.112	Programmed operation mode speed 2 Acc/Dec time	0 ~ 600.00s/0 ~ 6000.0s	0.00s	
04-37	P.113	Programmed operation mode speed 3 Acc/Dec time	0 ~ 600.00s/0 ~ 6000.0s	0.00s	
04-38	P.114	Programmed operation mode speed 4 Acc/Dec time	0 ~ 600.00s/0 ~ 6000.0s	0.00s	
04-39	P.115	Programmed operation mode speed 5 Acc/Dec time	0 ~ 600.00s/0 ~ 6000.0s	0.00s	
04-40	P.116	Programmed operation mode speed 6 Acc/Dec time	0 ~ 600.00s/0 ~ 6000.0s	0.00s	
04-41	P.117	Programmed operation mode speed 7 Acc/Dec time	0 ~ 600.00s/0 ~ 6000.0s	0.00s	
04-42	P.118	Programmed operation mode speed 8 Acc/Dec time	0 ~ 600.00s/0 ~ 6000.0s	0.00s	

Group	No.	Name	Setting Range	Default	User Setting
05-03	P.304	Motor rated voltage	0 ~ 510V	380V/440V 220V	
05-04	P.305	Motor rated frequency	50Hz system : 0 ~ 650.00Hz 60Hz system : 0 ~ 650.00Hz	50.00Hz 60.00Hz	
05-05	P.306	Motor rated current	0~500.0A	According to kW	
05-06	P.307	Motor rated rotation speed	50Hz system : 0 ~ 65000r/min 60Hz system : 0 ~ 65000r/min	1410r/min 1710r/min	
05-07	P.308	IM motor excitation current	0~500.0A	According to kW	
05-08	P.309	IM motor stator resistance	0 ~ 99.98Ω	According to kW	

➤ Protection Parameter Group 06

Group	No.	Name	Setting Range	Default	User Setting
06-00	P.9	Electronic thermal relay capacity	0~500.00A	0.00A	
06-01	P.22	Stall prevention operation level	0 ~ 250.0%	150.0%	
06-02	P.23	Stall prevention operation level correction factor	0 ~ 200.0% 99999: Stall prevention operation level is the setting value of 06-01(P.22).	99999	
06-03	P.66	Stall prevention for frequency decrement	50Hz system: 0 ~ 650.00Hz 60Hz system: 0 ~ 650.00Hz	50.00Hz 60.00Hz	
06-05	P.30	Regenerative brake selection	0: Brake duty is fixed at 3%, parameter 06-06(P.70) will be off. 1: Brake duty is 06-06(P.70) value.	0	
06-06	P.70	Special regenerative brake duty	0 ~ 100.0%	0.0%	
06-08	P.155	Over torque detection level	0 ~ 200.0%	0.0%	
06-09	P.156	Over torque detection time	0 ~ 60.0s	1.0s	
06-10	P.260	Action for over torque detection	0: OL2 alarm will not be reported after over torque detection, and inverter keeps running. 1: OL2 alarm will be reported after over torque detection, and inverter stops.	1	
06-12	P.245	Cooling fan working mode	0 : Turn on the fan while running., Turn off the fan after stopping for 30 seconds. 1 : After the power is on, the fan will remain ON. The fan will be turned off when the power is off. 2 : The fan will be turned on when the heat sink temperature exceeds 60°C during running. The fan will be turned off when the temperature is under 40°C or the power is off. 3 : When the heat sink temperature exceeds 60°C, turn on the fan; under 40°C, turn off the fan.	1	
06-13	P.281	Input phase loss protection	0: Off 1: When losing input phase, built-in keypad shows IPF alarm and inverter stops	0	
06-17	P.261	Maintenance reminder function	0: Off 1 ~ 9998day: Used to set the time for alarm output signal as reminder of maintenance.	0	
06-18	P.280	Detection for leakage current of ground when starting	XX0 : Off XX1 : Detect leakage current of ground when inverter starts OX1 : Detect leakage current of ground only for the first startup 1X1 : Detect leakage current of ground for every startup.	0	
06-19	P.282	GF detection level when operating	0 ~ 100%	50%	
06-27	P.292	Total inverter operation time (minutes)	0 ~ 1439 min	0 min	
06-28	P.293	Total inverter operation time (days)	0 ~ 9999 day	0 day	
06-29	P.296	Total inverter power-on time (minutes)	0 ~ 1439 min	0 min	
06-30	P.297	Total inverter power-on time (days)	0 ~ 9999 day	0 day	
06-40	P.288	Alarm error code query	Choose 0 ~ 12 recorded alarm	0	
06-41	P.289	Alarm error code display	Read only	Read only	
06-42	P.290	Alarm message query	Choose 0 ~ 12 recorded alarm	0	
06-43	P.291	Alarm message display	Read only	Read only	
06-84	P.207	Fire mode	XXX0:Off (fire mode off (normal mode)) XXX1:Forward operation (inverter runs in forward direction in fire mode) XXX2:Reverse operation (inverter runs in reverse direction in fire mode) 0XXX:Manual exit fire mode 1 (after the fire mode terminal function is off, manually reset inverter and return to normal mode) 1XXX:Auto exit fire mode (after the fire mode terminal function is off, inverter automatically returns to normal mode) 2XXX: Manual exit fire mode 2 (after the fire mode terminal function is off, the inverter keeps running, manually reset inverter and return to normal mode)	0	
06-85	P.208	Fire mode frequency	0~650.00Hz	60.00Hz	
06-88	P.209	Fire mode accumulated times	Read only	Read only	

➤ Communication Parameter Group 0

Group	No.	Name	Setting Range	Default	User Setting
07-00	P.33	Communication protocol selection	0: Modbus protocol	1	
			1: Shihlin protocol		
07-01	P.36	Inverter communication station number	0 ~ 254	0	
07-02	P.32	Serial communication baud rate	0 : Baud rate:4800bps	1	
			1 : Baud rate:9600bps		
			2 : Baud rate:19200bps		
			3 : Baud rate:38400bps		
			4 : Baud rate:57600bps		
			5 : Baud rate:115200bps		
07-03	P.48	Data length	0 : 8bit	0	
			1 : 7bit		
07-04	P.49	Stop bit length	0 : 1bit	0	
			1 : 2bit		

Group	No.	Name	Setting Range	Default	User Setting
07-05	P.50	Parity check selection	0: No parity check 1: Odd 2: Even	0	
07-06	P.51	CR/LF selection	1: CR only 2: Both CR and LF	1	
07-07	P.154	Modbus communication format	0: 1, 7, N, 2 (Modbus, ASCII) 1: 1, 7, E, 1 (Modbus, ASCII) 2: 1, 7, O, 1 (Modbus, ASCII) 3: 1, 8, N, 2 (Modbus, RTU) 4: 1, 8, E, 1 (Modbus, RTU) 5: 1, 8, O, 1 (Modbus, RTU) 6: 1, 8, N, 1 (Modbus, RTU)	4	
07-08	P.52	Number of communication retries	0~1000	5	
07-09	P.53	Communication interval allowable time	0~999.8s: Checking communication timeout with the set value 99999: No timeout check	99999	
07-10	P.153	Communication alarm action	0: Alarm and stop in idle state 1: No alarm and continue to operate	0	
07-11	P.34	EEPROM write-in selection	0: When writing parameters in communication mode, write in RAM and EEPROM 1: When writing parameters in communication mode, only write in RAM	0	

> PID Parameter Group 08

Group	No.	Name	Setting Range	Default	User Setting
08-00	P.170	PID function selection	0: Off 2:Parameter 08-03(P.225) as target value, terminal 3-5 current/voltage input as feedback source 3: The target value is given by the multi-speed, terminal 3-5 current/voltage input as feedback source	0	
08-01	P.171	PID feedback control method	0: Negative feedback control. 1: Positive feedback control.	0	
08-03	P.225	PID target value from keypad	0~08-43 (P.251)	20.0%	
08-04	P.172	Proportional gain	1~100	20	
08-05	P.173	Integral time	0~100.0s	1.0s	
08-06	P.174	Differential time	0~1000ms	0ms	
08-07	P.175	Abnormal deviation	0~200.0%	0.0%	
08-08	P.176	Abnormal duration time	0~600.0s	30.0s	
08-09	P.177	Abnormal processing mode	0: Stop freely 1: Slow down to stop 2: Alarm and continue operation	0	
08-10	P.178	Sleep detection deviation	0~100.0%	0.0%	
08-11	P.179	Sleep detection duration time	0~255.0s	1.0s	
08-12	P.180	Wake-up level	0~200.0%	90.0%	
08-13	P.181	Stop level	0~120.00Hz	40.00Hz	
08-14	P.182	Upper integral limit	50Hz system:0~120.00Hz 60Hz system:0~120.00Hz	50.00Hz	
08-15	P.183	Deceleration step length when stable	0~10.00Hz	0.50Hz	
08-16	P.223	Analog feedback signal bias	0~100.0%	0.0%	
08-19	P.224	Analog feedback signal gain	0~100.0%	100.0%	
08-43	P.251	PID pressure extreme value	1.0~100.0	100.0	
08-45	P.253	Analog signal feedback loss detection time	0.0~600.0s	0.0s	
08-46	P.254	Analog signal feedback loss action selection	0 : Alarm AErr and inverter stops freely 1 : Slow down to stop then alarm AErr 2 : Alarm AErr and continue operation	0	

> Application Parameter Group 10

Group	No.	Name	Setting Range	Default	User Setting
10-00	P.10	DC brake operating frequency	0~120.00Hz	3.00Hz	
10-01	P.11	DC brake operating time	0~60.0s	0.5s	
10-02	P.12	DC brake operating voltage	7.5K/11KF and below model : 0~30.0% 11K/15KF and above model:0~30.0%	4.0% 2.0%	
10-03	P.151	Zero-speed control function selection	0: Off. 1: DC voltage braking	0	
10-04	P.152	Voltage at zero-speed control	7.5K/11KF and below model : 0~30.0% 11K/15KF and above model:0~30.0%	5.0% 2.0%	
10-05	P.242	DC brake before inverter starts	0: Off 1: Before starting to operate DC brake	0	
10-06	P.243	DC brake time before inverter starts	0~60.0s	0.5s	
10-07	P.244	DC brake voltage before inverter starts	7.5K/11KF and below model : 0~30.0% 11K/15KF and above model:0~30.0%	4.0% 2.0%	
10-08	P.150	Restart mode selection	X0 : No frequency search. X1 : Reserved. X2 : Decrease voltage mode 0X : Power on once. 1X : Start each time. 2X : Only instantaneous stop and restart 3X : Only valid when the fire mode is reset	0	
10-09	P.57	Restart idling time	0~30.0s 99999: Off.	99999	
10-10	P.58	Restart rising time	7.5K/11KF and below model : 0~60.0s : 11K/15KF and above model : 0~60.0s :	5.0s 10.0s	
10-11	P.61	Remote control function	0: Off X1 : Remote control function, frequency can be memorized. X2 : Remote control function, frequency can't be memorized X3 : Remote control function, frequency won't save, clear frequency setting every time STF/STR 'turn off'. X4 : Remote control function, frequency will be memorized every 5s 1X: Target frequency 01-01(P.2)-01-00(P.1), target frequency value from RH/RM setting	0	

Group	No.	Name	Setting Range	Default	User Setting
10-12	P.65	Auto reset function	0: Off. 1: When over-voltage occurs, inverter will reset. 2: When over-current occurs, inverter will reset. 3: When either over-voltage or over-current occurs, inverter will reset. 4: When any alarm occurs, inverter will reset.	0	
10-13	P.67	Auto reset times	0: Off. 1~10: If the alarm exceeds 10-13(P.67) times, inverter will not reset.	0	
10-14	P.68	Auto reset waiting time	0~360.0s	6.0s	
10-15	P.69	Alarm reset accumulated times	Read only	0	
10-16	P.119	Forward and reverse rotation dead time	0~3000.0s	0.0s	
10-17	P.159	Energy-saving control function	0: Off. 1: Energy-saving mode.	0	
10-18	P.229	Dwell function selection	0: Off. 1: Backlash compensation function. 2: Acceleration and deceleration interrupted waiting function.	0	
10-19	P.230	Dwell frequency at acceleration	0~650.00Hz	1.00Hz	
10-20	P.231	Dwell time at acceleration	0~360.0s	0.5s	
10-21	P.232	Dwell frequency at deceleration	0~650.00Hz	1.00Hz	
10-22	P.233	Dwell time at deceleration	0~360.0s	0.5s	
10-23	P.234	Triangular wave function selection	0: Off. 1: If external signal TRI is triggered, triangular wave function will be turned on. 2: Triangular wave function is on at all time.	0	
10-24	P.235	Maximum amplitude	0~25.0%	10.0%	
10-25	P.236	Amplitude compensation at deceleration	0~50.0%	10.0%	
10-26	P.237	Amplitude compensation at acceleration	0~50.0%	10.0%	
10-27	P.238	Amplitude acceleration time	0~360.00s/0~3600.0s	10.00s	
10-28	P.239	Amplitude deceleration time	0~360.00s/0~3600.0s	10.00s	
10-46	P.268	Voltage stall level	220V : 155~400V 440V : 310~800V	380V 760V	
10-55	P.226	Reciprocating machine function selection	0 : Off 1 : Turn on reciprocating machine function	0	
10-56	P.227	Reciprocating forward limit time	0~3600.0s	0.0s	
10-57	P.228	Reciprocating reverse limit time	0~3600.0s	0.0s	

> Speed control parameter group 11

Group	No.	Name	Setting Range	Default	User Setting
11-00	P.320	Slip compensation gain	0~200%	85%	
11-01	P.321	Torque boost filter coefficient	0~2000	20	
11-02	P.322	Cutoff frequency point of current filter time 1	0~30.00Hz	4.00Hz	
11-03	P.323	Current filter time 1	0~400.00ms	According to kw	
11-04	P.324	Low frequency current filter time 2	0~400.00ms	According to kw	
11-05	P.325	High frequency current filter time 2	0~400.00ms	According to kw	

> Special Adjustment Parameter Group 13

Group	No.	Name	Setting Range	Default	User Setting
13-00	P.89	Slip compensation coefficient	0~10	0	
13-03	P.286	High frequency vibration suppression factor	0.2K~5.5K model: 0~1515 7.5K/11KF and above: 0~1515	300 509	

> User Parameter Group 15

Group	No.	Name	Setting Range	Default	User Setting
15-00	P.900	User registered parameter 1		99999	
15-01	P.901	User registered parameter 2		99999	
15-02	P.902	User registered parameter 3		99999	
15-03	P.903	User registered parameter 4		99999	
15-04	P.904	User registered parameter 5		99999	
15-05	P.905	User registered parameter 6		99999	
15-06	P.906	User registered parameter 7		99999	
15-07	P.907	User registered parameter 8		99999	
15-08	P.908	User registered parameter 9		99999	
15-09	P.909	User registered parameter 10		99999	
15-10	P.910	User registered parameter 11		99999	
15-11	P.911	User registered parameter 12		99999	
15-12	P.912	User registered parameter 13		99999	
15-13	P.913	User registered parameter 14		99999	
15-14	P.914	User registered parameter 15			