



#### 4.Parameters

parameter	description	setting	parameter	description	setting
PA01	Control mode	0001	PC01	Acceleration time constant	100
PA03	Auto-tuning response level setting	7	PC02	Deceleration time constant	100
PA05	Internal torque limit	30	PC03	S-pattern acc./dec. time constant	50
PA06	Electronic gear ratio numerator	1000 0	PC18	Stop option and power interruption restart option	0000
PA07	Electronic gear ratio denominator	7786	PD01	Digital input signal auto-ON option 1	1110
PA13	Pulse command select	0012	PD07	Digital input 6 option	0004
PA14	Encoder output pulses	500			
PA39	Motor rotary direction option	0011			

#### 5.Adjustment suggestion

1. Make sure all pins are wired correctly and never short circuit.
2. Restore the drive to factory settings and PA40=0088, and power off for 5 seconds.
3. Use the SDA debug software to detect if all I/O terminals are correct. " closed should be ON, open should be OFF"
4. Use the SDA debugging software to do JOG operation and observe whether the motor direction is normal.